G GOLDONI



OPERATOR MANUAL

S 65-80 **Q** 80

MACHINES FOR LIFE ___



SUMMARY

Chapter No.	Description
1	GENERAL INFORMATION
2	GENERAL SAFETY REGULATIONS
3	TECHNICAL FEATURES
4	COMMANDS AND INSTRUMENTS
5	RULES OF USE
6	SERVICE CHECKS
7	INCONVENIENCES AND REMEDIES



1 : General Informations

Index

1.1	1 Introduction1-2			
1.2	Note t	o owner	1-2	
1.3	Prope	r and improper use of the tractor	1-4	
	1.3.1	intendedUse	1-4	
	1.3.2	Unintended and improper use	1-5	
	1.3.3	Electromagnetic compatibility (EMC)	1-6	
1.4	Gene	ral informations and required training	1-6	
	1.4.1	manualusage	1-6	
	1.4.2	Unified signaling devices	1-7	
	1.4.3	Units of measurement used in this manual	1-9	
	1.4.4	TractorOrientation	1-9	
	1.4.5	Tractor delivery methods	1-10	
	1.4.6	Liability of the tractor owner	1-10	
	1.4.7	Operators liability	1-11	
	1.4.8	Warranty		
1.5	Identi	fication plates	1-12	
	1.5.1	Localization of tractor identification data	1-12	
	1.5.2	Engine Information		
	1.5.3	Chassis	1-13	
	1.5.4	Tractor identification plate	1-14	
	1.5.5	Nameplate with protective frame type	1-15	
1.6	САВ С	lassification	1-16	
1.7	Appro	val types	1-16	

1.1 Introduction

Keep this "owner's manual" carefully and do not neglect to consult it regularly.

Because of the considerable diversity of conditions of use, it is impossible for the company to provide perfectly upto-date and complete publications relating to the performance or methods of use of the tractors of its manufacture and thus to assume responsibility for loss or damage that may result from what is published or from any error or omission. In the event that the vehicle is to be used in particularly severe abnormal conditions (e.g., high water or very muddy terrain), we recommend that you consult your Dealer for specific instructions to avoid voiding the warranty.

The Tractor Manufacturer will accept no responsibility for any damage or injury due to improper use of the tractor, the risks of which will be borne solely by the user.

Compliance with and strict adherence to the conditions of use, service and repair specified by the Manufacturer are also substantially part of the intended use.

When operating, servicing and repairing this tractor, it is necessary to be fully aware of all its specific features and to be exactly informed of the relevant safety regulations (accident prevention).

We recommend that you contact an Official Reseller for any service or registration problems that may arise.

All rights reserved. This manual may not be reproduced or copied, in whole or in part, without the written permission of the Manufacturer.

It is specified that all trademarks that differ from those GOLDONI KEESTRACK s.r.l., companies that are part of the owner group, licensees or controlled by them, referring to third-party products and/or services in the following document belong to their respective owners.

1.2 Note to the owner

This manual contains useful information for proper maintenance. The tractor provided is reliable. Its performance and longevity depend on good maintenance and proper use of the tractor. This manual should be read by all tractor operators and kept handy at all times.

Upon delivery, The dealer will provide instructions on the general operation of the new tractor. Maintenance personnel are available to provide any clarification regarding the operation of the tractor.

The dealer has a full line of original spare parts. Parts are carefully manufactured and inspected to ensure high quality and fit of the parts needed. When ordering replacement parts, provide the dealer with the product serial number and model of the equipment. Locate these numbers now and transcribe them in the spaces provided below. Refer to the "General Information" section of this manual for the location of the model number and product identification number.

Contact the authorized dealer to learn about and order any additional fittings. Use the identification data of your vehicle copied from the plates and reported manually on this page.



Using genuine spare parts safeguards and ensures the perfect efficiency of the tractor. Using non-original spare parts or fitting them incorrectly will cause forfeiture of warranty.

RECORD THE FOLLOWING DATA IN THE SPACE BELOW

Model:	
Tractor identification number:	
Engine identification number:	
Date of purchase:	
Name of authorized dealer:	
Number by phone Of the authorized dealer:	

Safety plates with or without precautionary notations are provided on the tractor to warn the user of potential hazards that could result in personal injury. Comply with all safety messages to avoid possible injury or death

The tractor was designed and built in compliance with the quality standards required by current safety regulations. Nevertheless, the risk of accidents can never be completely eliminated. Therefore, it is essential to follow the required elementary safety rules and precautions. To avoid the risk of injury when using or repairing the tractor, read this manual carefully and pay special attention to the instructions on safety, operation and maintenance.

Use this tractor only for the jobs and applications given in this manual. When using the tractor in work requiring the application of special equipment, consult the dealer to be sure that adaptations or modifications comply with the tractor's technical specifications and meet current safety regulations.

Modifications or adaptations without the manufacturer's approval may invalidate the tractor's initial compliance with safety requirements.

The instruction manual should be kept on the tractor. Verify that it is complete and in good condition. To receive additional copies of the manual or copies in languages other than your country of residence, contact your dealer.

The manufacturer is committed to the constant improvement of its products. Therefore, the company reserves the right to make improvements or modifications whenever possible, without incurring any obligation to modify or change the means previously sold

The tractor should undergo periodic inspections, the frequency of which varies according to the type of use. Contact the authorized dealer.



Warning

The information in this manual is provided based on information available at the time of writing. Settings, procedures, part numbers, software, and other items may change which may affect the maintenance of the tractor. Check with the dealer that you have the complete and up-to-date information before operating the tractor. All data provided in this manual are subject to manufacturing variations.



The injection system and engine installed on the tractor comply with government emission standards. Any tampering applied on the tractor is strictly prohibited by law. Failure to comply with these provisions could result in:

- government sanctions;
- Charging costs for adjustments;
- Forfeiture of warranty;
- legal action and possible confiscation of the tractor until it is restored to its original condition.

Maintenance and/or repair of the engine should only be carried out by a trained technician!

Correct and incorrect use of the tractor

1.2.1 Intended use



The tractor has been designed and built in accordance with European directives on the prevention of health and safety risks. To minimize possible risks, to avoid any possible exposure to hazards or risks, it is essential that you read this manual carefully. You must understand and observe the indications and warnings on all decals, nameplates, and labels on the tractor. For any further information on this matter, please contact your dealer.



The tractor is also approved for road use, if it is registered and provided by license plate.

To operate in accordance with the intended use of this tractor, it is necessary to follow the instructions in this manual, and the routine maintenance and repair rules established by the manufacturer.

Persons who operate, maintain, and repair the tractor must be fully familiar with the tractor itself, any associated hazards, and must be properly trained and informed on the proper operation of the tractor, the contents of this manual, and the rules established by the manufacturer.

People who use, maintain and repair the tractor must always operate in compliance with the rules on occupational safety and hygiene, occupational medicine and road legislation to prevent accidents that can even cause death.

Any other use that does not comply with the above statement will be considered unintended or improper use and will automatically relieve the manufacturer of any liability in case of accidents. The responsibilities will fall totally on the user.

All persons operating the tractor must have a valid local permit to operate the vehicle or comply with applicable local regulations.

Please read the following directions carefully:

- Use the tractor only for the uses intended by the manufacturer and listed in this manual.
- Use the tractor safely.
- Correctly connect equipment. Using unapproved or improperly fitted implements and accessories could be a cause of tipping over, caused by their detachment.
- Ensure that the three point linkage corresponds to ISO 730 standards.
- Check that the speed and dimensions of the PTO on the tractor match those of the attached implement.
- Before using tractor-connected implements, carefully read the specific Instruction Booklet supplied with the implement. The tractor is a tool that allows it to be used in multiple configurations. It is not possible in this manual to report all safety-related information in the various configurations of the tractor.
- Before using the tractor for towing, or stump extraction, carefully check the tractive effort. Especially when attempting to extract stumps, the tractor may tip over should the latter fail to yield.
- The center of gravity of the tractor may increase when lifting weights at the rear lift or using a front-lift or loader In these situations, the danger of sudden rollover increases.
- Leave the driver's seat and get off the tractor only after performing the following maneuvers:
 - Bring the speed shift levers into neutral.
 - Apply the handbrake and, if present, the parking lock.
 - Disconnect the PTO unless it is to be in operation for certain implements.
 - Lower any implements attached to the tractor.

- When maneuvering with the tractor, take care that there are no people close of the operating area, especially if restricted
- When starting work, ask people to move away from the operating area. During the working phases, there is a risk of being hit by objects ejected from implements attached to the tractor (rotary mowers, power harrows, etc.).
- Be careful when working near roads or footpaths. Objects can be ejected beyond the work area, striking passers by. Stop and wait until the working area is clear before resuming operations.
- Only operators should ride on the tractor; do not allow anyone to stand or climb on the ladder accessing the driver's seat with the tractor in motion. In this situation, the operator's view is restricted, with the potential danger of falling.
- Maintain a safe distance from the implements working area. Do not stand between the tractor and the implement or the towed vehicle when using the external controls of the lift. Make sure that there are no untrained people in the work area.
- The tractor is equipped with software that controls certain safety functions. Do not tamper with these functions for any reason or download software that is not certified by the manufacturer. Uncertified software could compromise its proper functioning. This can be the cause of abnormal behavior of the tractor, thus reducing both performance and safety. For any software intervention, contact your dealer.
- Some safety functions are controlled by sensors. Their activation ensures their proper functioning.
- The tractor has only one operating station, so it can be operated by a single user.

1.2.2 Unintended and incorrect use

Any type of use not intended by the manufacturer is not considered to be in accordance with the intended use and therefore constitutes an incorrect use. The manufacturer will be relieved of any liability in the event of accidents and the user will be held responsible for all risks deriving from such use.

The list below lists a series of examples, uses and incorrect behaviors of this tractor that put the operator's life and health at risk.

- Allow the use of the tractor to people who have not been previously trained.
- Use the tractor on surfaces and spaces that cannot be defined as an agricultural work area or as a maintenance area
- Transporting people on tractors without a passenger seat. Transporting people without using the passenger seat (where available). Carry people in the field even in a passenger seat.
- Use the tractor for competitions or sporting events.
- Use the tractor to round up grazing animals.
- Start and move the tractor from the ground.
- Exceed the maximum admissible load.
- Do not follow the warnings on the tractor and in this manual.
- Repair and service the tractor while it is running and/or moving forward.
- Maintenance, cleaning, recording, and adjustments without complying with the safety recommendations contained in this manual.
- Make changes to the tractor without first contacting the Dealer or the manufacturer.
- Connect implements/equipment that are not compatible with each other and the tractor itself or that are not authorized.
- The use of non-original spare parts.

1.2.3 Electromagnetic Compatibility (EMC)

This tractor complies with European regulations on electromagnetic emissions. However, interference may occur due to the presence of auxiliary equipment. Auxiliary equipment may not conform to the standards required by those regulations.

These interferences could be the cause of serious abnormal operating and safety behaviors. To overcome these problems, follow the instructions below:

- check that all equipment other than that supplied by the manufacturer installed on the tractor bears the CE mark:
- the maximum power of emitting appliances must not exceed the limits imposed by the authorities of the tractorry's country of destination;
- the electromagnetic field generated by the auxiliary equipment must never exceed the value of 24 V/m at any point near electronic components.

Failure to observe these rules will result in the forfeiture of the tractor manufacturer's warranty.

1.3 General information and required training

1.3.1 Using the manual

This manual contains all the information related to service, the use of the tractor and the operations necessary to keep it in good working order.

Some of these operations must be carried out exclusively by specialized dealer personnel because they may require the use of adequate equipment/structures, not supplied with the tractor itself.

It is mandatory for all tractor users to read this manual carefully to:

- identify all hazards deriving from the use of the tractor;
- identify the components of the tractor, their function, the controls and all the implements for a correct and safe use of the tractor;
- become aware of the deadlines and methods of routine maintenance for a safe and correct use of the vehicle;
- quickly identify and locate possible faults to intervene in emergency situations.

The manual must always be kept on board the tractor, in the appropriate housing, for the duration of its life.



If the tractor is sold, always hand over the operator's manual to the new owner. If the tractor is sold to a new owner without an operator's manual, the new owner could be in dangerous situations because he has no way of knowing the safety rules and the tractor itself.

Along with the User Manual, the following documents are provided:

- Warranty certificate: the details of the dealer, the customer and the spaces for the stamps of the coupons are listed.
- Warranty conditions: all the components covered by the warranty are detailed, everything that is excluded and that causes the warranty to lapse.

1.3.2 Unified signaling indicators

Symbol	Description	Symbol	Description	Symbol	Description
	Fault alarm by	b	Acoustic alarm		Beacon A larm
	High beam Ligh warning ts lights		Low beam Lig alarm hts		Work light indicator
<u>}</u>	Rotating beacon indicator	<u> </u>	Position lights indicator		Read The instruction manual
4	Direction indicator by	+	Status indicator by battery charger		Rear window washer wiper indicator
∇	Wiper alert		Windscreen wiper and indicator		Pressure indicator En gine oil
	Engine water temperature indicator		Engine alarm rev s	00	Preheat alarm The engine
	Beacon e ngine failure		Beacon clogged engine air filter		Fuel level indicator
	Fuel supply system fault alarm	€5-0	4WD alarm		Differential lock indicator
	Forward Direction indicator	N	Neutral position by indicator (neutral)	R	Reverse Direction indicator
	Level indicator hydr aulic fluid		Brake fluid indicator	(P)	Brake indicator b

⇒○ ←	Pressure indicator Tra nsmission Oil		Beacon by mainten ance request; consult the technical manual	€© (\$)	Socket marker by Rear force
	Socket marker by Front force	750	Rear 750 rpm PTO indicator	540	Rear 540-rpm PTO indicator
	Liquid level indicator		System of braking, first trailer or first auxiliary circuit	(2)	System b raking system, second trailer or second auxiliary circuit
	Beacon by Lifter descent		Upper limit lifting indicator	$\sqrt[]{\int}$	Lower limit lifting indicator
	Hydraulic oil filter indicator	◇•	Pressure indicator	=======================================	Diesel particulate filter sensor for emissions
	Beacon O perator alert		presence of water in the fuel Indicator		

1.3.3 Units of measurement used in this manual


Following listed units of measurement used in this manual:

Symbol	Description
°C	Degree centigrade
A	Ampere
cm	Centimeter
cm3	Cubic centimeter
dB(A)	Decibel
g	Gram
rpm	Revs per Minute
h	Hour
kg	Kilogram
km/h	Kilometers per hour
kW	Kilowatt
1	Liters
m	Metres
m3	Cubic meters
min	Minutes
mm	Millimeters
N	Newton
N-m	Newton meter
Pa	Pascal
s	According to
V	Volt
W	Watt

1.3.4 Orientation of the tractor

In this manual, to indicate the direction, seen from the operator's seat, following symbols are used:

- 1- Front
- 2- Right
- 3- Rear
- 4- Left



1.3.5 Tractor delivery methods

Upon delivery of the tractor, the dealer must:

- Check the tractor according to the Manufacturer's procedure to ensure that it can operate immediately and safely.
- Explain to the user and all operators of the tractor the main notions of safety, the controls and implements of the tractor and the position of the components subject to maintenance. The illustration of the commands must include: signals (display included), adjustments, starting, stopping, stopping in emergency of the tractor and its components.
- Explain the sections of which it is composed, pointing out the obligation to read the chapter on safety and the one on owner responsibilities.
- Remind all operators intended to drive the tractor and the owner to comply with the regulations in force in the country of use relating to road traffic. Pay particular attention to the rules for speed, towing and transporting equipment.

Upon delivery of the tractor, the owner must:

- Receive the necessary training and information for himself and for all operators intended to use the tractor.
- Receive all the documentation supplied with the tractor, including warranty conditions

Upon delivery of the tractor, operators must:

- Receive the necessary training from the dealer relating to safety rules, tractor controls and implements, and the position of components subject to routine maintenance.
- Receive an explanation from the dealer of the contents of this manual as they are essential to operate safely, use the tractor correctly and carry out routine maintenance operations correctly.

1.3.6 Liability of the tractor owner

The tractor owner is responsible for:

- Read the safety chapter to understand the possible dangers to which operators are subject.
- Order parts for damaged decals to protect operator safety.
- If there are any misunderstandings or inconsistencies between this manual and the tractor, inform the dealer immediately.
- Train and inform everyone who will use the tractor about the dangers and the use of the tractor.
- Make sure that tractor operators read and understand the contents of the manual, especially the safety chapter.
- If necessary, contact the dealers/importers to request a copy of the manual translated into a language understandable to operators.

1.3.7 Operator liability



By 'tractor operators' we mean all those who use the tractor even if rented or under concession.

Please read this manual carefully to:

- Read all safety messages carefully
- Learn how to operate and use the tractor correctly.
- Identify possible risks due to incorrect use of the tractor.
- How to properly maintain the various components.
- Identify the compatible implements for the various processes and the tractor itself.
- Identify the position of the various controls and how they work.
- Identify the position and message of the warning lights on the tractor.
- Report anomalies that compromise the correct functioning of the tractor.
- Carry out periodic inspections as reported in the manual.
- Carry out the scheduled routine maintenance correctly. For extraordinary maintenance or repairs, contact authorized workshops. The manufacturer declines any liability for damage to people or property resulting from repairs or maintenance carried out privately outside the authorized service circuit.
- Report or replace damaged components as a possible cause of safety hazards or damage to the vehicle and the environment.
- Use only original spare parts.
- Only use the tractor for its intended use. The manufacturer declines any liability for damage to people or property deriving from uncorrect uses different than those intended.

1.3.8 Warranty

The Goldoni product warranty system covers, under certain conditions, material or construction defects. Please note that this booklet is published for worldwide distribution, so it is impossible to describe in detail and exactly the terms and conditions of the warranty relating to retail sales in each individual country. All detailed information regarding the warranty terms and conditions can be requested from the Retailer where the tractor was purchased.

The tractor warranty is covered according to the conditions and terms reported in the warranty certificate.

The Service Department provides specialized personnel able to intervene on our products. It is the only service authorized to intervene on the product under warranty.

The Dealer or Dealer is obliged to provide certain services when delivering a new tractor to the customer. These services include a thorough check prior to delivery to ensure that the tractor can be used immediately and the illustration of all instructions relating to the fundamental principles of its use and maintenance. These instructions will cover implements and controls, periodic maintenance, and safety precautions. Training course must be extended to all persons involved in the use and maintenance of the tractor.

Upon delivery of the new tractor, the Dealer or Dealer will carry out a preliminary pre-delivery check to ensure that the tractor can be used immediately. The fundamental principles for its use and maintenance will also be explained. These instructions will cover control implements and controls, periodic maintenance, and safety precautions. The tractor owner undertakes to provide the same information received to all persons involved in the use and maintenance of the tractor.

Any modification, alteration or assembly of components and the use of unapproved implements will void any liability on the part of the Manufacturer.

1.4 Identification plates

1.4.1 Localization of tractor identification data


The tractor is composed of a series of main components that can be identified by plate and/or punching.

The identification data must be provided to the dealer whenever spare parts or service interventions are requested. The same data is also necessary in case of theft of the tractor.

It is recommended to keep them clean and legible. If necessary, request through your dealer the plates that should be damaged or lost and place them in the same position.

1.4.2 Engine Informations

The engine plate is located at the top of the right side of the engine, under the tractor hood.



- A Manufacturer identification
- B Serial number
- C Weight
- D Type
- E Family
- F Model
- G Version
- H Maximum power (kW)
- L Maximum rpm
- M Homologation number
- N Lubrication oil characteristics




Fig. 1.3

1.4.3 Chassis

The data are stamped on the right front side of the tractor.




Fig. 1.4

- 1 Manufacturer brand acronym
- 2 Production series
- 3 Variant
- Y1/Y2 Engine Power
- Y3 Protective Structure
- 4 Version
 - Y4 Speed
 - Y5 Engine stage
 - Y6 Brand
- 5 Chassis number (serial number)




Fig. 1.5

1.4.4 Tractor identification plate

The plate is placed on the platform at the bottom right of the operator's seat.






Fig. 1.6




1.4.5 Nameplate with ROPS frame type

The plate is placed on the right pillar of the ROPS. Meaning of OECD/OECD codes:

- OECD/OCSE 6: The protective frame has passed the ROPS (Roll Over Protection Structure) tests for the front frame; in the event of a rollover, the driver is protected.
- OECD/OCSE 7: The protective frame has passed the ROPS (Roll Over Protection Structure) tests for the front frame; in the event of a rollover, the driver is protected.
- OECD/OCSE 10: The protection frame has passed FOPS (Fall Over Protection Structure) tests the frame resists falling ogjets that have an energy of 1365 Joule.
- 1 Manufacturer of the protective frame
- 2 Name of the protective structure
- 33 EEC approval code
- 4 OECD Approval Code /
- 5 Chassis number (serial number)
- 6 Tractor brand
- 7 Variant/version







1.5 Cabin classification

The classification of the cabin provides information on the protection of the cabin against dangerous substances. Categories 1 to 4 are used to define the level of protection, and it is possible to verify the category by the decal placed on the cabin.

The cab mounted on these models is classified in "Category 1."



The cab mounted on these models is classified in "Category 1." The decal indicating the category is placed on the right front pillar of the cabin.



1.6 Approval types

Commercial name	Туре	Variant	Version	Key Features
S65 ROLL BAR	TL	G 0 1	3 G G	45.0 kW engine
S80 ROLL BAR	TL	H 1 1	3 G G	55.2 kW engine
Q80 ROLL BAR	TL	H 1 1	4 G G	55.2 kW engine
S65 CAB GL9	TL	G 0 0	3 G G	45.0 kW engine
S80 CAB GL9	TL	H 1 0	3 G G	55.2 kW engine
Q80 CAB GL9	TL	H 1 0	4 G G	55.2 kW engine
Q80 CAB SG1	TL	H 1 2	4 G G	55.2 kW engine

2 : General safety standards

Index

2.1	GENE	RAL SAFETY REGULATIONS	2-3
	2.1.1	Important Warnings	2-3
	2.1.2	General Warnings	2-4
	2.1.3	Symbols of safety	2-5
	2.1.4	Identification of dangerous points on the tractor	2-6
	2.1.5	Safety plates	2-7
	2.1.6	Location of security decals	2-8
	2.1.7	Use of the tractor	2-19
	2.1.8	Towing and transport	2-20
	2.1.9	PassengersTransportation	2-20
	2.1.10	Lifting capacity	2-20
	2.1.11	Use of implements	2-22
	2.1.12	Do not stand between the tractor and the implement	2-22
	2.1.13	Prevention of fires	2-22
	2.1.14	Safety measures for tyres use and maintenance	2-22
	2.1.15	Wheel bolting check	2-23
		Maintenance and storage	
		Restarting after storage	
		Safety measures for parking	
	2.1.19	Working tightness	2-24
	2.1.20	Safety measures for maintenance	2-24
	2.1.21	Beware of high-pressure fluids	2-25
		Safety measures for handling fuel	
		Things to do before refueling	
		Safety standards electrical equipment	
		Battery safety regulations	
	2.1.26	PTO safety regulations	2-27
		seat belts	
		Safety regulations - Lifting and suspended loads	
		Rollover protection structure	
		Operator Protection Structure (FOPS)	
		Operator Protection Structure (ROPS)	
		Front loader (if available)	
		Safety regulations Air conditioning system	
		Personal protective equipment	
	2.1.35	Safety regulations - 'Do not use' sign	2-30

2.1.36	Chemicals hazardous	2-30
2.1.37	Safety information for the application of plant protection products,	
	(PPP)	2-31
2.1.38	Get in and out	2-31
2.1.39	Jobs in forestry	2-31
2.1.40	Vibrations level	2-32
2.1.41	Safety information for accidental contact with electric power lines .	2-32
2.1.42	Weathering safety information	2-33
2.1.43	Tractor electrical system	2-33
2.1.44	Stability of the tractor	2-33
2.1.45	Environment safety Standards	2-34
2.1.46	Disposal and scrapping	2-34

2.1 General safety standards

2.1.1 Important Warnings

Carefully read the safety regulations listed and follow the precautions indicated in order to avoid potential dangers and to safeguard your health and safety.

This tractor has been designed and manufactured only for agricultural uses. Any other use will be considered contrary to the use intended by the manufacturer who, therefore, cannot be responsible for damage to property and to the tractor itself or for injuries to people that may result from it.

The tractor must be used, serviced or repaired only by people who have been previously trained on the work environment and on safety regulations, in addition to being authorized to operate the tractor itself.

It should be considered that in taking the risk of improper use, subject also assumes the consequent responsibility.

Compliance with the operating, maintenance and repair operations described in this booklet are essential elements that qualify the use intended by the manufacturer.

The user must be trained and instructed in advance on tractor usage and on safety regulations before operating the tractor itself.

Any changes made to this tractor without first contacting and obtaining the consent of the manufacturer to intervene, relieves the Manufacturer himself of any liability for damage or injury.

The Manufacturer and all the Organizations in its distribution organization, decline any liability for damage that may result from the abnormal behavior of parts and/or components not approved by the manufacturer.

2.1.2 General Warnings

This tractor has been designed to make your work safer. Caution is irreplaceable, it is important to prevent accidents. It's too late to remember what should have been done when the accident has already happened. Do not attempt to start or operate the tractor without being in the driver's seat.

Read this manual carefully before starting, using, refueling, or other interventions on the tractor. The time dedicated to reading will give you an adequate knowledge of your tractor, useful to save you time and effort. It will also help you avoid the occurrence of any accidents.

Read all the safety decals on the tractor and comply with the regulations set out in this manual, before operating, restocking or servicing the tractor. Promptly replace damaged, lost or illegible ones. Clean them when they are covered by mud or debris.




Fig. 2.1

Learn the characteristics of your tractor and how to use all the equipment, implements and attachments mounted on it. Learn the use and function of each command, indicator, and instrument.

To prevent accidents and for proper tractor operation, it is important to know how to use each control, indicator and tool. You need to know the rated load capacity, speed range, brake and steering system characteristics, turning radius, and spaces of use.

Always operate with the cab or ROPS intact and properly mounted on the tractor. Check periodically that the related fasteners are not loose and that the structures do not have injuries or deformations caused by accidental shocks. Do not make changes to it by welding parts, drilling holes, etc., so as not to alter the rigidity of the ROPS structure.

Keep a first aid kit available so that you can take action as soon as possible in case of need. Make sure you know how to use these equipments.

Don't wear fluttering clothing, jewelry that can be easily grabbed by any moving part or get entangled on the tractor controls. Tie long hair.

Check that all rotating parts connected to the power take-off shaft are well protected.

2.1.3 Safety Symbols

Within this manual, there are the precautionary annotations DANGER, WARNING and ATTENTION, followed by special instructions. These precautions are provided for the personal safety of the operator and his collaborators.

Read carefully all the messages contained in this manual, before carrying out repair/maintenance work.

Contact the authorized dealer to learn about and order any additional equipment. The spare parts catalog is in fact available only from the authorized dealer. Use the identification data of your vehicle copied from the plates and reported manually on this page.



Symbol used to alert the operator to the presence of potential hazards, which could, if not respected, cause personal injury. Respect all safety messages that follow this symbol to avoid possible injuries, even fatal ones.



Warining

This type of message indicates a potentially dangerous situation that, if not avoided, can result in minor or moderate injuries.



Attention

This type of message refers to potentially dangerous situations that may result in minor injuries, if not avoided



Danger

This type of message indicates a potentially dangerous situation that, if not avoided, will cause death or serious injury.

2.1.4 Identification of dangerous points on the tractor




Fig. 2.2

1- Front/rear wheels	Running out by the moving tractor. Crushing by the tire.
	Tire explosion.
2- Access to the driver's seat	Falling hazard .
	Pay attention to contact with hot parts.
3- Front/rear implements attachment	Attention to rotating parts (PTO).
	Danger of crushing caused by connected implements. Danger
	of suspended loads falling.
	Danger of oil leakage under pressure.
4 - Cabin	Danger of entry of toxic/harmful substances. Danger
	of entry of falling objects.
	Pay attention to the reduced field of view.
	Damage due to non-use of seat belts .
5- Engine bonnet	Pay attention to contact with hot parts.
	Pay attention to possible contact with parts under load. Pay
	attention to the presence of sharp parts.
	Pay attention to rotating parts (e.g. fan).
6- Fuel supply	Beware of spilled fuel. Fire hazard.
	Pay attention to contact with hot parts.

2.1.5 Safety plates

Safety tags are applied to the tractor to safeguard the personal safety of operators and other persons involved.

Observe the contents and location of these safety signs before operating the tractor.

It is important to carefully read, understand, and observe the directions and warnings on all safety decals and the information provided in the operator's instruction manual.


Do not remove or obscure safety decals and instructions.

Keep the safety signs legible by cleaning them with a soft cloth, water and non-aggressive detergent. Replace any unreadable or missing safety labels and instructions that can be found at your dealer.

In the event of loss or damage, you can request replacement decals from authorized retailers. If you purchased a used tractor, check that all the decals and safety instructions are present, legible, and in the correct position. To do this, see the section on the presentation and location of these decals.

2.1.6 Location of security decals


The following safety decals should never be removed from their original position on the tractor. If, due to maintenance or deterioration, they should be removed or become unreadable, it is necessary to proceed with their restoration, applying them in the correct position, indicated in this paragraph.



(A) 00065368 - Entanglement hazard

WARNING: Danger of entanglement in belt drives. Keep your hands away from rotating parts and belts while the engine is running. Turn off the panel and remove the key before inspect the tractor. Read the technical manual for more information.

POSITION Radiator, right and left side.



(B) 00065374 - Risk of shearing

WARNING: Shear hazard - motor fan. Keep your hands away from the fan and belts when the engine is running. Do not remove the safety protectors. Turn off the engine and remove the key before performing maintenance or repair work.

POSITION Water radiator, right and left side



(C) 00065415 - Risk of burns - hot surfaces

WARNING: Keep away from hot parts of the engine when it is running. Turn off the engine, remove the key, and wait for the system to cool down before carrying out maintenance or repair work.

POSITION Engine exhaust, hot surfaces.



Fig. 2.6




Fig. 2.7

(E) 00069710 - Pinch point danger

WARNING: Pinch point danger due to moving parts. Keep your hands away from the adjustable connecting levers. Never access the crush zone as long as the parts can move.


POSITION Front lift area.



(F) 00065402 - Risk of sunburn

ATTENTION: Risk of sunburn - High pressure steam and hot water. Turn off the engine, remove the key, and wait for the system to cool down before removing the radiator cap. Remove the filling cap with extreme care. Read the technical manual for more information.

POSITION Water radiator, right and left side /Water radiator expansion tank.



(G) 00065378 - Tractor out of control, danger of being overwhelmed

DANGER: Danger of being overwhelmed. Start the engine only when you are sitting in the seat with the power outlet disconnected and the transmission in neutral mode. DO NOT short circuit the starter terminals to start the engine.

POSITION Starter



Fig. 2.10

(H) 00065367 - Risk of electric shock

WARNING: Electric shock hazard - Risk of personal injury and damage to components. Disconnect the battery before servicing the electrical system. Read the technical manual for more information.

POSITION Battery disconnect zone.





Fig. 2.11

(I) 00065377 - Battery Risks

DANGER: Lead-acid battery risks or explosive gases; or Corrosive liquid (sulfuric acid); Keep away from open flames or sparks. Protect your eyes when working on or around the battery. Read the Safety and Operating Information in the Operator Instruction Book for more information.


POSITION Battery support zone.



(L) 00065965 - Entanglement Risk - PTO, Rotating Shafts

DANGER: Risk of entanglement —PTO. Keep your distance from rotating trees shaft Keep all PTO carters, rotating shafts, in neutral during operations.


POSITION PTO Carter.



(L) 00065376 - Entanglement Risk - PTO, Rotating Shafts

DANGER: Risk of entanglement —PTO. Keep your distance from rotating trees shaft Keep all PTO carters, rotating shafts, in neutral during operations.

POSITION Rear PTO



(O) 00065369 - Tractor out of control, danger of being overwhelmed

WARNING: tractor out of control. Danger of being overwhelmed. Turn off the engine, pull out the ignition key, and turn on the parking brake before leaving the tractor.

POSITION (Cabin version): left pillar.

POSITION (ROPS version): left pillar.



Fig. 2.16

(P) (P) 00065371 - tractor rollover

WARNING: Falling or being crushed danger if the tractor overturns. Keep your seatbelts securely fastened while using, do not jump if the tractor starts to tilt. Do not use the tractor on slopes or in conditions that compromise its safety and stability limits.

POSITION (Cabin version): left pillar.

POSITION (ROPS version): left fender.



Fig. 2.17

(Q) (Q) 00065370 - Read the Operator Instruction Manual

WARNING: To avoid personal injury, read the Operator Instruction Manual and safety information before operating the tractor.

POSITION (Cabin version): right central pillar.

POSITION (ROPS version): right pillar.



(R) 00065382 - Danger of explosion

DANGER: Danger of explosion - material under pressure. Filling the accumulators with nitrogen only

GENERAL SAFETY REGULATIONS




Fig. 2.19

(S) (S) 00067313 - Bonnet opening

WARNING: Engine bonnet opening: Before opening the bonnet, turn off the engine and read the instructions in the Operator's Manual.

POSITION Engine bonnet opening area.



Fig. 2.20

(T) Hydraulic valves:

WARNING: For road driving, lift the implements to the required height and lock the hydraulic functions of the tractor. When the front lifter is not in use, it is essential to lock the hydraulic functions.

POSITION Draft Control /electronic rear lift: Lift flow locking zone Hydraulic spool valves levers: Hydraulic spool valves levers area.



Fig. 2.21

(V) 00065387 - Personal Protective Equipment (PPE)

WARNING: Wear the appropriate personal protective equipment (PPE) for the job to be performed, including safety shoes, protective glasses, face protection, helmet, work gloves, respirators, hearing protection headphones.

POSITION (Cab version): left side.

POSITION (ROPS version): left side.




Fig. 2.22

- A First Category
- B Second Category
- C Third Category




Fig. 2.23

(w) Hazardous environments.

WARNING: Hazardous environments. Wear protective clothing, safety glasses and a respirator before working in an area that is being treated. See the Operation section of the operator's manual for detailed information.

POSITION (Cab Version): left front pillar.

00065386 - Always Lock Rollbar

DANGER: Risk of rollover and personal injury.



Fig. 2.25

00065385 - Danger of being overwhelmed

WARNING: Do not stand on the fender while driving and do not carry people. Sitting in this tractor is allowed in a passenger seat and only if the driver's view is not obstructed.

LOCATION (ROPS version): Left rear fender.



00065423 - Falling danger

DANGER: Access the driver's seat via the stepladder and special handles, ensuring three points of contact at all times.

POSITION Control console: left side.



Fig. 2.27

 (\varnothing) 00065623 - Brake Oil/Fluid - Read the Operator's Manual

WARNING: Brake oil/fluid - The red indicator light on the dashboard indicates the presence of a brake system malfunction. Read the specific instructions in the Operator Instructions Manual carefully.

POSITION Oil/brake fluid tank area.





Fig. 2.28

00067434 - Lifting point

WARNING: To identify the locations on the tractor where a lifting cylinder or support device may be used. Lift only the front or rear , never at the same time. Always place the wheel locking wedges on the axle that is not being lifted. Read the instructions in the Operator's Manual.

POSITION Front and rear axle center, front area.



00067346 - Grease lubricant

ATTENTION: The decal indicates the greasing points. Grease at the indicated points, read the instructions in the Operator's Manual.

POSITION Greaser point area.




Fig. 2.30





Fig. 2.31

00069712 - Refrigerant under pressure

WARNING: Refrigerant (R134A) under pressure. Maintenance operations should be carried out only by trained personnel at the dealer's premises.

POSITION Radiator area.



FDM51201104 - Roll-bar lifting point

WARNING:

POSITION Left roll-bar column with a central height 1500 mm above the ground.




Fig. 2.33

FEM51201102 - Step presence

WARNING:

POSITION Left footboard and step.




Fig. 2.34

2.1.7 Use of the tractor

Select the Track width that are most suitable for the job to be carried out, always considering that you can have the best stability.

Gradually engage the clutch. An abrupt engagement, especially when disengaging from excavations, ditches, muddy ground or moving on a steep slope, can cause dangerous tractor sudden raise Disengage the clutch promptly when the front wheels tend to lift up.

When driving downhill, keep the tractor with one gear in place. Never disengage the clutch and never position it in neutral.

Proceed with the maximum care when operating near the edge of ditches or escarpments. If you have to work with a tractor in altitude, for example on the sides of hills, proceed at a moderate speed and avoid sudden or too tight steering.

When the tractor is moving, the operator must be properly seated in the driver's seat. Do not get on or off the tractor in motion.

If you need to use the brake, press the pedal gradually. Avoid

taking corners at high speed.

When transferring to roads open to traffic, comply with traffic regulations. When driving, do not

keep your feet on the brake and clutch pedals.

Never carry passengers, not even inside the cabin, unless the tractor has a regularly approved additional seat. In this case, the passenger must be seated in the extra seat with the seat belt fastened.

When traveling on the road, always connect the brake pedals using the appropriate plate. Braking with the pedals not connected may cause the tractor rolling over Do not abuse the use of brakes but prefer the use of engine brakes.

2.1.8 Towing and transport

Towing

For good tractor stability while driving, follow the instructions listed below:

- The braking space increases with the speed and weight of the towed load. Proceed slowly and keep an extra amount of time and safety distance to arrest.
- Adjust the towing device correctly depending on the vehicle to be towed or the tool to be towed.
- Proceed slowly when towing very heavy loads.
- For your safety, do not tow trailers without an independent braking system.
- When towing, never take turns with the differential locked because you may not be able to steer the tractor.
- Never allow children or others to be carried in or on the towed implement
- Use only approved hooks.
- Tow only tractor equipped with a homologated towing hook. Towed implement must be attached only to the approved Hitching system.
- Never drive downhill with clutch in neutral.
- Do not stay in the area between the tractor and the towed vehicle.
- Do not make abrupt turns. Pay special attention when making turns or operating on surfaces in difficult conditions. Use caution when going reverse.
- Towing too much load can cause loss of traction and loss of control on slopes. Reduce the towed weight when operating on slopes.
- The total towed weight must not exceed the combined weight of the tractor, ballast and operator. Use counterweights or ballasts on the wheels as described in the implement or tractor operator's manual.

Transport

- The tractor must be towed just over short distances and not on public roads.
- An operator must remain in the driver's seat in the towed tractor.
- The speed must not exceed 10 km/h.

2.1.9 Passenger transportation

Only the presence of the operator is allowed on the tractor. Do not carry passengers. Passengers in the tractor or implement may be hit by external objects or thrown from the tractor with serious consequences.

The transportation of a passenger without a seat causes violent shocks in the event of an accident. DO NOT carry the passenger if the tractor does not have a special seat provided by the manufacturer.

Passengers obstruct the operator's view, with the result that the tractor is not used safely.

The passenger seat, if any, allows the passenger to be transported only in road operations. DO NOT carry the passenger while working in the field.



Note

For some markets and some tractor models, where permitted by local legislation, a foldable passenger seat is available.

2.1.10 Lifting points

When, for reasons of intervention on the tractor, it is necessary to lift it, follow the following:

- Park the car on a flat surface.
- Lock the wheels.
- Before lifting, make sure that there are no people nearby.
- Check the suitability of the equipment to be used before repare
- Use implements that can support the tractor complete or partial weight
- Do not intervene under the tractor lifted only by hydraulic jacks.
- Keep the tractor suspended with safety stands.
- To lift the tractor, use only the points indicated in the figure.
- Always lift the tractor only from the rear or front, never simultaneously

Always place locking wedges in front of or behind the wheels of the not lifted axle



danger

When lifting the tractor from the front, place fixed support stands under the rear side axles to prevent the tractor swinging.

When lifting the tractor from the rear, place fixed support stands under the front side axles to prevent the tractor swinging.





Fig. 2.35

The correct tractor lift points are listed below: Front axle.



Rear differential crankcase.




Fig. 2.37

2.1.11 Use of agricultural tools and machinery

Do not attach implements or operating tractors to the tractor that require power greater than the tractor's class.

Do not face sharp turns with the PTO under heavy load; to avoid causing damage to the cardan joints of the drive shaft connected to the PTO itself.

When using implements that require a stationary tractor with the engine running, keep both the gear and the gear splitter in neutral, lock the handbrake. The use of a stopping wedge is also recommended.

Before using the PTO connected to an operating tractor, always make sure that there are no people within the operating tractor's range. Also check that all the rotating parts connected to the power take-off shaft are well shielded.

2.1.12 Do not stand between the tractor and the implement

The tractor may advance suddenly or the implement may suddenly start moving.

In order to avoid serious physical damage, sometimes even fatal, never stop between tractor and implement or between tractor and trailer to facilitate the connection when the tractor backs up.

- Before performing any type of operation that requires you to stop between the tractor and the connected implements, always turn off the engine.
- When it is necessary to operate the lift, keep distance from people and the affected area.

Most accidents are caused by carelessness and moving tractors.

2.1.13 Fire prevention

Remove grass and debris from the engine compartment and the muffler area, before and after using the

tractor. Always close the fuel valve, if present, when storing or transporting the tractor

Don't keep the tractor parked near open flames or ignition sources, such as a water heater or boiler.

Check frequently that the fuel pipes, tank, cap, and fittings are free of cracks or leaks. Replace damaged components if necessary.

Never store the tractor with fuel in the tank inside a building where the vapors can reach an open flame or spark.

Let the engine cool down before storing the tractor in any closed environment.

2.1.14 Safety measures for tyres use and maintenance

Explosive separation of parts of the tire and rim can cause serious injury or death. Never attempt to

fit a tire with equipment and experience that is inadequate for the job. Always maintain the correct pressure in the tire.

Do not inflate your tires at a higher pressure than the recommended pressure.

Do not keep the pressures lower than the required values, so as not to overheat the tires too much, this could cause:

- tire breakages;
- de-beading.
- Internal injuries;
- uneven wear and short lifecycle.

Do not weld or heat a mounted wheel and tire assembly. The heat can cause an increase in air pressure and therefore the tire to explode. Welding can structurally weaken or deform the wheel.

Check tire pressure by keeping your body out of the possible trajectory of the valve mechanism or cap.

When inflating tires, use a mandrel and an extension tube long enough to allow

operator to stand to the side and NOT in front of or on top of the pneumatic assembly.

Check your tires regularly for low pressure, cuts, bubbles, damaged rims, or missing or loose nuts and bolts.

Do not exceed the speeds reported on the tires, in addition to excessive overheating, it causes premature tire wear.

Do not ride your tires on hydrocarbons (oil, diesel, grease, etc.)

After installing the tires, check the tightening of the nuts after 100 km or 3 hours of driving. Then check the tightening periodically.

Have the tires checked by a specialist when one or more problems are found.

Tires mounted on tractors that remain parked for a long time tend to age more quickly than tires used more frequently. In this case, it is advisable to lift the tractor above the ground and protect the tires from direct sunlight.



The replacement of tires must be carried out by competent personnel in possession of the necessary equipment and technical knowledge. The replacement of tires carried out by incompetent personnel can cause serious physical injuries to people, injuries to the tire and deformations of the rim itself.

2.1.15 Wheel bolting control

If the wheel bolts are not properly tightened, a serious accident could occur with serious injuries. Check the tightness of the wheel bolts frequently during the first 100 hours of operation.

The wheel bolts must be tightened to the specified torque with the correct procedure each time it is unscrewed.

2.1.16 Maintenance and storage

Keep nuts, bolts, and screws securely fastened to ensure that the tractor is operating safely.

Never store the tractor with fuel in the tank in an environment where vapors can reach open flames or sparks.

Allow the engine to cool down before storing the tractor in a closed environment.

To reduce the danger of fire, keep the engine, silencer, battery compartment, and fuel storage area clean of grass, leaves, or excess grease.

Safely replace worn or damaged parts.

If the fuel tank needs to be emptied, perform the operation outdoors.

When the tractor needs to be parked, put in the garage, or left unattended, lower the implement if a safety mechanical lock is not used.

Do not leave the tractor unattended while it is running.

2.1.17 Restarting after storage

Before using the tractor for the first time, or after a long period of inactivity, you must do the following:

- verify that the tractor is not damaged;
- verify that the mechanical parts are in good condition and not rusty;
- carefully grease all moving parts;
- check that there are no oil leaks;
- check the engine oil level;
- check the transmission oil level;
- verify that all protectors are correctly positioned.

2.1.18 Safety measures for parking


Before getting out of the tractor, follow the instructions below:

- stop the tractor on a horizontal surface, not on a slope;
- unplug the power outlet and stop the implements;
- lower the implements to the ground;
- block the parking brake;
- turn off the engine;
- remove the key;
- wait for the engine and all moving parts to stop before leaving the operator's seat;
- Close the fuel stop valve if the tractor has one.

2.1.19 Working tightness

Always wear clothing and equipment appropriate to working conditions. You must have:

- safety glasses, or safety glasses with side protection;
- a helmet when working with the tractor;
- protective gloves (neoprene for chemical products, leather for heavy work);
- protective headphones or ear plugs;
- respirator or filter mask;
- waterproof and tight clothing;
- reflective clothing;
- safety shoes.



2.1.20 Safety measures for maintenance

The only authorized interventions are those listed in the MAINTENANCE chapter. Any other intervention must be carried out in workshops authorized by the manufacturer. Refer to the retailer for authorized centers.

Ordinary tractor maintenance can only be carried out by qualified and experienced personnel. Understand the procedure well before carrying out service work.

Before servicing the vehicle, read carefully and follow the instructions below:

- never operate the tractor in a closed environment where dangerous accumulations of carbon monoxide may
- keep the nuts and bolts perfectly tight, to be sure that the tractorry is operating safely;
- prevent debris of any kind from accumulating on the tractor. Collect the spilled oil or fuel, remove any debris soaked in fuel. Let the tractor cool down before storage;
- Never make adjustments or repairs with the engine running. Wait until all movements on the tractor have stopped before making adjustments, cleaning or repairs;
- Check the correct functioning of the brakes frequently. Have the necessary adjustment and maintenance operations carried out by authorized workshops;
- replace safety instruction labels, if damaged;
- keep any body wall and clothing away from moving parts and control levers to prevent them from getting entangled;
- before carrying out any cleaning or maintenance operation on the tractor, always lower any connected implements to the ground:
- disconnect all electrical supplies and turn off the engine;
- Lock the parking brake and remove the key. Allow the tractor to cool down;

- use secure supports for the elements of the tractor that need to be lifted for maintenance;
- use stands or lock service latches to support components if necessary;
- Disconnect the battery before performing repairs. Disconnect the negative pole first, then the positive one. Install the positive pole first, then the negative one;
- before any maintenance on the tractor or implements, carefully release the pressure from all components with energy storage, for example hydraulic components or springs;
- Relieve the hydraulic pressure by lowering the cutting implement to the ground or at the mechanical stop, and move the hydraulic control levers back and forth;
- keep all parts in good condition and properly installed. Repair any damage immediately. Replace broken or worn parts;
- charge the batteries in an open, well-ventilated area, away from sparks. Disconnect the battery charger before plug/unplug it Wear protective clothing and use insulated utensils.

2.1.21 Beware of high-pressure fluids

Hydraulic hoses can fail due to physical damage, aging, and exposure. Check the pipes regularly. For safety, follow the instructions below:

- hydraulic connections may become loose due to physical damage and vibration. Check connections regularly. Tighten loose connections;
- fluid leaks under pressure can penetrate the skin, causing serious injury;
- Relieve pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure;
- Use a piece of cardboard to search for leaks. Protect hands and body from high-pressure fluids;
- if an accident occurs, seek medical attention immediately;
- any fluid injected into the skin must be surgically removed within a few hours to prevent gangrene Physicians who are not familiar with this type of injury should refer to a reputable medical source.

2.1.22 Safety measures for handling fuel

The fuel is extremely flammable and its vapors are explosive. To avoid personal injury or damage to property, use extreme caution when handling fuel and follow the listed safety precautions:

- NEVER approach the flammable source with cigarettes, cigars, pipes, and other trigger sources.
- use only portable, non-metallic containers for fuel. If a funnel is used, make sure it is plastic and does not contain nets or filters;
- NEVER remove the tank cap or add fuel when the engine is running. Let the engine cool down before refueling;
- NEVER add fuel to or drain it from the tractor in a closed environment Take the tractor outdoors and provide adequate ventilation;
- Collect spilled fuel immediately. If fuel is spilled on clothing, change it immediately. If fuel spills near the tractor, do not try to start the engine, but move the tractor from the spill area. Avoid creating ignition sources until fuel vapors have dissipated:
- never store the tractor or fuel container where there are open flames, sparks, or pilot flames, such as on a water heater or other equipment;
- Prevent fires and explosions caused by static electricity discharges. The discharge of static electricity can ignite vapors in a fuel container without grounding;
- Never fill tanks inside a vehicle or on a plastic-lined trailer or trailer platform. Always place the tank on the ground, away from the vehicle, before refueling;
- Consumables are harmful to health. Keep them away from children.

 If you swallow the liquid, contact a doctor immediately, otherwise you could run into serious health risks.
- All consumables and parts in contact with them should be disposed of in accordance with what is described in the relevant legal regulations. Licensed workshops are equipped for proper disposal and to ensure environmental sustainability
- The use of special additives may compromise the right to warranty. Do not use lubricant additives.

2.1.23 Things to do before refueling

In order to be able to safely refuel the vehicle, it is necessary to follow the instructions below:

- remove the implement that uses fuel from the tractor and refuel it on the ground. If this is not possible, fill such implement with a portable container, instead of with the fuel pump;
- keep the pump nozzle in continuous contact with the edge of the tank or with the opening of the container until the filling is complete. Do not use a nozzle locking-opening device;
- Do not overfill the tank. Put the cap back on the tank and tighten it thoroughly;
- after use, put back and tighten all fuel container caps;
- for gasoline engines, do not use gasoline with methanol. Methanol is harmful to health and the environment.

2.1.24 Electrical equipment safety standards

The electrical equipment has been designed and built according to the provisions of current regulations on the subject. The list contains the warnings necessary for the proper functioning of the electrical equipment:

- Do not use boosters or quick starters to start the engine.
- Do not disconnect the power supply while the engine is running.



Before disconnecting the power supply, turn off the motor and wait at least 2 minutes, so that the electronic control unit can carry out the "after-run" procedure.



ALWAYS disassemble the electronic control unit and protect all electrically connected devices, located near the negative pole (mass), before performing arc welding on the frame on which the motor is installed.

2.1.25 Battery safety regulations

In order to service the vehicle batteries, the following instructions must be followed:

- always wear eye protection equipment;
- Do not produce sparks or use live flames near the battery.
- Ventilate the room while charging or using the battery in tight spaces.
- The negative (-) pole must be disconnected first and reconnected last.
- Do not weld, grind metal, or smoke near a battery.
- To start the engine with auxiliary batteries or jumpers, follow the procedure set out in the instruction manual.
- Do not short circuit the clamps. For battery storage and handling, follow the manufacturer's instructions. Battery terminals, poles, and related accessories contain lead or lead compounds. Wash your hands after maintenance work.
- Keep batteries out of reach of children and other unauthorized persons.
- Battery acid can cause burns. Batteries contain sulfuric acid. Avoid contact with skin, eyes or clothing.
- Antidotes (in case of external contact):
 - in case of eye contact:
 - Rinse with water for at least 15 minutes;
 - seek immediate medical attention.
 - If swallowed:
 - drink plenty of water or milk;
 - do not induce vomiting;
 - contact the medical staff immediately.



When you need to start the tractor with an external booster or battery, do not remove the original battery.

Remove the battery only when the engine is off, otherwise the engine control unit will be damaged.

2.1.26 PTO safety regulations (P.D.F.)

Equipment operated by the PTO can cause serious or fatal injuries. Before intervening on or near the PTO Shaft, or before performing maintenance or cleaning operations on the equipment operated by the PTO, disconnect the PTO itself, stop the motor and remove the key.


Always follow the following safety steps:

- NEVER remove the PTO shaft carter The removal of the carter could cause serious or fatal accidents for the operator or people near the work area;
- Do not wear loose clothing while using equipment activated by the PTO Failure to comply with these indications could result in serious or fatal accidents;
- When using the Power Take-Off PTO, and in particular when moving from one speed to another, always make sure that the implement working rpm corresponds to the rpm provided for the selected speed.
- Before using the PTO, make sure that there are no people or objects in the operating area.

2.1.27 seat belts

Seatbelt inspection and maintenance:

- use seat belts to minimize the risk of accidents such as a rollover;
- check that the safety belts are not damaged;
- keep objects with sharp edges that could damage it and compromise its safety at a distance from the belts;
- periodically check that the fixing bolts are properly tightened.



2.1.28 Safety regulations - Lifting and suspended loads

Any lifted loads may fall off. Mounted implements and parts can be accidentally lowered, crushing or killing people who may be present.

To avoid physical damage, sometimes even fatal, due to crushing, follow the instructions below:

- identify the entire area of movement of the tractor and equipment and do not allow anyone to access it;
- do not stand under hydraulically raised loads. Lower the lifted loads to the ground before going under them;
- Do not keep the implements off the ground while the tractor is parked or during maintenance operations. If it is necessary to keep the hydraulic cylinders in a raised position, for maintenance or the need for access, lock them mechanically or support them;
- do not lift loads higher than necessary. Lower transport loads. Remember to keep a safe distance from the ground or other obstacles.



In the event of incorrect use of the front loader or other equipment that could cause danger to the occupants in the cabin, the manufacturer is not responsible.

In versions with front loader:

- use front loaders only if the driver is adequately protected with safety devices (FOPS) or if restraint implements mounted on the charger are used;
- buckets, forks, or other loader equipment or other lifting, handling, or digging equipment and the related load modify the tractor's center of gravity. This may cause the tractor to tip over on slopes or rough terrain;
- suspended loads may fall from the loader bucket or lifting equipment and crush the operator. Use extreme care when lifting a load. Use the correct lifting equipment.

2.1.29 Rollover protection structure (ROPS)

The tractor is equipped with a protective arc or a cabin. The structure protects the operator in the event of a rollover. For greater security, follow the instructions below.

To avoid serious personal injury or death, follow the instructions below:

- avoid using the tractor on slopes or in conditions that compromise its safety and stability limits. Using the tractor beyond these limits may cause rollover. Observe the recommendations provided;
- be especially careful when driving on steep slopes with the tractor loaded;
- it is forbidden to connect devices to the protective structure for the purpose of towing;
- do not modify the safety arc through welding, drilling, bending, grinding, etc. These changes cause the loss of the approval characteristics;
- always keep your seat belts fastened when using the tractor. The structure offers adequate protection only when the driver is properly secured to the seat;
- if the structure has deformations and wear due to accidents or overturns, it is essential to restore its efficiency before reusing the tractor in the field. For repairs or replacement of the structure, rely on qualified personnel;
- the protective arc must always be raised and locked. Always use seat belts;
- Lower the safety arc only if strictly necessary. In this situation, use caution. When the work is finished, raise the arc again and lock it before reusing the tractor:
- do not use the tractor with the protective arc to carry out treatments with plant protection products;
- Do not use the tractor for towing or extraction work whose magnitude of the tractive effort is unknown, as in the case of the extraction of logs. The tractor could tip backwards if the stump doesn't give way.

2.1.30 Operator Protection Structure (FOPS)



danger

The FOPS approved cab is not installed on these tractor models.

Jobs that require a certain level of protection need additional protective measures.

The purpose of the cab is to avoid or limit risks for the operator due to objects falling from above during normal use. An uncertified cabin (FOPS) offers an insufficient degree of protection against falling rocks, bricks, or concrete blocks.

Use a certified (FOPS) facility when working with front loaders or for forestry applications.

2.1.31 Operator Protection Structure (OPS)



danger

On the tractor equipped with this type of cab, there are no fixing points for protective structures designed to protect operators (OPS), as defined by the ISO 8084:2003 standard. The tractor, not having a protective structure capable of effectively protecting the operator from the dangers mentioned above, is not suitable for use in forestry.

Jobs that require a certain level of protection, need additional protective measures.

The operator protection structure (OPS) is mounted on the tractor to limit the chances of injury to the operator caused by the penetration of objects into the driver's seat area.

The cabin air filtration and ventilation system does not allow complete protection against the ingress of dust or gases during treatments with pesticides. Take the following precautions to increase the level of protection:

- always use Personal Protective Equipment (PPE) and protective clothing;
- keep doors, windows and roof closed during spraying work;
- keep the inside of the cabin clean;
- do not enter the cabin with contaminated shoes and/or clothing;
- store all Personal Protective Equipment (PPE) outside the cabin;
- bring the wiring into the cabin with the sprayer's remote control joystick;
- use only original replacement filters and make sure that the filter is properly installed;
- check the condition of the sealing material and filters by replacing them if damaged.

2.1.32 Front loader (if available)

Objects can fall from front loader causing serious, sometimes even fatal, injuries. To avoid accidents due to falling objects, follow the instructions below:

- never install a front loader for unprotected tractors (FOPS);
- adopt restraint accessories installed on the front loader;
- do not lift the front loader to a height that would cause objects to fall or overturn on the operator;
- Do not allow people to get close to the manouvring area of the tractor with front loader. Do not allow people to be near or under the raised bucket of a front loader;
- never use the front loader to lift people;
- Make sure that there are no suspended electrical cables in the area where the loader is used. Otherwise, keep a sufficient distance to be able to operate safely;
- Use the front loader to move hay bales, pallets, etc. only if equipped with the necessary terminal;
- In road transfers, place the loader in the transport position and lock it. Respect the maximum front overhang. If the overall size of the tractor with the loader exceeds 3.5 m, it will be necessary to ensure road safety with additional measures. It is forbidden to transport equipment and material with a front loader on public roads;
- danger of accidentally lowering the front loader. For this reason, block the valves after finishing the work. Lower the front loader to the ground before leaving the tractor;
- the assembly and disassembly of the front loader for safety reasons must be carried out only by one person, the driver himself;
- disassemble the front loader only with a mounted tool (shovel, fork) on a solid, flat area;
- when the front loader is mounted, connect all the hydraulic pipes, including the hydraulic return;
- carry out maintenance (greasing) job with a loader mounted on the tractor only in a lowered position;
- risk of injury due to lift height, passage under underpasses, bridges, etc..
- the speed of movement must always be adapted to the driving conditions;
- it is strictly forbidden to carry people. Store and lock the front loader so that external people, such as children, cannot overturn it.

2.1.33 Safety regulations Air conditioning system

The air conditioning system is under high pressure. Do not disconnect pipes. The release of high pressure can cause serious injury.

The air conditioning system contains gases that are harmful to the environment if released into the atmosphere. Do not attempt to service or repair the system by yourself.

Maintain the air conditioning system serviced, repaired or recharged only by specialized personnel.

2.1.34 Personal protective equipment

Personal protective equipment (PPE) is equipment worn by the worker to protect himself against one or more risks that arise during the working, maintenance and repairing phases, which could threaten his safety or health during work.

Always use PPE during working and maintenance, even if the risk of accidents is minimized, to prevent those risks that cannot be eliminated (residual risks).

Use the appropriate PPE for each specific procedure. For personal protective equipment that may be necessary, safety shoes, protective glasses and/or a face protector, helmet, work gloves, respirators, and hearing protection headphones are included.



2.1.35 Safety regulations - 'Do not use' sign

Before starting tractor maintenance, place a "Do Not Use" warning sign on a visible area of the tractor, and remove the key from the starter switch.

2.1.36 Hazardous chemicals

Hazardous chemicals can cause serious injuries. Fluids, lubricants, paints, adhesives, coolants, etc. required for the operation of the tractor can be harmful.

Material Safety Data Sheets (MSDS) provide information on the chemicals contained in each specific product, how to use them safely, and what to do if that product is accidentally spilled. MSDS cards are available from the dealer.

Before carrying out maintenance job, carefully read the information sheets of the individual products on the safety of the materials used on the tractor.

The information on the fact sheets allows you to carry out operations on the tractor safely.

Follow the information provided by the manufacturer on the product containers and the information contained in this manual.

The disposal of fluids, filters and containers must be done with respect for the environment, in compliance with the regulations and laws in force on environmental protection. For correct disposal information, contact your local recycling center or dealer.

Fluids and filters must be stored according to the local regulations in force in your country. For the storage of chemicals or petrochemicals, use only appropriate containers.

2.1.37 Safety information for the application of plant protection products, (PPP)

The cab of this tractor corresponds to class 1 as specified by the EN 15695-1:2009 standard and does not provide protection against dangerous substances.

The tractor equipped with this cab cannot be used in conditions that require protection against dangerous substances. The cab only partially protects the operator against chemicals and dust.

To carry out treatments with plant protection products, follow the following instructions:

- during treatments, wear specific devices for protection against chemical vapors (PPE) even if you are inside the cabin:
- read the instructions carefully and follow the information provided by the manufacturer of the dangerous substance contained on the labels on the product containers;
- carefully read the operating instructions provided by the sprayer manufacturer;
- although the ventilation and air filtration system is unable to provide a full level of protection, the adoption of appropriate protective measures will help to increase it;
- sprayers can be used both towed and mounted on the tractor, but it is mandatory to use Personal Protective Equipment (PPE), in order to reduce the risks of intoxication;
- regardless of the type of chemical used, it is mandatory to use Personal Protective Equipment (PPE).

2.1.38 Get in and out of the tractor

Get on and off the tractor only on the side indicated by the manufacturer, holding on to the appropriate handles, steps or ladders.

Don't jump out of the tractor, especially if it's moving.

The steps, the ladders and the platform must be kept clean and free of debris. Don't stand

on steps or ladders with the tractor moving.

When getting on and off the tractor, don't use the steering wheel or other controls as a foothold.

2.1.39 Jobs in forestry

The tractor is not designed for use in forestry. Contact a GOLDONI dealer to verify the possibility of equipping the tractor itself with a structure suitable for the purpose. Protection against heavy falling objects is ensured only by adopting specific safety measures.

2.1.40 Vibrations level

Vibrations due to improper maintenance can cause injury to the operator. Check that the tractor is in good condition and that its maintenance complies with the instructions in this manual to avoid damage to health.

The vibrations to which the operator's body is subjected depend on various factors:

- land or surface on which you are proceeding;
- proper maintenance:
- Correct tire pressure:
- type of seat and condition of wear of the seat;
- tractor speed;
- malfunctioning steering and braking system.

The vibrations transmitted from the tractor to the operator are a source of disturbance for the operator.

Prolonged exposure to vibration could cause health problems and safety concerns.

Soot model/turns	Vibration level in m/s² detected (test mass) - aws		
Seat model/type Light-weight operator Heavy-weight operator		Heavy-weight operator	
GT62-M91	0,92	0,73	
SC84-M91	0,92	0,73	
SC84-M97	1,18	0,94	



Note

In compliance with EU regulation 2018/830 (Annex XIV), the following table shows the vibration levels measured on the seats in terms of aws*.

aws* = rms (average square value) corrected for the weighted acceleration of the vibration measured on the seat during a bench test.



The level of vibration that the tractor transmits to the user's body depends on various parameters, some relating to the tractor, others relating to the terrain in which it operates, others to the type of working application and the tractor possibly connected and finally others specifically related to the driver.

For more information on vibrations transmitted inside the body (WBV) by agricultural tractors, please refer to specific publications on the subject and to local regulations concerning related risks; to correctly evaluate statistical values based on the daily use of the tractor, use a specific measuring device, such as a triaxial accelerometer for the seat.

2.1.41 Safety information for accidental contact with electric power lines

The tractor, during the opening and closing of foldable implements, during use and through antennas, may come into contact with overhead power lines.

To avoid deadly electrical shocks or fires derived from currents that are discharged onto the tractor:

- when opening/closing implements, keep a sufficient distance from high-voltage power lines;
- do not open or close implements near power poles or power lines;
- with the implement open, keep a safe distance from the high voltage line, so that you can perform maneuvers:
- do not abandon the tractor, or leave it under overhead power lines, to avoid possible dangers of electric shock due to electric arcs:
- In the presence of overhead power lines, electric arcs may be accidentally produced. These arcs

These electric arcs produce, outside the tractor, very high electrical voltages and large voltage differences are created on the surrounding area.

To avoid often deadly tensions:

- do not walk in long steps, do not lie on the ground or touch the ground with your hands;
- Do not touch metal parts;
- do not make any contact on the ground;
- Warn the people present: DO NOT approach the tractor Electrical tensions on the ground can cause strong electrical discharges;
- wait for the intervention of specialized rescue personnel. The overhead power line must be turned off.

If you are forced to leave the cabin despite the electric arc due to the direct danger of death due to a fire:

- abandon the tractor by jumping as far as possible looking for a safe position;
- do not come into contact with the external parts of the tractor and move away from the danger zone.

2.1.42 Weathering safety information

In the presence of storms and weather events such as, for example, lightning that may cause hazards to the safety of the operator and the tractor, it is necessary to take cover immediately.

2.1.43 Tractor electrical system

Some parts of the tractor may be under tension.

Avoid contact so as not to be hit by possible electrical shocks. To avoid damage, sometimes even fatal, contact specialized personnel.


2.1.44 Machine stability

By connecting implements front and rear to the tractor, the weight distribution on the axles is varied.

Add or remove ballast from the tractor until a correct weight distribution is established depending on the implement in use.

Never exceed the maximum weights allowed on axles and tires.

Correct static weight distribution ensures maximum tractor efficiency, maximum productivity and extends the life of the tractors's components.





The percentages shown in the figure for 4WD models are indicative. They refer to the tractor complete with ballast and full fuel tank.



Warning

When attaching implements at the rear, it is recommended that a minimum weight of 20% be applied to the front

2.1.45 Ecological standards

Safeguarding the environment is very important. Improper disposal of fluids or waste could alter the ecological system.

All fluids (lubricants, fuels, refrigerants, etc.) must not be dispersed in the environment. Their disposal must be carried out according to the regulations in force in your country.

To dispose of properly, contact the competent authorities or the staff of your dealer.

When carrying out maintenance job, requiring the discharge of lubricants, always place a collection container under the affected component.

The containers used for draining the various fluids must be recognizable. To recover such substances, never use containers derived from food products, which may mislead.

2.1.46 Disposal and scrapping

The tractor is composed of parts that are subject to disposal rules and regulations, so when the tractor is discarded and no longer used, it must be scrapped by authorized bodies.

Do not disperse the tractor or its components in the environment.



Warning

In the event of scrapping, the engine must be disposed of in appropriate landfills, in accordance with current legislation.

Before proceeding with the scrapping, it is necessary to separate the plastic or rubber parts from the rest of the components.

The parts consisting solely of plastic material, aluminum and steel may be recycled if collected by the appropriate centers.

For the collection of waste oils and filters, it is mandatory to contact the "Required Used Oil Consortium".

Used oil must be properly recovered and must not be dispersed in the environment, since, according to current legal regulations, it is classified as hazardous waste and as such must be transferred to the appropriate collection



3: Technical features

Index

3.1	Techn	ical Data	. 3-2
	3.1.1	Engine	. 3-2
	3.1.2	Transmission	. 3-3
	3.1.3	Brakes	. 3-3
	3.1.4	Steering	. 3-3
	3.1.5	Rear PTO	. 3-3
	3.1.6	Power take-off front	. 3-4
	3.1.7	Rear lift	. 3-4
	3.1.8	Front linkage	. 3-4
	3.1.9	Hydraulic system	. 3-4
	3.1.10	Electrical system	. 3-5
	3.1.11	Driver's station	. 3-5
		Maximum operating inclination of the vehicle	
	3.1.13	Cabin	. 3-6
	3.1.14	Towing devices	. 3-6
	3.1.15	Towable masses	. 3-7
	3.1.16	Ballasts	. 3-7
3.2	Weigh	nts and dimensions	. 3-8
3.3	Lubrica	ants, fuels and refrigerants	3-10
	3.3.1	Fuel	3-11
	3.3.2	Engine oil	3-11
3.4	Table o	of speeds	3-12
	3.4.1	Q80	3-12
	3.4.2	S65/S80	
3.5	Level o	of noise	3-14
3.6	TYRES.		3-14
	3.6.1	Available tires	3-14
	3.6.2	Eligible Masses Summary Table	

Technical Data

3.1.1 Engine

Producer		DOOSAN
Model		D24
Power supply		Electronic direct injection diesel
Emissions type		Stage V
Number of cylinders		4
Displacement	cm³	2400
Aspiration		Turbocharger + Intercooler
Rated speed	rpm	2300
Dated Dawer	kW / CV	45 / 61
Rated Power	@ rpm	@ 2300
Marianana tanana	N⋅m	245,0
Maximum torque	@ rpm	@ 1100
Torque backup	%	31
Cooling		To liquid
Specific fuel consumption (max torque speed)	g/kWh	220
Tank capacity	I	70
Engine bonnet		RTM (High Strength Fiberglass)

3.1.1.1 Q80 / S80

Tractor		Q80 / S80	
Producer		DOOSAN	
Model		D24	
Power supply		Electronic direct injection diesel	
Emissions type		Stage V	
Number of cylinders		4	
Displacement	cm ³	2400	
Aspiration		Turbocharger + Intercooler	
Rated speed	rpm	2300	
Reted Dower	kW / CV	55-2	
Rated Power	@ rpm	@ 2300	
Maximum targua	N⋅m	310,0	
Maximum torque	@ rpm	@ 1400	
Torque backup	%	35	
Cooling		To liquid	
Specific fuel consumption (max torque speed)	g/kWh	220	
Tank capacity	1	70	
Engine bonnet		RTM (High Strength Fiberglass)	

3.1.2 Transmission

		Q80	S65/S80
Transmission type		Mechanical traction, four-wheel drive	
Gearbox type		24 synchro	onized
Shift command		Mechanical w	vith side levers
Clutch		Dry single disc, 11" dia	meter (280 mm)
Clutch control		Mechanic	al foot pedal
Shuttle type		Mechanical,	synchronized
Reverse shuttle		The lever	
Rear differential lock		Electro- hydraulic	
Front axle		4WD, engageableunder load	
Front wheel drive clutch control		Electro- hydraulic	
4WD clutch		Multidisc in oil bath	
Front differential lock		NO-SPIN (automatic)	
Front axle oscillation		9° 11°	
Minimum speed	km/h	0,46	0,49
Maximum speed (approved)	km/h	40	

3.1.3 Brakes

Rear braking type	With multiple discs in oil bath, mechanical control	
Front braking type	IST (simultaneous dual drive engagement under braking)	
Emergency brake and parking	Agent on the rear wheels, with independent mechanical control	
Hydraulic trailer braking	Hydraulic control with pulse on main circuit	
Mechanical lever support for trailer brake	CUNA type	

3.1.4 Steering

	Q80 S65/S80		
Steering type	Hydrostatic with load sensing valve		
Steering angle	57°	55°	

3.1.5 Rear PTO

Туре		Single shaft, independent and synchronized
independent speeds	rpm	540-540E
Other speeds independent of forward speed		540-1000
Ground speed synchronized		Yes
Direction of rotation (looking at the PTO)		Clockwise
Profile		1-3/8" 6-slot
Clutch		Independent, mechanical with dry disc
Clutch control		Lever-operated mechanical

3.1.6 Power take-off front

TECHNICAL

Туре		Independent singleshaft
independent speeds	rpm	1000
Other speeds independent of forward speed		-
Direction of rotation (looking at the PTO)		Counterclockwise
Profile		1-3/8" 6-slot
Clutch		Electromagnetic
Clutch control		Electronic

3.1.7 Rear lift

		Q80	S65/S80	
Туре		Position- and draft of	Position- and draft controlled hydraulic	
lifting capacity at ball ends	kg	28	2800	
Three-point hitch category		Category 1 and 2 with quick coupling	Category 1 and 2 with fixed attachment	
			Category 1 and 2 with quick coupling	
Mechanical Upper link		Category 1 and 2 with quick coupling	Category 1 and 2	
HydraulicUpper link		Category 1 and 2 with quick coupling		
Lower arms type		Telescopic with quick couplings		
Right tie rod type		Hydraulic with quick coupler	Mechanic Hydraulic with quick coupler	

3.1.8 Front linkage

Туре		Raise and lower
lifting capacity at ball ends	kg	1000
Three-point hitch category		Category 1

3.1.9 Hydraulic system

	Q80	S65/S80	
Туре	Open center		
Pump flow rate	38 + 50 l/min with double pump 22 + 50 l/min with double pum		
Rear hydraulic distributors	3 in one-piece (1 floating, 1 double-acting, 1 with kick-off)		
Optional rear hydraulic distributors	1 mechanical (with diverter)		
Front hydraulic distributors	2 mechanical (1 double-acting, 1 floating)		
Oil-free return	Quick 1/2 NPTF		

3.1.10 Electrical system

Battery		12V 850A 95Ah
Safety		remote battery switch
		Digital display ECO-HE 2
Dashboard		Cruise Control RPM
		G FARM Ready (digital agriculture predisposition)
3-PIN SOCKET	Volt	12
7-pin socket	Volt	12
USB socket		Cell phone charging
Rear work light		Adjustable
December		LED (rollbar version)
Beacon		Orange (cab version)

3.1.11 Driver's station

	Q80	S65/S80	
Platform	Integral s	uspended	
Platform support	Silicone silent-blocks w	ith variable deformation	
Front fenders	Independer	nt, swiveling	
Rear fender protection	Plastic compo	ound profile	
Safety frame	Fully foldable roll	bar	
Standard cabin	Goldoni Ov	erview GL9	
Low profile cabin	Goldoni LowProfile SG1	-	
Left and right rearview mirror	Adjustable a	and foldable	
Headlight set	LE	ED	
0.5.4	On elastic suspension, with seat belts and OPS		
Seat	On pneumatic suspension, with seat belts and OPS		
Seat adjustments	Horizonta	al, vertical	
Toolbox	Ye	es	
Operator's Manual	Yes		

3.1.12 Maximum operating inclination of the vehicle

Forward	Degrees	25°
Reverse	Degrees	25°
Left	Degrees	25°
Right	Degrees	25°

3.1.13 Cabin

TECHNICAL

	Standard profile	Low Profile	
ROPS approval	Type GL9	Type SG1/1	
Side doors	With handle, gas spring, key lock	With handle, gas spring, key lock	
Dustproof cabin air filter	In paper	In paper	
Filter air Cabin anti treatments	Active carbon	-	
Front glass	Openable	Fixed athermic	
Rear Glass	Openable	Openable	
Front windshield wiper	1 speed	1 speed	
Rear windshield wiper	1 speed	1 speed	
Front windshield washer	0.5 liters	0.5 liters	
Mirrors rear view mirrors right/left	adjustable and closable	adjustable and closable	
Front sun shade	Height adjustable	-	
Arrangement Beacon	In-cab switch and external bayonet coupling	In-cab switch and external bayonet coupling	
Ventilation and heating system	Electroventilated	Electroventilated	
Air conditioning system	Electroventilated condenser on cabin roof	Electroventilated condenser on cabin roof	
Front work light	2 LED	-	
Rear work light	2 LED	2 LED	
Radio	Radio with removable bluetooth panel	Radio with removable bluetooth panel	

3.1.14 Towing devices

	Q80	S65/S80		
Rear tow bar	Category C/EEC adjustable in 7 heights	Category CEE/CEE-X/CEE-Y adjustable		
SLIDER rear tow bar	Category EEC-X/EEC-Y sliding t	ype adjustable in height		
Front tow bar	Fixed			
Towbar	Oscillating category CEE/CEE-X			

Allowable vertical load

Fixed	S65/80 Roll- bar	Q80 Roll-bar	S65/80 A - Cabin GL9	Q80 A - Cabin GL9	Q80 B - Cabin SG1/1
CBM GTX001	1280	1250	1200	1160	1160
CBM GTF30028D	1280	1250	1200	1160	1160
CBM GTB30031D	500	500	500	500	500
CBM X007BT/xx	0	0	0	0	0
CBM Y277F/xx	1280	1250	1200	1160	1160

SLIDER	S65/80 Roll- bar	Q80 Roll-bar	S65/80 A - Cabin GL9	Q80 A - Cabin GL9	Q80 B - Cabin SG1/1
CBM X 314 SL-E/xx	1280	1250	1200	1160	1160
CBM GTF30 023D	1280	1250	1200	1160	1160
Y244-389SLD	1280	1250	1200	1160	1160

3.1.15 Towable masses

	Q80	S65/S80
Not braked	2150 kg	2000 kg
Inertial braking	8000 kg	8000 kg
Hydraulic braking (ITALY)	14000 kg	14000 kg
Hydraulic trailer braking (ITALY)	16000 kg	16000 kg

Î

Warning

Consult the road circulation documents for data on maximum vertical loads and maximum towable masses.

Take into account the load capacity of the tires. Do not exceed the mass allowed on the tires. Do not exceed the permissible mass on the rear axle of the tractor. Comply with local regulations. The values shown in the table may be limited by the road circulation regulations of each country.

3.1.16 Ballasts

Front	204 kg in 6 cases of 34 kg		
Rear	-		
Water in the tire	With air/water valve		

Weights and dimensions




Fig. 3.1

Model		Q80	S65/S80		
Α	Length without ballasts	3592 mm	3413 mm		
F	Wheelbase	1890 mm	1890 mm		
	Distance between front axle and	496 (Version with ballasts)			
	trailer hitch	680 (Front lift	version)		
	Distance between rear axle Rear lift	1052	930		
В	Width	at	1122 mm (min)		
Ь	Width	front wheels1122 mm (min)1498 mm (max)	1375 mm (max)		
С	Width	at	1041 mm (min)		
C	Widti	rear wheels1041 mm (min)1458 mm (max)	1458 mm (max)		
D	Width at the fenders	1344 mm (min)	1360 mm (min)		
D	width at the lenders	1876 mm (max)	1818 mm (max)		
G Grou	Ground clearance	169 mm (min)	215 mm (min)		
G	Ground clearance	214 mm (max)	267 mm (max)		
	Cab version height GL9	2096 mm (min)	2135 mm (min)		
		2266 mm (max)	2305 mm (max)		
E	Cob version height SC1/1	1844 mm (min)			
_	Cab version height SG1/1	1919 mm (max)			
	ROPS frame version height	2167 mm (min)	2212 mm (min)		
	KOFS frame version neight	2410 mm (max)	2245 mm (max)		
	Poppet height	1054 mm (min)	1106 mm (min)		
	Bonnet height	1102 mm (max)	1143 mm (max)		
	Steering wheel height	1207 mm (min)	1256 mm (min)		
	Steering wheel height	1254 mm (max)	1350 mm (max)		
	Seat height	852 mm (min)	1125 mm (min)		
	Seat neight	1186 mm (max)	1134 mm (max)		
	Height to roor fonder	1076 mm (min)	1122 mm (min)		
	Height to rear fender	1121 mm (max)	1175 mm (max)		
	Minimum turning radius	3,95 m	3,85 m		

Vehicle empty masses in running order

Model		Tara	Front	Rear	
005/00 D.III.	kg	MIN	2145	875	1270
S65/80 Roll-bar version		MAX	2315	1015	1300
Q80 Roll-bar version	kg	MIN	2395	1095	1300
Qou Roil-bai version		MAX	2565	1235	1330
S65/80 cab version GL9	kg	MIN	2330	965	1365
505/60 cab version GL9		MAX	2500	1105	1395
Q80 cab version GL9	kg	MIN	2455	1045	1410
Qou cab version GL9		MAX	2625	1185	1440
OOO ash version CO4/4	kg	MIN	2455	1045	1410
Q80 cab version SG1/1		MAX	2625	1185	1440

3.2 Lubricants, fuels and coolants

Q80 / S65 / S80 Series

Group	Lubricants, cooling an fuels d	Capacity	Туре	specs
	Engine oil	8,6 I	SAE 10W-40	ACEA E9/E7-12 - API CJ-4/SM
Engine	Fuel	70 I		DIN EN 590
	Coolant	9,8 I	ETHYLENE GLYCOL (1)	SAE J1034 ASTM D 3306 and 4985
Cabin	Washin system by g liquid	0,5	-	-
	Refrigerant (gas)	0.7 kg	R134a	-
	Olio Transmission - Rear differential	33	15W-40	API GL 4
Transmission	Transmission Oil - Rear final drive (each)	21	80W-90	API GL 5
	Front Axle Oil - Front Differential	5,6	80W-90	API GL 5
				GENERAL MOTORS DEXRON D II 6137 M
				GENERAL MOTORS DEXRON 6032-M
	Brake Oil	0,5	ATF	GENERAL MOTORS ATF TYPE A, SUFFIX A
Brakes				MASSEY FERGUSON M-1110
				ALLISON C4
				FORD M2C 138 CJ
				M.B. p. 236.7
	Final drives Lateral (each)	0,7		
Miscellaneous (greasing)	grease	-	MULTIPURPOSE E.P.	NLGI 2

^{(1) (50) -} The coolant must be composed of 3306% protective fluid for radiators based on monoethylene glycol with an OAT organic inhibition formulation, in accordance with ASTM D 1 type 50 standards and 50% of demineralized or distilled water.

^{(2) -} Check the transmission oil level and top up if necessary in a FRONT PTO Version. Refer to the section "Maintenance of the Tractor Hydraulic System," in the chapter "Service."

3.2.1 Fuel

The engine was designed to be powered with standard fuels available on European territory (according to DIN EN 590 specifications).

The use of fuels with specifications other than those indicated is prohibited.

Using fuel that is not recommended could damage the engine. Do not use dirty fuel or gasoil-water blends because this would cause serious engine problems.

Any damage caused by the use of fuels other than those recommended will not be covered by warranty.



Warning

Properly filtered fuel prevents damage to the injection system. Clean any fuel spill immediately during refueling.

Do not fill the fuel tank completely. Leave room for fuel to expand.

Do not store fuel in galvanized (i.e. zinc-coated) containers. The fuel inside a galvanized container generates a chemical reaction, producing "compounds" that quickly clog the filters or cause failure of the injection pump and/or injectors.

3.2.1.1 Fuel for low temperatures

To operate the engine at temperatures below 0°C, use suitable fuels normally distributed by oil companies and in any case corresponding to the specifications listed in the fuel compatibility table.

In conditions of cold ambient temperatures (-10°C), supplement the diesel with specific additives to avoid the formation of paraffin.

When paraffin forms in the fuel, the diesel filter clogs up, stopping the flow of fuel.

3.2.1.2 Fuel Biodiesel

In the case of BIODIESEL fuel (according to UNI EN 14214 specifications), it can be mixed, up to 5%, with fuel available on European territory (according to the DIN EN 590 standard).

3.2.2 Engine oil



Warning

The motor may be damaged if operated with the wrong oil level.

Do not exceed the MAX level as its combustion may cause an abrupt increase in rotational speed. Only use the prescribed oil to ensure adequate protection, efficiency and engine life. If you use oil of lower quality than the prescribed one, the life of the engine will be significantly compromised. The viscosity of the oil must be adequate for the ambient temperature in which the engine operates.

Prolonged skin contact with spent motor oil may cause epidermal cancer.

If contact with oil is unavoidable, wash your hands thoroughly with soap and water as soon as possible.

For the disposal of waste oil, refer to the 'Disposal and Scrapping' section, in the chapter 'General Safety Regulations'.

3.2.2.1 SAE oil classification

It identifies oils based on their viscosity, not taking into account any other quality characteristics.

The code consists of two numbers with an interposition of a 'W', where the first number determines the value in cold temperatures, while the second determines the value in conditions of high temperatures.

3.3 Table of speeds

3.3.1 Q80

Speed with tires: 280/70 18" (front) and 380/70 20" (rear)

Front radius: 410 mm		Rear radius: 525 mm			
Range Gear		Forward speed (km/h)	Speed Reverse (km/h)		
Speed in LOW mode					
	1	8.67	8.24		
Fast	2	14.28	13.57		
rasi	3	25.27	24.02		
	4	32.7	31.08		
	1	1.64	1.56		
Ma -li	2	2.70	2.57		
Medium/Slow	3	4.79	4.55		
	4	6.19	5.89		
	1	0.46**	0.44		
01	2	0.76	0.73		
Slow	3	1.35	1.28		
	4	1.75	1.66		
Speed in HIGH mode	-		-		
	1	11.19	8.24		
- .	2	18.42	13.57		
Fast	3	32.61	24.02		
	4	40*	31.08		
	1	2.12	1.56		
NA - P /OL-	2	3.49	2.57		
Medium/Slow	3	6.18	4.55		
	4	7.99	5.89		
	1	0.6	0.44		
0.1	2	0.99	0.73		
Slow	3	1.74	1.28		
	4	2.26	1.66		

3.3.2 S65/S80

Speed with tires: 260/70 16" (front) and 360/70 24" (rear)

Front radius: 360 mm Rear radius: 550 mm

Range	Gear	Forward speed (km/h)	Speed Reverse (km/h)
Speed in LOW mode	•		
	1	9.08	8.63
Foot	2	14.96	14.21
Fast	3	26.48	25.17
	4	34.26	32.56
	1	1.72	1.64
Madium/Class	2	2.83	2.69
Medium/Slow	3	5.01	4.77
	4	6.49	6.17
	1	0.49**	0.46
01	2	0.80	0.76
Slow	3	1.42	1.35
	4	1.83	1.74
Speed in HIGH mode			
	1	11.72	8.63
Fact	2	19.30	14.21
Fast	3	34.16	25.17
	4	40*	32.56
	1	2.22	1.64
Medium/Slow	2	3.65	2.69
IVIEUIUIII/SIOW	3	6.47	4.77
	4	8.37	6.17
O.	1	0.63	0.46
	2	1.03	0.76
Slow	3	1.83	1.35
	4	2.36	1.74

3.4 Level of noise

TECHNICAL



Noise level in the driver's ear measured according to Annex XIII of Delegated Regulation (EU) No. 1322/2014 of the commission, as last amended by Delegated Regulation (EU) 2018/830.

Model	Q80	S65-80
External noise level	86 db(A)	86 db(A)

3.5 TYRES

3.5.1 Available tires

The characteristic values of tires are shown below.

Q80

Front	Load index	Pressure (bar)	Rear	Load index	Pressure (bar)
260/70 R16	109 A8	2,4	340/65 R20	124 A8	2,0
280/70 R18	114 A8	2,4	360/70 R20	120 A8	1,6
320/65 R18	109 A8	1,6	420/65 R20	138 A8	1,6
260/70 R16	109 A8	2,4	320/70 R20	123 A8	2,0
280/70 R18	114 A8	2,4	380/70 R20	122 A8	1,6
280/70 R18	114 A8	2,4	320/85 R20	119 A8	1,6
280/70 R16	112 A8	2,4	340/65 R20	124 A8	2,0
260/70 R20	113 A8	2,4	320/70 R24	116 A8	2,0

S65/80

Front	Load index	Pressure (bar)	Rear	Load index	Pressure (bar)
11.0/65 R12	PR8	2,3	360/70 R20	120 A8	1,6
240/70 R16	104 A8	2,4	320/70 R24	116 A8	1,6
260/70 R16	109 A8	2,4	360/70 R24	122 A8	1,6
240/70 R16	104 A8	2,4	380/70 R20	122 A8	1,6
27/10.5 R15	PR4	2,0	41/14 R20	PR4	1,7
11.0/65 R12	PR8	2,3	320/85 R20	119 A8	1,6



If the wheel set is replaced with a different size, go to an authorized dealer to have the correct wheel parameters inserted into the vehicle control unit. This is necessary in order to be able to display the real speed of the vehicle on the display.

3.5.2 Eligible Masses Summary Table

Q80

Set	Axis	Tyre dimensions including the load capacity index and the speed category symbol	Pneumatic Radius (mm)	Tyre load rating for each of them (kg)	Maximum allowable mass of vehicle (kg)	Maximum permissible mass per axle (kg)
1	Front	280/70 R18	400	1180	3800	1800
1	Rear	380/70 R20	525	1500	3600	2800
2	Front	260/70 R20	425	1150	3800	1800
2	Rear	320/70 R24	525	1250	3600	2500
3	Front	320/65 R18	425	1030	3800	1800
3	Rear	420/65 R20	500	2360		2800
4	Front	280/70 R18	400	1180	2900	1800
4	Rear	360/70 R20	500	1400	3800	2800
5	Front	260/70 R16	370	1030	2900	1800
5	Rear	320/70 R20	475	1550	3800	2800
6	Front	280/70 R18	400	1180	2000	1800
Ь	Rear	320/85 R20	500	1360	3800	2720
7	Front	260/70 R16	360	1030	3900	1800
'	Rear	340/65 R20	450	1600	3800	2800
0	Front	280/70 R16	380	1120	3900	1800
8 Re	Rear	340/65 R20	450	1600	3800	2800

S65 / S80

Set	Axis	Tyre dimensions including the load capacity index and the speed category symbol	Pneumatic Radius (mm)	Tyre load rating for each of them (kg)	Maximum allowable mass of vehicle (kg)	Maximum permissible mass per axle (kg)
4	Front	240/70 R16	350	900	2200	1350
1	Rear	320/70 R24	525	1250	3300	2500
2	Front	260/70 R16	370	1030	3300	1350
2	Rear	360/70 R24	550	1500		2800
3	Front	240/70 R16	350	900	3300	1350
3	Rear	380/70 R20	525	1500		2800
4	Front	11.0/65 - 12	330	900	2200	1350
4	Rear	360/70 R20	500	1400	3300	2800
_	Front	11.0/65 - 12	330	900	2200	1350
5	Rear	320/85 R20	500	1360	3300	2720
6	Front	27/10.50 - 15	330	600	2200	1200
6	Rear	41/14.00 - 20	500	1400	3300	2800

4 : Commands and instruments

Index

4.1 Gener	ral list of commands	4-3
4.1.1	Dashboard controls	4-3
4.1.2	Front area controls	4-4
4.1.3	Right side controls	4-4
4.1.4	Left side controls	4-5
4.1.5	Externalcommands	4-5
4.1.6	Cab controls GL9	4-6
4.1.7	Cab controls SG1/1	4-7
4.2 Comm	nands	4-8
4.2.1	Mirrors rearview mirrors	4-8
4.2.2	Toolbox	4-9
4.2.3	Seat	4-10
4.2.4	Steering wheel	4-15
4.2.5	Acoustic alarm	4-15
4.2.6	CAN Diagnostic Interface	4-16
4.2.7	Safety frame	4-16
4.2.8	Cruise Control	4-17
4.3 Cab co	ontrols	4-21
4.3.1	Front windshield wiper	4-21
4.3.2	Rear windshield wiper	4-21
4.3.3	Sun shades (cabin GL)	4-22
4.3.4	Front-rear crystal washer	4-22
4.3.5	Goalkeeper	4-23
4.3.6	Crystals	4-24
4.3.7	Emergency exit	4-24
4.4 Multi	functional Dispaly	4-25
4.4.1	Welcome screen	4-29
4.4.2	Main Screen	4-31
4.4.3	MENU screen	4-40
4.4.4	Screen BUS OFF	4-49
4.4.5	POWER OFF Screen	4-49

4.5 Ligh	ts	4-50
4.5.1	1 Light switch	4-51
	2 - Right turn signal	
	3 Emergency lights	
	4 Beacon (optional)	
4.6 Air (Conditioning	4-53
	1 Air conditioning Controls	
	2 Air Ducts	

4.1 General list of commands

This paragraph provides an overview of all the available instruments and commands. Unless otherwise specified, they are valid for all versions. For the correct use of the commands listed here, you should carefully read the chapter "Rules of Use".

4.1.1 Dashboard controls

- 1 Directional buttons, display menu
- 2 Cruise control switch
- 3 Emergency light switch
- 4 Display





Fig. 4.1

- 5 Starter key panel
- 6 12V socket
- 7 USB socket
- 8 Hand throttle knob



4.1.2 Front area controls

- 1 Steering wheel
- 2 Reverse lever: Forward, Reverse
- 3 Gear shift lever
- 4 Speed splitter lever
- 5 Clutch pedal
- 6 Parking brake lever
- 7 Light diverter and acoustic alarm
- 8 Left brake pedal
- 9 Brake pedal connection blade
- 10 Right brake pedal
- 11 Accelerator pedal
- 12 Leva Hi-Lo
- 13 Rear PTO clutch lever





Fig. 4.3

4.1.3 Right side controls

- 1 Control levers for rear hydraulic spool vlaves
- 2 Rear linkage draft control lever
- 3 Rear lift position control lever





- 5 Differential lock switch
- 6 Diverter switch
- 7 Regeneration switch
- 8 Beacon
- 9 Front power take-off switch (if available)
- 10 Trailer brake switch (if available)
- 11 Auto-matic power take-off switch




Fig. 4.5

4.1.4 Left side controls

- PTO mode selection lever (Ground Speed/Independent)




Fig. 4.6

4.1.5 External controls

1 - Remote Battery switch




Fig. 4.7

- 2 7-pin trailer socket
- 3 External 12V socket
- 4 Quick connections for rear spool valves
- 5 PTO speed selection lever.




Fig. 4.8

4.1.6 GL9 cab controls

- 1 Air recirculation vents
- 2 Air temperature switch
- 3 Fan speed switch
- 4 Air outlet vents
- 5 Air Conditioning Switch




Fig. 4.9

- 6 Work light switch
- 7 Windshield washer pump switch
- 8 Work light switch
- 9 Rotating lamp switch
- 10 Rear windshield wiper switch





Fig. 4.10

4.1.7 Cab controls SG1/1

- 1 Air outlet vents
- 2 Air recirculation vents
- 3 Air Conditioning Switch
- 4 Air Conditioning Temperature
 Switch



- 5 Fan speed switch
- 6 Rear windshield wiper switch
- 7 Windshield washer pump switch
- 8 Front windshield wiper switch
- 9 Work light switch
- 10 Rotating lamp switch




4.2 Commands


4.2.1 Rear view mirrors

The rear view mirrors are adjustable in all directions, allowing the user an excellent view from the driver's seat.


Roll-bar



A - Cabin GL9




B - Cabin SG1/1



4.2.2 Toolbox

The tool box is located between the left footboard and the front wheel, on the left side of the tractor.



4.2.3 Seat

Do not get on or off the seat with the tractor moving.



danger

Seat adjustments must be made when the tractor is stopped, with the engine off and the parking brake on.

Mechanical seat controls:

- 1 Longitudinal adjustment
- 2 Height adjustment (limiter)
- 3 Weight adjustment
- 4 seat belts




Fig. 4.17

Producer	COBO	COBO
Type	GT62-M91 (SG1/1 cab)	SC84-M91 (GL9 cab and Roll-bar)
Approval No.	e13*1322/2014*2018/830W2*00015*01	-
Category	Α	Α
Class	I, II	I, II
location	Centrale	Centrale

Pneumatic seat controls:

- 1 Longitudinal adjustment
- 2 Height adjustment (pneumatic)
- 3 seat belts




Fig. 4.18

Producer	COBO
Туре	SC84-M97
Approval No.	
Category	A
Class	I, II
location	Centrale

Weight adjustment (if available)



Warning

Continuous adjustment of the driver's weight from 50 to 120 kg.

Turn the lever on the front side of the suspension clockwise or counterclockwise. The correct adjustment is achieved when the seat height is raised halfway through the suspension travel stroke.

If the seat has a window with a weight indicator, adjust according to the weight reading on the indicator.

If the seat is equipped with a window with an indicator needle (M99 suspension), the correct adjustment is achieved when the needle is in the center of the green area.

Some suspensions have a ratchet lever. The position of the handle must be adjusted according to the direction of rotation that the lever must take; pull the handle outwards and turn it 180° until it returns to position.




Fig. 4.19



Note

Make the adjustment with the operator seated, so that the seat is loaded.

Height adjustment (limiter)

The limiter limits the suspension's travel travel upwards.

The restriction is carried out continuously, to be carried out with the operator seated so that the seat is loaded. The seat height can be adjusted both upwards and downwards by turning the height adjustment knob.

After each height adjustment, the weight must be adjusted.



Make the adjustment with the operator seated, so that the seat is loaded.




Fig. 4.20

Height adjustment (pneumatic)

The setting is carried out continuously, to be carried out with the operator seated so that the seat is loaded. The seat height can be adjusted both upwards and downwards by turning the height adjustment knob.



Note

Make the adjustment with the operator seated, so that the seat is loaded.





Fig. 4.21

Longitudinal adjustment

Move the adjustment lever to the right to unlock the guides; the lever can be located on the left guide of the seat. Make sure that, after making the adjustment, the lever "clicks" by locking the guides. Check that the seat does not move lengthwise.



Document pocket (if any)

Туре	Operating Instructions
Hard pocket with back cover	Open the pocket by moving the cover to the back of the seat after removing the two side tabs from their seats
Flexible pocket with automatic button closure	Open the pocket by detaching the automatic button and lifting the closing flap upwards
Hard pocket with top cover*	Open the pocket by lifting the lid upward

^{*} allow the use of a locking padlock.

4.2.3.1 Abdominal safety belt


Static belt: adjust the length of the belt according to the operator's abdominal size, leaning against the backrest and keeping the belt attached to the lower abdomen, on the thighs side. Keeping the tab perpendicular to the belt, shorten the belt by pulling on the part (5) (free end), lengthen the belt by pulling on the part (6).

For the belt with winder, the adjustment takes place automatically.

Check that once worn, the belt is not twisted and that it does not pass over sharp corners or fragile objects if these items are in contact with clothing.

Fasten the belt by inserting the tab into the slot of the buckle until it triggers (indicated by a 'click') and verify that the tab has been attached by trying to remove it by pulling the belt out.

Unfasten the seat belt by pressing on the red button on the buckle (7), until the tab is triggered and detached.



How the winder works

The winder has two types of operation:

- lock the ribbon when the belt is fastened. Check, when the belt is worn, that the tape is blocked by trying to remove it slowly from the wrapper.
- lock the tape when it is abruptly removed from the winder.

Check, when the belt is on, that the wrapper is blocking the tape by abruptly removing it from the wrapper.

4.2.3.2 Seat care

Any intervention, including maintenance, must be carried out by specialized personnel and using appropriate personal protective equipment.

Dirt may compromise the functioning of the seat. So always keep the seat clean! To carry out the cleaning, the padding must not be detached from the seat frame.



danger

Risk of injury due to the backrest being thrown forward! When cleaning the backrest padding, the backrest adjustment should be activated only if the backrest is supported with one hand.



Warning

Don't clean the seat with high-pressure steam cleaning tractors!

When cleaning the padding surfaces, avoid the passage of moisture through the padding.

Check the compatibility of the detergents for upholstery or synthetic materials on the market first on a hidden and small surface.

4.2.4 Steering wheel

The tractor is equipped with a height-adjustable steering wheel. Before delivery, the steering wheel and steering column were adjusted to the standard position.

Telescopic adjustment: to adjust the position of the steering wheel, unlock the safety lock on the left side to be able to raise or lower the steering wheel to the desired position. Then move the safety latch downwards to lock the steering wheel.



danger

This adjustment must be made when the tractor is stopped with the engine off and the parking brake on.




Fig. 4.24

Tilting adjustment: to adjust the position of the steering wheel, unlock the safety lock by pulling down the lever on the right side, so that you can adjust the tilt of the steering wheel to the desired position. Then push the lever forward to lock the steering wheel.



danger

This adjustment must be made when the tractor is stopped with the engine off and the parking brake on.




Fig. 4.25

4.2.5 Acoustic alarm

Press the audible warning switch at the end of the light switch lever. The audible alarm will start ringing.

Use the acoustic alarm to signal your presence to pedestrians or other vehicles while the tractor is running.



Note

The audible alarm works regardless of the position of the switch.




Fig. 4.26

4.2.6 CAN Diagnostic Interface

The CAN diagnostic interface is used to establish communication between the diagnostic device and the tractor so that faults can be detected.




Fig. 4.27

4.2.7 Safety frame

Models without a cab are equipped with a protective frame of the fold-down type.



danger

When working, always keep the protective frame mounted in the correct vertical position.

If the roll bar is in a horizontal position, the safety conditions are lacking in the event of a rollover. Check the correct positioning of the roll bar before starting the engine.



danger

Under no circumstances should it be necessary to modify the structural components of the protective frame by welding additional parts, drilling holes, grinding, etc. Failure to observe these instructions may compromise the rigidity of the frame, reducing the level of protection guaranteed by the original equipment.




danger

In the event of the tractor overturning or damage to the protective frame or cab (for example due to impact), all deformed structural components must be replaced to ensure original safety.

To lower the safety frame, do the following on both sides:

- Remove the handle (1) then remove the pin (2).
- Lower the frame. Gas shock absorbers
 (3) they help the lifting action and reduce the backlash when lowering.
- Insert the pin (2) into the hole (A) to fix the rollbar in a vertical position; insert the pin into the hole (B) to fix the roll-bar in a horizontal position.
- Lock the pin (2) with the handle (1).



4.2.8 Cruise Control

It is possible to activate the Cruise Control (in the following of this manual it will be called CC) with the single press of the "SET" button.


When the engine is off, the setpoint page will be displayed for 5 seconds.

When the engine is running, it will be possible to modify and store the RPM values.



Icon	Description
n/min	Cruise Control in Standby: Set Point 1 selected
$\sum_{n/\min}^{2}$	Cruise Control in Standby: Set Point 2 selected
$\bigcap_{n/min}^1$	Active cruise control: Set Point 1 selected
n/min	Active cruise control: Set Point 2 selected

CC button.



Cruise Control activation and storage from standstill (V=0 Km/h)

Quick press of the "SET" button (1).

It is possible to activate the CC and store the RPM values desired when stopped so that they can then be used during work.

Pressing the "SET" button will display the stored Set Points and the icon (2) related to the selected Set Point.

In this phase, the system is activated and remains in stand-by. To change the value (number of engine revolutions) of the selected Set Point, press the "SET" button once: that Set Point will be highlighted in red and the word 'rpm' related to that Set Point will start flashing.

Turn the hand throttle wheel to change the rpm to the desired speed, then press the "SET" button once to store the value.

To change Set Point, press the "SET" button twice, make sure the icon (2) of CC has changed, repeat the above steps to set and store the new desired RPM value.



When the RPM values are stored when stopped, the motor remains in "LOW IDLE" (engine at idle) so as not to cause discomfort to the operator.





Fig. 4.30



CC use in motion

Activate the CC function (if it is not already active) by pressing the "SET" button.

Press the "RES" button (3) (quick press) 1 time to use the CC. The tractor will be moved to the selected RPM speed, 1 or 2 depending on

the icon shown. In this condition, so when the CC is active, the Set Point regime used is identified both by the relative icon and by the fact that the corresponding regime is shown with a larger font size.

Press the "RES" button (3) twice in a row to move from CC1 to CC2.



Warning

In order to use the CC, the tractor must be moving. It is not possible to use the CC starting from a standstill.




Fig. 4.32

RPM storage on the go

It is possible to store and use, in the dynamic phase, a certain RPM regime.

- Activate the CC function (if it is not already active) by pressing the "SET" button.
- To be able to memorize and use the RPM regime in which we are, press the "SET" button (1) once (quick press).
- The CC will store the current RPM, on the CC1 (4) or CC2 (5) value displayed at that time and will activate it immediately, keeping the speed constant.
- In stand-by mode, you can move from one CC to another by pressing the "SET" button (1) twice (quick press). The CC will remain in stand-by mode.




Fig. 4.33

"Step by step" adjustment of the setpoint in use


It is possible to make a "STEP by STEP" selection using the "+" (6) and "-" (7) buttons on the dashboard.

The single pressure increases or decreases the stored RPM value by 20 RPM at a time.

Continuous pressure allows you to increase or decrease the set RPM value by 100 RPM at a time.

The new set RPM value is stored and will replace the previous one.

This function is available only in the case of active Cruise Control.




Turn off and off Cruise Control function

The CC stand-by takes place for:

- Clutch pedal pressure
- Brake pedal pressure
- - Handbrake actuation
- Change to Neutral
- Operator not sitting for more than 15 seconds
- Single press of the 'RES' button

The CC is switched off by holding down the "RES" button (5) for at least 5 seconds or the tractor key off.



4.3 Cab controls

4.3.1 Front windshield wiper

Operates with starter key in the contact position. To operate the front windshield wiper, press the switch (1).



The lower part of the button lights up when the light switch knob is at the lights position (first click).

The switch is located on the right side of the cab top panel.

Position A = windshield wiper off

Position B = windshield wiper on

Position C (held down, automatically returns to B) = windshield washer




Fig. 4.36


4.3.2 Rear windshield wiper

Operates with starter key in the contact position. To operate the rear windshield wiper, press the switch (2).

The switch is located on the wiper motor. Position 1

= inserted

Position 0 = off



4.3.3 Sun shades (GL cabin)

To avoid operating the tractor with eyes exposed to direct sunlight, the operator should lower the sun shade.

- 1 Curtain rewind command
- 2 Curtain command

To lower the curtain, pull it down using the curtain control (2) as indicated by the arrow. To rewind it, press the curtain rewind command (1).



The sun shade is only available for the GL cabin.




Fig. 4.38

4.3.4 Front-rear crystal washer

Operates with starter key in the contact position.


Press the switch as indicated by the arrow, holding it down starts the water supply on both the front and rear windows.

The switch is located on the right side of the cab top panel.


Position A = windshield wiper off

Position B = windshield wiper on

Position C (held down, automatically returns to B) = windshield washer



Refill the windshield wiper fluid reservoir using appropriate cleaners. In the winter period , check that the liquid has antifreeze properties.




4.3.5 Goalkeeper

Both doors can be opened from the outside by pressing the appropriate button (3), and from the inside by pressing the appropriate lever (4).

The doors will be held in the open or closed position by shock absorbers.

It is possible to lock the doors with a security key.



4.3.6 Crystals

The front window can be opened from the inside by turning the lever counterclockwise and pushing the crystal forward. It is held in the open or closed position by shock absorbers.

Front windshield wiper Rear windshield wiper

4.3.7 Emergency exit.

A - Cabin GL9

Emergency exits are at the rear window and right door.




Fig. 4.43

B - Cabin SG1/1

The emergency exits are at the left door and the right door.




Fig. 4.44

4.4 Multifunctional tool

This chapter lists and describes the information on the multifunction instrument, both with regard to the warning lights, the analog indicators and the digital information display.




Fig. 4.45

L1 - Left turn signal L2 - Alternator malfunction L3 - Low engine oil pressure L4 - Right turn signal L5 -High beam lights

L6 - Low beam lights L7

- Position lights

L8 - Presence of water in fuel L9 - Operator alert.

L10 - Engine air filter obstruction

L11 - 4WD engaged

L12 - Differential lock engaged L13 -

Regeneration Inhibited

L14 - Forced Regeneration L15

- General Alarm Light

L16 - Parking brake engaged L17 -

Hydraulic oil filter clogged

L18 - Low brake oil level

L19 - Fuel Level Indicator Group


L20 - Engine coolant temperature warning light assembly

L21 - Digital information display


K1 - Left button K2 -

Right button

Turn the starter key clockwise to turn on the display. The welcome screen will be displayed.



To navigate between the display functions: K3 - Button + K4 - Button -



Alarm light and buzzer

Every time the system detects an error, the warning light (L9) located on the dashboard lights up, accompanied by an audible signal.



Fig. 4.48

The following table indicates in which situations the light (L9) and the buzzer come on; they will turn off when the conditions are solved.

Condition	LED	Buzzer
CAN BUS line connection for engine control unit absent	On	On
Engine failure	On	On
Engine alarm	On	On
Operator present and parking brake disengaged	On	On for 15 seconds
Vehicle control unit failure	On	On
Particulate filter clogging	On	On
Action required to start the engine	Off	On
Service maintenance required	Off	Impulse

Fuel level.

There are 8 LEDs indicating the fuel level in the tank. The moment the red light (first of the 8 LEDs) starts flashing, it means that you have entered reserve and need to refuel.



Fig. 4.49

Engine coolant temperature led

There are 8 LEDs expressing the engine coolant temperature level.




Fig. 4.50

Coolant temperature (°C)	Number of LEDs lit
< 60	1
60 - 69	2
70 - 79	3
80 - 89	4
90 - 99	5
100 - 109	6
110 - 115	7
> 115	8 beacons

4.4.1 Welcome screen

When the instrument panel is turned on, the Goldoni logo will be shown for 2.5 seconds.



Fig. 4.51

In the next 2.5 seconds, the following screen with the image of the tractor model in use will be shown.





Fig. 4.53

(A) - Hours worked

In this field, the dashboard shows the current hours worked.



Fig. 4.54

(B) - Hours Remaining at the Service. In this field, the dashboard shows the hours remaining for the next service interval.



Fig. 4.55

(C) - Battery Voltage. In this position, the voltage value detected on the battery will be displayed.



During the total 5 seconds on the welcome screen, the LEDs for fuel level and engine coolant temperature will light up in order, from first to last, and then turn off in reverse order.

During that interval all LEDs will also be on and then turn off again, and possibly immediately show a possible malfunction.



If malfunctions occur, the LED lights that identify it will light up.

4.4.2 Main screen

Three screens may be displayed depending on the working conditions:

(1) - No PTOengaged





Fig. 4.57

(2) - PTO engaged, rear or front (if available)



(3) - Both PTO engaged




Fig. 4.59

The following information will be displayed on the home screen:

(A) - Vehicle speed

This field shows the speed, expressed in km/h or mph, with a decimal precision.





Fig. 4.60

(B) - Engine RPM


Field (B) shows the number of engine revolutions, with the reference icon and the corresponding unit of measurement.

By default, engine speed information is shown.



(C) - Warnings messages (only in the screen without PTOs)

In the event that service is required or in the event that the particle filter clogging percentage is greater than 110%, when the main screen first appears after the power is turned on, the corresponding error message will be displayed for a duration of 5 seconds, accompanied by the beeper. In the case of a service-related warning, this message is no longer shown in the event that, when maintenance is performed, the condition is reset by appropriate CAN message from Diagnostic Tool.






Fig. 4.63

(D) - Instantaneous consumption

Field (D) shows the instantaneous consumption expressed as I/h. There is also an indicator (D1) that moves from left to right according to the instantaneous consumption value.




Fig. 4.64

(E) - Set Point del Cruise Control

The field (E) shows the cruise control setting parameters.





Fig. 4.65

(F) - Front PTO engaged (if available)

In this position, the status of the front PTO will be displayed. See the table below for a description of the icons displayed.

Icon	Description	
**************************************	Front PTO engaged	



(G) - Rear PTO engaged

In this position, the status of the rear PTO will be displayed. See the table below for a description of the icons displayed.

Icon	Description	
540 - Grøn	- PTO	Reverse Engaged with speed 540
540E 5 4 €	- PTO	Reverse Engaged with speed 540E
1000 6-0 m	- PTO	Reverse Engaged with speed 1000

The icon (F) is shown when calculating the speed P.D.F. (540, 540E or 1000) before showing the correct icon.

AUTO STOP COLOR L 0.0 km/h 0 rpm 0.0 l/h

Fig. 4.67


(H) (J) - Starter interlock

This chapter lists and describes the security measures applied to ensure the start-up phase.

In the box (J), the missing safety conditions will be shown in order to start the tractor.



It will not be possible to start the tractor without carrying out safety operations.




Function	Icon displayed on the display	Icon description	Tractor behavior	Solution
Operator presence switch on seat		The icon indicates that the operator must be seated on the seat during the start-up phase of the tractor	If the system does not detect the presence of the operator in the seat, the icon will be displayed on the dashboard display followed by an acoustic signal. It will not be possible to start the tractor	Sit in the seat to be able to start the tractor
Sensor Shuttle lever position	N	The icon indicates that the shuttle's leverage mustTo be positioned in Neutral (N)	If the system does not detect that the inverter lever is positioned in Neutral (N), the icon will be displayed on the dashboard display followed by an acoustic signal. It will not be possible to start the tractor	Place the shuttle lever in the Neutral (N) position
Front and rear PTO sensor not engaged	\\$	The icon indicates that the front power outlet and the rear power outlet Th ey do not need to be entered	If the system detects that the front or rear power outlet is engaged, the icon will be displayed on the dashboard display followed by an acoustic signal. It will not be possible to start the tractor	Disconnect the front PTO and Set the rear Power Grab to Neutral or Synchronized mode
Sensor brake Parking number inserted	(P)	The icon Indica tes that the parking brake must be turned on	If the system detects that the parking brake is not engaged, the icon will be displayed on the dashboard display followed by an audible signal. It will not be possible to start the tractor	Switch on the parking brake
Sensor Clutch pedal pressed	+ %	The icon indicates that the clutch pedal must be pressed	If the system detects that the clutch pedal is not depressed, the icon will be displayed on the dashboard display followed by an audible signal. It will not be possible to start the tractor	Depress the clutch pedal

(I) - Electro-hydraulic spool valves (if available)

The field (D) indicates the status of the electrohydraulic spool valves. Here are the graphics :

	Barana
Icon	Description
	Spool valve 1 selected/hooked
<u></u> 2	Spool valve 2 selected/hooked
]	Spool valve 3 selected/hooked
	Spool valve 4 selected/hooked
≪ ≧ 1	Distributor 1 selected andin floating/lock mode
>>	






Note

In the case of distributor 1 in floating mode, the corresponding indicator light will flash with a frequency of 1 flash per second.

(J) - Inverter

In this position, the status of the shuttle will be displayed. See the table below for a description of the icons displayed.

Icon	Description
N	Shuttle in Neutral position
	Shuttle in forward gear position
□□□ •□□	Shuttle in reverse position



(K) - PTO Auto Mode

In this position, the status of the PTO Auto Mode will be displayed. See the table below for a description of the icons displayed.

Icon	Description
AUTO	- PTO AUTO Mode Active






Fig. 4.71

(L) - 4WD Auto Mode

In this position, the status of the PTO Auto Mode will be displayed. See the table below for a description of the icons displayed.

4WD	Dashboard indicator light	Display icon
Not inserted	Off	Off
Permanent (Lower speed	Lit.	Off
а		
t 18 km/h)		
Automatic (lower speed	On when the double	
а	drive	
t 12 km/h)	is	
	engaged	





The automatic 4WD mode can only be activated at speeds below 12 km/h.

Note

Reaching a speed of 18 km/h, it automatically disengages; returning below 12 km/h, 4WD automatically reengages.

In case of braking, 4WD automatically engages. (dashboard light on, display icon off).

(M) - Active Regeneration / NOx concentration in exhaust gas above threshold.

In this position, the regeneration status will be displayed. See the table below for a description of the icons displayed.

Icon	Description
E -37	Regeneration Activated
= 1:3>	NOx concentration in exhaust gas above the threshold




Fig. 4.73

(N) - Trailer turn signal indicator (if available)

The icon concerning the activation of the trailer turn signals will be displayed in this position.





Fig. 4.74

(O) - Glow plug preheating

The icon concerning the activation of glow plugs for engine preheating will be displayed in this position.



(P) - STOP SIGNAL

The icon concerning the stop signal will be displayed in this position; it lights up whenever a condition critical to tractor operation arises.

Whenever this light appears, TURN OFF THE ENGINE IMMEDIATELY AND CONTACT THE GOLDONI SERVICE CENTER.




Fig. 4.76

4.4.3 MENU screen

Starting from the main screen, pressing the right button (K2) takes you to the MENU screen from which you can access the screens of:

- Settings
- Diagnostics
- Info
- Service Using the "+" and "-" buttons, one can move around the screen.

To confirm the selected item and consequently move to the associated page, press the left button (K1); alternatively, press and hold the right button (K2) to return to the main reference screen.



4.4.3.1 SETTINGS

In this screen there is an additional menu with the following possible options:

- Date/Time
- Brightness
- Language
- (M) Unit of measurement

Using the "+" and "-" buttons one can move around the screen.

To confirm the selected item and consequently move to the associated page, press the left button (K1); alternatively, press and hold the right button (K2) to return to the MENU screen.

IMPOSTAZIONI DATA/ORA LUMINOSITÀ LINGUA UNITÀ DI MISURA

Fig. 4.78

- Date and Time

This screen displays, with editing options, dates and time in the format "dd/ mm/yyyy hh:mm"

dd - Day mm - Month yyyy - Year hh - Hours mm -Minutes

Pressing the left button (K1) will cause the day field to start flashing and highlight red; use the "+" and "-" buttons to change the value. Pressing the left button (K1) again confirms the value entered and moves on to edit the next field, which will be highlighted in red and will in turn begin flashing. In general, to change the selected field, use the "+" and "-" buttons: if you do not want to make any changes, press the left button (K1) to move to the next field change.

When you reach the last editable field (minutes), hold down the left button (K1) to confirm and finish editing the date and time.

Press the "-" button to return to the previous menu; alternatively press the right button (K2) for 1 second to return to the main reference screen.

DATA E ORA 26 / 05 / 2023 12 : 30

BRIGHTNESS

In this screen you can view and possibly change settings related to the brightness of the display and LEDs.

There are two different modes of brightness management:

- Operator Manual
- Automatic

In "Manual" mode, to choose the desired brightness mode, press the left button (K1), and the item for the mode currently in use will highlight in red: use the "+" and "-" buttons indifferently to change modes.

In "Automatic" mode, on the other hand, the display uses the internal light sensor, automatically adjusting the brightness of the screen and LEDs according to the intensity of external light.

Press the "-" button to return to the previous menu; alternatively press the right button (K2) for 1 second to return to the main reference screen.

If you have set the "Manual" mode, you can independently change the brightness values of Display and Led: by pressing the right button (K2), the screen brightness parameter will highlight in red color: to increase or decrease the value, press and/or hold down the "+" and "-" buttons.

Whether you have changed this value or not, pressing the right button (K2) again will confirm the brightness value of the screen, this item will return to white, and you will move on to changing the brightness of the LEDs. In this, too, the corresponding parameter will be highlighted in red, and to change its value use the "+" and "-" buttons in the same way.

Set the desired led brightness value and press the right button (K2) again to finish editing and save the selected values. When confirmed, the entry will return to white.

Press the "-" button to return to the previous menu; alternatively press the right button (K2) for 1 second to return to the main reference screen.



Fig. 4.80



LANGUAGE

This screen displays, and possibly changes the current language. You can choose from 4 different languages:

- Italian
- English
- Spanish
- French

To change this setting, press the left button (K1) and the language item will highlight in red; use the "+" and "-" buttons to navigate through the available options.

Once the desired language is selected, press the left button (K1) again to confirm.

Press the "-" button to return to the previous menu; alternatively press the right button (K2) for 1 second to return to the main reference screen.

Fig. 4.82

(M) - Unit of measurement

In this screen you can view and possibly change the unit of measurement related to the vehicle speed. There are two possible units of speed measurement:

- km/h
- mph

To change this parameter, first press the right button (K2), the unit measurement will highlight red. To switch between items use the "+" and "-" buttons indifferently.

To confirm the selected option, press the right button (K2) again; when confirmed, the unit will return to white.

Press the "-" button to return to the previous menu; alternatively press the right button (K2) for 1 second to return to the main reference screen.



4.4.3.2 DIAGNOSIS




The DIAGNOSIS screen can be accessed directly from the main screen by pressing the left button (K1)

This screen shows the errors in the vehicle.

Each error code is identified according to 2 factors:

- Icon identifying the source of error (engine, vehicle ECU, PTO., Display, Spool valves generic error).
- 4-digit code that uniquely identifies the error.

You have the following indicator lights identifying the error source:



If the tractor has more than 6 active errors, the most serious errors will be shown. If there are errors with the same degree of severity, the chronologically most recent ones will be shown.

If an error is present, the operator alert light (L9) will be on.

Press the "-" button to return to the previous menu; alternatively, press the right button (K2) for 1 second to return to the main reference screen.




Fig. 4.84

4.4.3.3 INFO

In this screen there is a menu with the following items:

- Dpf
- Vehicle
- Industry 4.0
- Trip

Again, the selected item is highlighted in red, and to navigate through the options present press the "+" and "-" buttons to scroll down and up.

Press the left button (K1) to confirm the selected option and consequently move to the corresponding screen.

Press the right button (K2) to return to the MENU screen.

INFO DPF VEICOLO INDUSTRIA 4.0 TRIP

Fig. 4.85

DPF INFO.

This screen shows the following information about the aftertreatment system:

- Percentage of clogging of the particle filter.
- Number of hours since the last active regeneration

When this warning message is displayed, if the engine does not regenerate automatically, perform forced regeneration.

Press the "-" button to return to the INFO screen; alternatively press the right button (K2) for 1 second to return to the MENU screen.



Note

In case the particle filter clogging percentage exceeds 110 % a warning message will be displayed on the main screen for the duration of 5 seconds, while in this screen the entry for this parameter will be highlighted in red.



VEHICLE INFO



The VEHICLE INFO screen can be accessed directly from the main screen by pressing the "+" button (K3), but only if Cruise Control is not active. In this case, the +/- keys will make the "Step by Step" adjustment of the setpoint in use.

This screen shows some operating parameters of the vehicle:

- Engine coolant temperature
- Engine oil pressure
- Motor torque
- Total engine hours
- Total vehicle hours
- Battery Voltage

Press the "-" button to return to the INFO screen; alternatively, press the right button (K2) for 1 second to return to the MENU screen.

INFO VEIC	OLO
Temp. liquido motore	20 °C
Pressione olio motore	1.0 Bar
Coppia motore	0 Nm
Ore motore totali	0
Ore veicolo Totali	0
Tensione Batteria	0.0 V

Fig. 4.87

FARMING KIT INFO (if available)

This screen shows the contents of Farming system:

- In the green box, the order number. The data is transmitted from the portal and is reported to the display with a number from 1 to 10.
- In the pink box, the type of processing to be performed for the specific job order chosen from 1 to 15 (swath, plowing, bedding, pruning, fertilization, milling, packaging, irrigation, le- veling, blending, tamping, subsoiling, rolling, sowing, shredding). The icon changes according to the selected processing.
- In the purple box the execution date of the selected job.
- In the yellow box the com- munication start and end times.
- In the red box are the GPS coordinates, latitude and longitude, of where the tractor will go to perform the work.
- The blue box shows the load level of the diesel engine: green light with engine load from 1 to 80%, yellow light from 80% to 90%, red light over 90%.

Press the "-" button to return to the INFO screen; alternatively, press the right button (K2) for 1 second to return to the MENU screen.



TRIP INFO.



The INFO TRIP screen can be accessed directly from the main screen by pressing the "-" button (K4), but only if Cruise Control is not active. In this case, the +/- keys will make the "Step by Step" adjustment of the setpoint in use.

This screen displays the parameter "Trip" which indicates the number of hours and minutes of motor operation elapsed since this variable was last reset.



Fig. 4.89

There are two "Trip" items that can be managed independently: once you enter this page, press the left button (K1) and the value for the first of the two items will highlight in red.



To perform zeroing, press the left button (K1) for 1 second, alternatively press the left button (K1) again to go to the selection of the second item. Following any resetting of the first item, the selection will automatically switch to the second item.

To reset the second entry always hold the left button (K1) for 1 second, alternatively press the left button (K1) again to exit editing.

Press the "-" button to return to the INFO screen; alternatively, press the right button (K2) for 1 second to return to the MENU screen.



Fig. 4.91

4.4.3.4 **SERVICE**

This screen provides information about the service. In particular, it is shown:

- Service status: identified by a green sticker if no service is needed, by a red sticker otherwise.
- Hours until the next service interval .
- Engine hours at last service performed.

Press the "-" button to return to the previous menu; alternatively, press the right button (K2) for 1 second to return to the main reference screen.



4.4.4 BUS OFF screen

This screen is displayed when an absence of communication from the electronic control units is identified. The icon of the control unit that is not communicating (A) will be displayed along with the STOP icon (B). A continuous beep will be active.





Fig. 4.93

4.4.5 POWER OFF screen

Turning the key counterclockwise will start the procedure of turning off the display. The following screen will be shown for 1 second before the display turns off completely.



4.5 Lights




Fig. 4.95

1 - High beam headlight (if available)

- 2 Low beam headlight
- 3 Front position light
- 4 Front turn signal
- 5 Brake stop light and rear position6 Rear turn signal
- 7 Rear license plate light
- 8 Rear reflectors
- 9 Rotating lamp (optional)

4.5.1 Light switch

Place the light diverter knob in position (1) to turn on the right and left side lights.

Place the light diverter knob in position (2) to turn on the low beam lights.

Move the light diverter lever forward to turn on the high beam lights and the high beam light on the dashboard will come on (if available).





Fig. 4.96

4.5.2 Direction indicator

Move the light diverter lever downwards to activate the right turn signal. Move the lever upwards to activate the left turn signal. The light for the activated direction indicator will start to flash on the instrument panel.



4.5.3 Emergency lights

The emergency light switch is used to control the emergency lights. Pressing the switch in position (1) will flash the direction indicators at the same time. Pressing the switch in position (0) will stop the direction indicators from blinking.





Fig. 4.98

4.5.4 Rotating lamp (optional)

The beacon switch is used to control the ignition of the rotating lamp. Press the switch in position (1) to turn on the rotating lamp; press the switch in place (0) to turn it off.



4.6 Air Conditioning

4.6.1 Air conditioning controls

The air conditioning control panel consists of:

- 1 ventilation adjustment knob (electric fan)
- 2 heating knob
- 3 air conditioner switch (cold air adjustment)

To modify air volume fed into the cabin, act on the three speeds of the electric fan (1).

With the knob (2) you can adjust the hot air temperature. Turning the knob (2) adjusts the temperature, turning clockwise (all the way to the right) provides maximum heating inside the cabin. Turning (all the way to the left) stops the circulation of hot air in the cabin. For dehumidifier function also turn on the air conditioner.

With the knob (3) you can adjust the temperature of cold air. Turning the knob (3) adjusts the temperature, turning clockwise (all the way to the right) provides maximum cooling inside the cabin. Turning (all the way to the left) stops the circulation of cold air in the cabin. For maximum effectiveness of the air conditioner make sure the heater is closed.

A - Cabin GL9




Fig. 4.100

B - Cabin SG1/1




Fig. 4.101



When the air conditioner or fan heater starts, close the cabin doors and windows. Otherwise, the cooling or heating effect will be diminished.



Warning

Do not disassemble air conditioner parts, to avoid possible damage to the air conditioning system.



Warning

To ensure proper operation of the air conditioning system, clean the condenser at regular intervals to remove dust, insects or other impurities



Warning

In order to prevent compressor jamming, turn on the air conditioner for a few minutes at least once a month. Turn on the compressor, turn the temperature control rotary switch to the maximum and minimum positions, so that the engine is allowed to idle for a few minutes.



Warning

Special tools and protective equipment are needed to maintain the air conditioner. If the air conditioner is broken, contact the GOLDONI service network to prevent any risks or accidents due to improper maintenance.



danger

Avoid direct contact with coolant! If it should come into contact with the eyes, seek immediate medical attention for treatment to prevent further injury

The maximum permissible temperature near the coolant pipes is 80°C.

4.6.2 Air diffusers

Air recirculation vents are of two types:

- 4 air outlet vent (diffuser)
- 5 suction nozzle

The nozzle cover plate can be rotated to adjust air volume and direction.

To achieve air recirculation inside the cabin, the ventilation should be operated with all diffusers (4) and extractors (5) open and the doors closed; this allows the circuit to draw air from inside the cabin and not from outside.

A - Cabin GL9





Fig. 4.102

B - Cabin SG1/1



5: RULES OF USE

Index

5.1	Start	Start and arrest the engine		
	5.1.1	Startup safety systems	5-4	
	5.1.2	Access to the driver's seat (version with roll-bar)	5-5	
	5.1.3	Access to the driver's seat (version with cab)	5-5	
	5.1.4	Starting the engine	5-6	
	5.1.5	Engine shutdown	5-9	
	5.1.6	Starting the tractor	5-10	
	5.1.7	Arresting the tractor	5-12	
	5.1.8	Running-in	5-14	
5.2	Partic	culate filter regeneration (DPF)	5-15	
	5.2.1	Particulate filter regeneration	5-15	
	5.2.2	Regeneration strategy DPF	5-18	
5.3	Trans	mission controls	5-21	
	5.3.1	Hand Throttle	5-21	
	5.3.2	Pedal accelerator		
	5.3.3	Gearbox clutch pedal	5-22	
	5.3.4	Shuttle lever	5-23	
	5.3.5	Range selection	5-23	
	5.3.6	Gear lever	5-24	
	5.3.7	Selection mode	5-25	
	5.3.8	Differential lock	5-26	
	5.3.9	Double traction	5-27	
5.4	brakir	ng system	5-30	
	5.4.1	Service brake	5-30	
	5.4.2	Parking brake	5-31	
5.5	PTO		5-33	
	5.5.1	Rear PTO	5-33	
	5.5.2	- Front PTO engaged (if available)	5-37	
	5.5.3	PTO Speed		
	5.5.4	Cardan Joint	5-39	

5.6	Rear li	ft	5-40
	5.6.1	Position controlled	.5-40
	5.6.2	Draft control settings	.5-41
	5.6.3	Mixed control position/draft	.5-42
	5.6.4	Floating operation	
	5.6.5	Lift speed and sensitivity adjustment	.5-43
	5.6.6	Transportation by road	. 5-44
5.7	Front l	linkage (if available)	5-44
5.8	Hook and towbar5		
	5.8.1	Safety Warnings	.5-45
	5.8.2	Front rescue hook	.5-46
	5.8.3	Rear tow bar	.5-47
	5.8.4	Tow bars towing	. 5-50
5.9	Trailer	· towing	5-51
		7-pin trailer socket	
5.10		point linkage	
	_	Rear three point linkage	
		Front three-point hitch (if available)	
5.11	Hydra	ulic spool valves	.5-63
	5.11.1	Equipment available	.5-66
5.12	Hydra	ulic trailer brakes (if available)	5-71
	5.12.1	Hydraulic trailer brakes - Single-line type CUNA	.5-72
	5.12.2	Hydraulic trailer brakes - Single line France	.5-74
	5.12.3	Hydraulic trailer brakes - Dual-line M.R	.5-76
5.13	Wheel	s and Tracks	5-78
	5.13.1	Inflating tires	.5-79
	5.13.2	Tire puncture	.5-80
	5.13.3	Wheel replacement	.5-81
	5.13.4	Adjusting the Tracks	.5-82
	5.13.5	Steering angle setting	.5-86
5.14	Front f	fenders	5-87
	5.14.1	Rotation angle adjustment fenders	.5-87
	5.14.2	Horizontal adjustment	.5-87
5.15	Ballast	S	. 5-88

RULES OF USE

5.15.1	Front ballasts	(optional)	5-88
5.15.2	Liquid ballast ((not for road traffic))5-89

5.1 Starting and arresting the engine

5.1.1 Startup safety systems

This chapter lists and describes the safety measures applied to the tractor in order to guarantee the minimum safety conditions during start-up.

When turned on, the operations to be carried out to safely start the tractor will be shown on the display.



Function	Icon	Icon description	Tractor behavior	Solution
Switch operator presence on seat		The icon indicates that the the operator shall to be seated on seat during The start-up phase Of the tractor	If the system does not detect The presence Of the operator on the seat a beep. It won't be Is it possible to start the tractor	Sit on the seat. in order to start the tractor
Sensor position shuttle lever	N	The icon indicates that the leverage of the shuttle shall being positioned in Neutral (N)	If the system does not detect That the shuttle lever is placed in Neutral (N) it will be an audible signal was made. It will not be possible to start the tractor	Position the lever of the of the shuttle in position Neutral (N).
Sensor Socke t by PTO - PTO Reverse not Engaged	\\$	The icon indicat es which The Socket by PTO front (if available) and Reverse not must being enter		Disengage The Socket by PTO front and place the lever Of modes Of Socket by Rear PTO Neutral (N) position. Ground speed
Sensor brake by engaged	(P)	The icon indicat es which Thebrake by Parking must be inserted	If the system detects that The parking brake is not It is engaged in a beep. It won't be Is it possible to start the tractor	Switch on the brake of
Sensor pedal Clutch pressed	₩	The icon indicates that the The pedal Of Friction must be Pressed	If the system detects that The clutch pedal is not It is pressed a beep. It won't be Is it possible to start the tractor	Press the pedal of the clutch

5.1.2 Access to the driver's seat (roll bar version)

Follow the instructions below to safely and correctly access the driver's seat:

- - Make sure you grab the handrails (1) then carefully get on the tractor.

danger

The platform (2) can be slippery, grip the handrails (1) securely during the entering phase

- Sit on the seat.
- Adjust mirrors and seat position, as explained in the previous chapter.
- Familiarize yourself with the location of the various tractor controls.
- Fasten your seatbelt.




Fig. 5.1

5.1.3 Access to the driver's seat (cab version)



Note

The figure represents the GL9 (high-profile) booth, but the directions also apply to the SG1/1 (low-profile) booth, as it has similar handholding points.

Follow the instructions below to safely and correctly access the driver's seat:

- Open the door.
- - Make sure you grab the handrails (1) then carefully get on the tractor.



danger

The platform (2) can be slippery, grip the handrails (1) securely during the entering phase

- Sit on the seat.
- Close the door.
- Adjust mirrors and seat position, as explained in the previous chapter.
- Familiarize yourself with the location of the various tractor controls.
- Fasten your seatbelt.




Fig. 5.2

5.1.4 Starting the engine

To start the engine, you must be properly seated in the driver's seat and follow the instructions below:

- insert the handbrake;
- press the clutch pedal deeply, then bring all the control levers to the neutral position;
- Turn the starter key to the start-ready position and wait for the system checks;
- Turn the starter key to the start position.

The key lock is equipped with an anti-repetition system. To perform a second starting operation, return the key to the 'OFF' position.

Before moving the tractor, wait at least 30 seconds with the engine running idle, to allow all the organs to be properly lubricated.



Warning

Before attempting to start the engine, verify that there is fuel in the tank.

Insert the key into the starter switch. The starter switch has 3 positions:

- OFF: In this position the engine is off and you can insert or remove the key.
- ON: In this position, the tractor circuit is run and the display will turn on. (If the outside temperature is below -8
- °C the preheating system will be activated automatically.)
- ST: In this position, the engine can be started. As soon as the engine is started, release the key that will automatically return to the ON position.




Fig. 5.3

To start the engine, press the clutch pedal (1) deeply and place the key on. Check that there are no fault lights on on the display.

As soon as the preheating light goes out, you can start the engine by placing the key on ST. Wait for the engine to start and release the key.




Warning


After starting the engine, release the key immediately so as to reposition it to ON, otherwise the motor will be damaged.



Warning

Do not attempt to start the engine for more than 20 consecutive seconds. If the engine does not start, wait 2 minutes for it to cool down and try again. If the ignition fails 4 consecutive times, look for the solution to the problem before restarting another time.





5.1.4.1 Starting the engine at low outside temperatures



DO NOT use ether or other fluids to start the engine at low temperatures, this could cause serious harm to people and the vehicle.

Warning

DO NOT attempt to start the engine for a long time, otherwise the battery will run out.



Warning

When the temperature is below 10°C, turn the key to ST position only when the preheating phase is over.

To maintain the life of the motor and its efficiency, it must be heated in both hot and cold seasons.

At low temperatures, after starting the engine, run it at low revs for 3-4 minutes before starting work.

When the temperature is below 0°C, it is advisable to insert the recommended refrigerant mixture into the cooling circuit and introduce the anticoagulant additive into the tank, and only then the diesel.



Warning

For the amount and type of liquid, see 'Lubricants, Fuels, and Coolants'.

5.1.5 Engine shutdown



danger

Always lower the mounted implement to ground level.



Warning

Do not turn off the engine under full load or at high rotational speed.

Before turning off the engine, stop the tractor following the instructions described in the "Tractor Stop" section.

Before moving the ignition key to the OFF position, wait a few minutes with the engine running at idle speed in order to obtain homogeneous cooling of all components and avoid possible damage caused by high temperatures and poor lubrication.

Place the starter key in the OFF position.


Remove the key from the switch to prevent unqualified personnel from starting the engine.



Warning

If the battery is disconnected, do not disconnect the power supply while the engine is running to turn off the tractor.

Before disconnecting the power supply, turn off the engine and wait at least 3 minutes, so that the electronic control unit can carry out the "afterrun" procedure: if this procedure is not respected, the electronic engine management control unit may be damaged.





danger

Always start the engine from the driver's seat with all gear levers and the PTO lever in a neutral position. The brakes must be registered correctly and engaged at the same time. Adjust the seat and fasten your seat belts.



danger

Never run the engine indoors without making sure that it has adequate ventilation, the exhaust gas are harmful to your health and can even be lethal.



danger

Before starting the engine, make sure that the handbrake is locked and that the gearbox and the PTO are in neutral, even if the tractor is equipped with a safety device when starting. Never exclude the safety switch when starting. If this does not work regularly, contact the specialized staff of your Dealer.



danger

Before starting the engine, make sure that all connected implements have been completely turned down.



danger

Make sure that all the intended guards and protections are properly installed on the tractor (safety frame, side panels, bonding, power gain protection, front deck transmission shaft protection, etc.).



danger


Before starting the tractor, always make sure that there are no people or obstacles within its range of action.

After starting the tractor, always check that all lights and implements are working properly. If a fault or malfunction is detected, DO NOT use the tractor until the problem has been solved.

After starting the engine, proceed as follows:


Depress the clutch pedal (1);

Use the gear ever (2) to enter the desired gear;



Use the range levers (3) to enter the desired range;

Use the shuttle lever (4) to enter the desired direction of travel;



Disconnect the parking brake (5);

Gradually release the clutch pedal (1) and increase the engine speed using the accelerator.




Fig. 5.9

5.1.6 Arresting the tractor



danger

Before leaving the tractor, always lower the implements connected to the ground. Never leave it in a raised position above the ground.

When leaving the tractor, always bring all the control levers to the neutral position, insert the handbrake, stop the engine and engage a gear.



danger

When the tractor is abandoned and left unattended, always remove the starter key.



If possible, park the tractor on level ground, enter a gear and lock the handbrake. On sloping terrain, in addition to locking the handbrake, switch on the first gear of the uphill gearbox or the first reverse gear downhill. For greater safety, also use some stopping wedges, don't fail to do so if you park with a connected trailer.




Fig. 5.10

To stop the engine, proceed as follows: Decrease engine speed;

Press the clutch pedal (1) and the brakes (2) to slow down until it stops;

Place the range, gear and shuttle levers in the neutra position.




Fig. 5.11

Release the clutch pedal (1);

Insert the parking brake (3) by pulling the lever;




Fig. 5.12


Place the key in the OFF position.

Remove the key from the switch to prevent unqualified personnel from starting the engine.



Warning

Refer to the 'Engine Stopping' section to turn off the engine properly.



5.1.7 Running-in

Before being used, the tractor must be operated for a certain time under the expected lubrication, rotational speed and load conditions. At the same time, carry out the necessary checks, adjustments and maintenance, to normalize the technical conditions.

Preparations before the run-in

- Lubricate the front hub oil pan, the front drive axle coupling pin, and the water pump shaft. Check the level in the engine oil pan, in the transmission system and in the lift, in the central control of the front wheel axle and in the final reducer, making the necessary refills
- Top up the diesel and coolant, updating the labels accordingly.
- Check that the tires are inflated to normal pressure.
- Check that the electrical circuit is working properly and that its connections are secure.
- Move all control levers to a neutral position.

Running-in

During the run-in period (first 50 hours of operation), it is necessary to use the engine with a percentage of load absorbed between 50% and 70% of the maximum power.

- Avoid using the engine at its maximum performance for long periods during run-in.
- Do not run in the engine with an absorbed load percentage of less than 50% or with a low rpm for long periods. A run-in carried out in this way may be the cause of excessive oil consumption and/or oil spillage from the drain.
- If the engine is also run-in for a duration of more than 50 hours with a percentage of load absorbed between 50% and 70% of the maximum power, a longer operating life of the organs and a lower maintenance cost can be guaranteed.
- During the run-in, carry out maintenance according to the established intervals (see the chapter "Maintenance coupons").

5.2 Particulate filter regeneration (DPF)

5.2.1 Particulate filter regeneration

The diesel particulate filter (DPF) is a device designed to remove polluting particles from diesel engine exhaust gases.

The exhaust gas treatment system is based on the ability to capture and retain unburned polluting particles inside a special filter, and then regularly eliminating them through combustion during a subsequent phase, called "regeneration".

The procedure takes about 15-30 minutes (depends on the type of engine and the amount of particulate matter accumulated in the DPF filter).

The regeneration of the particulate filter can take place automatically or manually.

The particulate filter regeneration button has two positions:

- Position (A): FORCED REGENERATION.
 Hold down the button for 3 to 5 seconds and release.
- Position (C): REGENE INHIBITION-RATION. Hold for 3 to 5 seconds and release.




Fig. 5.14

The start of the automatic regeneration phase is indicated to the operator on the LCD display of the instrument panel. The indication is necessary for safety purposes to inform the operator of the high temperature reached by the exhaust during the process.

Automatic regeneration does not affect engine performance. During the procedure, the operator can continue to use the vehicle normally.

Under certain conditions, automatic regeneration may not be completed (for example continuous engine stops and starts, long periods at idle speed) and therefore it may be necessary to repeat it.

The start of automatic or manual regeneration, if set, is highlighted when the light (1) on the LCD display comes on.

Once the operation is finished, the light goes out.




Fig. 5.15



Warning

The operator must continue to drive the vehicle during the regeneration process.

If the regeneration starts in unsafe places, it is possible to inhibit the regeneration itself by placing the command in position (C), see figure 5.14. Inhibited regeneration, if set, is highlighted when the light (2) on the LCD display comes on.

Regenerate as soon as you are in a safe place.

Continuing to work with inhibited regeneration, the DPF becomes clogged with a consequent reduction in engine performance, indicated by the flashing of the light (3) on the instrument panel together with an acoustic warning.




Fig. 5.16




Fig. 5.17

In case the particle filter clogging percentage is more than 110%, when the main screen first appears after the power is turned on, the corresponding error message will be displayed for a duration of 5 seconds, accompanied by the beeper.




Fig. 5.18



If an excessive number of regenerations have been carried out, an additional engine oil replacement is required compared to what is indicated in the maintenance plan.

The request for oil replacement is indicated when the alarm light on in the instrument panel display comes on, this request does not result in any weakening of the engine.


It is possible to complete the regeneration process by pressing and holding the button in position (A) until the regeneration starts; the button automatically returns to position (B) when released. This procedure is called "Manual Regeneration."

danger

Manual regeneration must be carried out with the tractor parked. Park the tractor outdoors, away from potentially flammable elements (e.g. hay, straw, dry leaves, etc.) and away from people or animals.

Do not stay on the tractor during the manual regeneration procedure.

Keep the tractor under strict control throughout the process.



In order to avoid accidents caused by inhaling engine exhaust gases, always operate the engine in a well-ventilated area. Engine exhaust fumes are toxic.



danger

During regeneration, the exhaust gases become extremely hot and cause fire if directed at combustible materials. The vehicle during this procedure must be parked outside.

During the regeneration phase of the particulate filter, do not park the vehicle on surfaces that have flammable materials and that may burn in contact with the exhaust system.

During regeneration, the muffler reaches extremely high temperatures. Make sure that the exhaust system is not in contact with or near people or things. It is forbidden to use exhaust gas aspirators in contact with the muffler.



The temperature of the engine coolant must be above 65°C.

The engine will increase its rpm up to about 2000 rpm.

The regeneration process of the DPF filter is to be considered complete when the motor returns to idle speed. When manual regeneration is finished, turn off and on the engine again.

5.2.2 DPF regeneration strategy

5.2.2.1 DPF operating thresholds



Note

Completing the regeneration reduces the mass of the particulate matter to a value below the minimum threshold.

Particulate mass less than 100%

Initialization of particulate matter accumulation.

Particulate mass between 100% and 105%

The request is made to start automatic regeneration; if regeneration starts, the indicator lights up:



Particulate mass between 105% and 110%

The following light blinks slowly:



The operator must carry out a forced regeneration as far as possible. When regeneration starts, the indicator lights up:



Particulate mass between 110% and 120%

The error code "3254" is reported and the following light comes on (fixed engine light, DPF light, slow blinking):



The torque of the motor is limited by 25%. The operator must start the service regeneration manually as soon as possible.

Continuing to use the tractor, further delaying the execution of the regeneration, may damage the particulate filter.

If the engine fault light does not go out after the regeneration has been completed, contact an authorized GOLDONI workshop.

Particulate mass over 150%

The error code "3253" is reported and the following light comes on (blinking engine light, DPF light flashing fast):



The engine torque is limited to 50%. Automatic and manual regeneration are disabled. The operator must contact an authorized GOLDONI workshop as soon as possible.

Continuing to use the tractor, further delaying the execution of the regeneration, may damage the particulate filter. The particulate filter should be cleaned, or replaced, when the particulate matter percentage exceeds 150%.

5.2.2.2 Automatic regeneration

Regeneration duration: 20-30 min. depending on the driving cycle.

Factors that enable regeneration:

- Refrigerant temperature > 25°C
 - Engine ignition time > 10s
- Engine speed > 950 rpm

Automatic regeneration is interrupted if:

- Engine at idle > 90s
- Overrun time > 180s (guide in release, example: downhill)
- Temperature DPF In > 700°C
- Regeneration inhibitor button (optional)

The regeneration is blocked for 2 hours if the duration of the regeneration > 30 min, for example in the case of a very unfavorable driving cycle.

5.2.2.3 Manual service regeneration

Regeneration duration: 30-40 min. at 2000 rpm.

Manual regeneration is initiated by the operator and is activated if:

- Refrigerant temperature > 40°C
- Accelerator pedal or knob < 5%.
- Hand brake pulled
- Battery > 9V
- Amount of particulate matter between 20% and 120%.
- Regeneration can be activated throught the dedicated button by pressing it for 2 seconds.



If the regeneration is not activated, contact an authorized GOLDONI workshop.

Manual regeneration is interrupted if:

- Refrigerant temperature > 40°C
- Accelerator pedal or knob > 5%.
- Battery <9 V
- Amount of particulate matter < 20% or > 120%.
- Hand brake off

5.3 Transmission controls


5.3.1 Hand Throttle

Warning

Use the throttle by hand only when you want to work with a constant number of engine revolutions. Do not use it when driving on the road.

The hand throttle allows you to manually control the engine speed while keeping them constant.


Place the lever fully down to have the minimum engine speed. Push it up gradually to increase engine speed.



The hand throttle allows you to manually control the engine speed while keeping them constant.

Turn the knob counterclockwise to have the minimum number of engine revolutions. Turn the knob clockwise gradually to increase engine speed.

If the knob is left in a position other than the minimum, the next time it is turned on, it must be returned to the minimum position in order to use it, otherwise it will not accelerate.



Fia. 5.21

5.3.2 Pedal accelerator



Warning

When using the pedal accelerator, it is recommended that the hand throttle be placed completely at the bottom by hand with the engine at idle speed.

Pressing the accelerator pedal cancels the position of the Hand throttle. By releasing the pedal, the engine returns to the speed established by the hand throttle

Press the pedal to increase the speed. Release the pedal to decrease it.




Fig. 5.22

5.3.3 Gearbox clutch pedal



danger

NEVER face a slope with the clutch disengaged.



Warning

Do not work with your foot resting on the clutch pedal in order to avoid premature wear of the clutch disc.



Warning

A prolonged disengagement of the clutch causes wear of the thrust bearing.

With the pedal at the top, the clutch is engaged and transmits motion between the engine and the transmission. Depress the pedal (1) to disengage the clutch. Release it to reengage the clutch.




Fig. 5.23

5.3.4 Shuttle lever

The lever allows you to select the direction of travel for the tractor:

- Forward: lever in position (F)
- Neutral: lever in position (N)
- Reverse: lever in position (R)

To select the direction of travel, it is necessary to: stop the tractor, press the clutch pedal, select the desired direction of travel, and finally release the clutch pedal gradually.




Fig. 5.24





Never reverse the direction of travel with the tractor moving otherwise the transmission could be damaged.

5.3.5 Range selection

Three different working ranges can be selected with the range selection lever, giving 12 speeds in each direction of travel.

To switch from one range to another, it is necessary to: stop the tractor, disconnect the transmission clutch by pressing the pedal, select the desired range by acting on the lever, and finally gradually release the clutch pedal.






5.3.6 Gear lever


With the gear lever, it is possible to select four different synchronized gears in forward and reverse gears. The selections are synchronized. Each gear is identified by a number on the handle.

With the lever in the central position, no gear is engaged (Neutral position).

To switch from one gear to another, it is necessary to disconnect the transmission clutch by pressing the pedal and select the desired gear, then gradually release the clutch pedal.

The lever can take four positions (plus the neutral position):






5.3.7 Mode selection

This model has two positions for transmission: H - High - normal gears

L - Low - reduced gears (-20%)

To switch from one range to another, it is necessary to: stop the tractor, disconnect the transmission clutch by pressing the pedal, select the desired range by acting on the lever, and finally gradually release the clutch pedal.

To select gear L (slow low-speed) move the lever (1) forward.




To select H gear (High-normal gears) move the lever (1) backward.



Note

The 20% reduction is achieved only in forward gear, that is, with the shuttle disengaged.



5.3.8 Differential lock

The rear differential locking system is installed in the rear axle of the vehicle and allows the rear wheels to be locked so that they rotate together.

It is particularly useful when plowing or when one of the two-wheel drive is in poor grip conditions due to muddy, rough, slippery terrain.



To optimize the effect, insert the differential lock before the wheels start to slip. Do not insert the lock while a wheel is already sliding.



Warning

The differential lock inserted prevents the Tractor from steering.

Do not use the differential lock near and at curves, and avoid using it with fast gears and with a high speed motor.



Warning

If the wheel sinks into the ground, reduce the engine speed before inserting the differential lock so as to avoid damaging the gearbox.



danger

Do not use the differential lock at speeds above 10 km/h.

The differential lock system is controlled by the button (1) located on the right side of the operator seat.

To activate the differential lock, press the button (1). The relevant indicator light (2) will start flashing on the display

To deactivate the differential lock, press the button (1) in the opposite direction. The light (2) on the display will go out.




Fig. 5.29

5.3.9 Dual traction

The use of 4WD allows increased traction while the tractor is running.



For safety reasons, the 4WD is always engaged when the tractor is off or stationary with the parking brake engaged or the service brake pedals depressed.

By starting the tractor, the 4WD remains on or switches off according to the operation mode set.

Engaging 4WD should ALWAYS be done by depressing the clutch pedal and bringing the engine to idle rpm with the wheels of the vehicle stopped.

The 4WD system allows access to terrain with greater inclinations. Operating on greater inclinations greatly increases the risk of tipping. Therefore, pay close attention to how the tractor is used and the maneuvers to be performed.



Warning

The use of 4WD greatly increases tire wear. It is not recommended to use it while driving on roads or on particularly hard ground.

The 4WD system has a number of modes of operation. Button (1), located to the right of the operator seat, controls mode selection: pressing it allows you to scroll through the available operating modes until the desired one is selected.





Fig. 5.30

The following table summarizes the modes of operation of 4WD.


Sequence	Modes functional	Description	Warning light dashboard	Icon display
1	DISABLED (2 2 Wheel Drive	Not inserted	Off	Off
2	PERMANENT	Engageable only below 18 km/h, remains engaged at all times, at any driving speed	Lit.	Off
3	AUTO	From 0 to 12 km/h it engages and remains engaged until 18 km/h, beyond which it automatically disengages. Once disengaged, if you decelerate, it will automatically reengage if your travel speed drops to 12 km/h or less.	the 4WD is switche d on; otherwise	Lit.
-	-	Whichever mode is selected, 4WD engages automatically when the brake pedals are pressed together; if they are pressed separately, it will not engage.		Off

Double pull selection procedure.

- When the tractor is off, the 4WD is always engaged. Turning the ignition key to the ON position automatically selects the DISABLED operation mode.
- Press and hold the clutch pedal (2).
- Pressing button (1) selects the PERMANENT mode of operation.
- Pressing button (1) again switches to the AUTO operation mode.
- Finally, pressing button (1) once more returns to the DISABLED operation mode, and so on in a cyclic sequence.
- Slowly release the clutch pedal (2) after selecting the desired mode.







5.4 Braking system

5.4.1 Service brake

The service brakes can be used independently or when simultaneously connected with appropriate pin. If independent brakes are used, you can press the left pedal (1) to lock the left wheel and the right pedal (2) to lock the right pedal.




Fig. 5.33

To use the brakes simultaneously on both wheels, pair the pedals with the connecting pin (3). Press the pedals to brake on both wheels at the same time.




Fig. 5.34



Note

Avoid braking abruptly except in situations of extreme necessity.

Braking smoothly will increase safety and decrease brake wear and tear, increasing their lifespan.



Warning

Acting on the brake pedals automatically engages the IST system of Simultaneous Front Traction Engagement, which disengages when the brake pedals are released.



danger

Check the efficiency and proper functioning of the brakes before starting the tractor.

Always pair the brake pedals with the connecting pin when driving on the road.



danger

Don't keep your foot on the brake pedals when you don't need to.


If you experience excessive pedal loosening during braking or you reach end position freely:

- Don't set the tractor in motion.
- Identify the cause immediately and eliminate the defect.
- If you are unable to remedy it, contact an authorized GOLDONI workshop immediately.

For optimal brake operation , there must be oil in the brake circuit. Before any operation, check that the oil level is within the minimum limits for operation as shown in the figure.

If the oil level is too low, refill the tank. Check the brake oil circuit for leaks before driving.

The tank is located behind the right dashboard case.



5.4.2 Parking brake

The parking (or park) brake is controlled by lever (1).

To insert the parking brake, press the service brake pedals deeply, pull the lever (1) upwards, then release the pedals. The brake is inserted is indicated when the red light on the instrument panel comes on.





Fig. 5.36





danger

Insert the parking brake every time you leave the driver's seat.



Warning

Before starting the drive, make sure that the parking brake has been disengaged and the appropriate light on the display is off.



danger

Do not use the parking brake as a replacement for the brake system.

5.5 PTO

The PTO is a rotating shaft to which implements for particular processing uses can be connected.



For safety reasons, it is not possible to start the engine with the PTO in motion.



Warning

If you are not using the rear PTO, move the mode selection lever to the Neutral position. This prevents the PTO shaft and other rotating organs from being accidentally rotated.



danger

Do not remove or damage the sheet metal carter.



danger

When the PTO is not used, the shaft must be covered with the appropriate protection.




danger

If equipment with high inertia (for example, lawn mowers, etc.) is connected to the PTO, use a cardan transmission with a "free wheel" device. This device avoids the transmission of motion from the equipment to the tractor, allowing the immediate arrest when the clutch is pushed.

5.5.1 Rear PTO

The rear PTO can be used in two modes (Ground Speed or Independent) and two speeds (540 rpm or 750 rpm).

Turn the cover (3) clockwise to unlock it, then remove it. (3) making it fit with the locking pins and turning it counterclockwise to lock it.





danger

- PTO ENGAGED LEVER UPWARD
- PTIO DISENGAGED LEVER DOWN

Abruptly releasing the clutch lever can cause the tractor to respond dangerously.



Warning

The lever should remain positioned downward for the shortest possible time and only as long as is strictly necessary for speed and mode selection.


Keeping the PTO clutch lever positioned downward can cause serious damage to the clutch.

The PTO mode selection lever (3) has 3 positions:

- Ground Speed PTO-right lever (S);
- Neutral center lever (N)
- Independent-left lever (I).

Select Ground speed mode by moving the lever (3) up. Select Independent mode by moving the lever (3) down.

When you have finished machining, remember to return the lever (3) for PTO mode selection, to the Neutral (neutral) position.






Fig. 5.40

The PTO speed selection lever (4) has 2 positions:

- fast 750 rpm. (or 1000 rpm if di- sponible) lever upward (A).
- slow 540 rpm. downward lever (B);




Fig. 5.41

The tractor is equipped with a safety system that stops the engine when the operator get up from the seat while the rear PTO is active.

When the operator gets up from the seat while the PTO is active, an alarm buzzer is activated and the PTO light (L) on the dashboard starts to flash: if the operator sits back within 6 seconds, the light (L) and the buzzer turn off; otherwise, within 7 seconds the engine stops, the buzzer goes off but the light (L) continues to blink because the PTO is still on.


When the engine stops after 7 seconds have elapsed, it is necessary to carry out the normal engine starting procedure (see the "Starting and arresting the Engine" section), then reactivate the PTO following the procedures described in this section. It is not possible to reactivate the engine (and the PTO) automatically only by sitting in the tractor seat.



danger

The engine stops (thus disconnecting the PTO) after about 7 seconds from the moment the operator gets up from the seat. During this period of time, an audible signal (buzzer) indicates that the PTO is still operating.

To keep the PTO running even when the operator gets up from the seat, it is necessary to activate the "PTO Auto" mode by pressing the button (5) twice within 2 seconds after inserting the PTO; the icon (L) is displayed on the display.



The "PTO Auto" mode is deactivated once the operator sits back in the seat.

PTO operating logic

If the PTO is active and the operator gets up from the car seat, the alarm buzzer sounds and the warning light

- PTO (1) starts flashing. If the operator sits back then the buzzer goes off.

If the PTO is deactivated, the alarm buzzer is not activated. If the engine is turned off for safety reasons, the buzzer goes off.

When the engine is turned off for safety reasons concerning the P.D.F. (for example, the operator gets out of the car seat) then the P.D.F. indicator light (1) is flashing.

When the engine is turned off for safety reasons related to the P.D.F., it is necessary to turn the engine back on and re-insert the P.D.F. from the beginning. It is not possible to reactivate the engine and PTO automatically only by sitting in the tractor seat.

If a malfunction is detected on the seat, an error is shown on the display and the engine shuts off automatically every time the PTO is inserted.



Fig. 5.43

5.5.2 - Front PTO engaged (if available)

The front PTO can be used in Independent mode at speed 1000 rpm.

The Socket by PTO front comes operated by the switch (1).

Disconnect the PTO: press the switch (1) once.

Press it again to disengage the PTO.





Fig. 5.44



The tractor is equipped with a safety system that stops the PTO if the operator were to get up from the seat while the PTO is active.

When the operator gets up from the tractor seat while the PTO is active, an alarm buzzer is activated and the PTO light (L) on the dashboard starts to blink: if the operator resides within 7 seconds, the light (L) and the buzzer turn off; otherwise, within 7 seconds the PTO stops, the buzzer goes out but the light (L) continues to flash because the PTO is still on.


When the PTO stops after the 7 seconds have elapsed, turn off and reinsert the power switch (1) to reactivate the PTO It is not possible to reactivate the PTO automatically only by sitting in the car seat.



danger


The PTO comes off after about 7 seconds from the moment the operator gets up from the seat. During this period of time, an audible signal (buzzer) indicates that the PTO is still operating.

To keep the PTO running even when the operator gets up from the seat, it is necessary to activate the "PTO Auto" mode by pressing the button (3) twice within 2 seconds after inserting the PTO; the icon (L) is displayed on the display. The "PTO



Auto" mode is deactivated once the operator sits back in the seat

Turn the cover (3) clockwise to unlock it, then remove it. (3) making it fit with the locking pins and turning it counterclockwise to lock it.



PTO operating logic

If the PTO is active and the operator gets up from the car seat, the alarm buzzer sounds and the warning light


- PTO (1) starts flashing. If the operator sits back then the buzzer goes off.

If the PTO is deactivated, the alarm buzzer is not activated. If the PTO stops following protection, the buzzer goes off.

When the PTO is deactivated for safety reasons (for example the operator gets out of the car seat) then the PTO indicator light (1) is flashing.

When the PTO stops for safety reasons, it must be re-inserted through the switch (2) to reactivate it. It is not possible to reactivate the PTO automatically only by sitting in the car seat.

If a malfunction is detected in the car seat, an error is shown on the display and the PTO is permanently deactivated.



5.5.3 PTO Speed

РТО	540	750 (540E)	1000	1000
location	Rear	Rear	Rear	Front
Direction of rotation	Clockwise	Clockwise	Clockwise	Counterclockwise
Туре	Independent	Independent	Independent	Independent
Normalized speed (rpm)	540	750	1000	1000
Engine speed/ PTO Speed (rpm)	4,00 / 1	2-94	2-21	2-3
Speed Engine @ Normalized speed (rpm)	2160	1591,5	2210	2300
PTO speed/wheel speed ratio (rpm)	5,27 1	7,15 1	10,19 1	-

5.5.4 Cardan Joint

For the rules of safe use and maintenance relating to some components of the tractor built by third parties, consult the specific booklet.



Warning

For the correct functioning of the cardan joint and to avoid damage to the components and protectors, keep in mind that the technically possible inclination of the cardan joint depends on the size and shape of the PTO carters, as well as on the shape and size of the cardan and its protective devices. Therefore, the possible inclination of the cardan joint may vary.



danger

Use only cardan joints equipped with adequate protection.

Rear lift

This is a 3-point rear hydraulic lift with controlled by hydraulic spool valve.

The following conditions of use are possible:

- Controlled position
- Controlled effort
- Floating operation
- Mixed regulation

The lift is operated by two levers located on the right side of the seat (Fig. 5.49):

- 1 Position control lever
- 2 Draft Control control lever




Fig. 5.49

5.5.5 Position-controlled operation

Controlled position allows the tool to be carried and maintained in a given position, whatever that may be, including the highest and lowest position, whether in or out of the ground.

The use of this function is for implements without wheels and other ground bearing parts and implements equipped with wheels or other ground bearing parts.

- Move the draft control lever (2) to the forward end position.
- Move the position control lever
- (1) according to the desired height. The implement movement is proportional to the position of the lever.

Placing the lever (1) fully in- back will give the maximum lift. With lever (1) fully forward, the lifter will be fully lowered.




Fig. 5.50

5.5.6 Controlled effort operation

By using the draft controlled lift, the tractor's tractive effort can be kept constant regardless of changing working conditions.

The use of this function is for all implements carried by the tractor that have no support on the ground such as skids, wheels, etc.

- Move the position control lever
 (1) fully forward.
- Adjust the desired effort using the draft control lever (2).
- Using the position adjustment lever (1) lifter raise and lower the lifter.






Fig. 5.51




Note

The depth reached by the implement is proportional to the tractive effort determined by the soil texture. The linkage, in this condition, automatically keeps the tractive effort required of the tractor constant.





When working with draft control, the lowering speed of the linkage can be adjusted by acting on the linkage lock adjuster (3).



5.6.3 Mixed position/draft control

The use of this function is for work performed under controlled stress on uneven terrain, during which excessive burial of the implement may occur.

The lifter will operate at draft control, but at the same time it will prevent the implement, encountering areas of soil of lower resistance, from burying itself excessively, resulting in uneven work.

Bury the tool according to the desired working depth in the manner described for "Controlled effort operation."

- Move the position control lever
 (1) fully forward.
- Adjust the desired effort using the draft control lever (2).
- Using the position adjustment lever (1) lifter raise and lower the lifter.
- When the implement has stabilized at the desired depth, move the position control lever (1) backward until the lift arms begin to rise.




Fig. 5.55

To lift and bury the implement, act only on the position adjustment lever (1) lifter.

5.6.4 Floating operation

The use of this function is indicated when you want to release the implement, leaving it free to follow the contour of the ground, using, for example, tillers, tampers, bulldozers, etc.

Position both position control levers (1) and draft control (2) fully forward.




Fig. 5.56


5.6.5 Lift speed and sensitivity adjustment

Tightening the adjusting tap (3) results in a slower rate of lift descent. By unscrewing the same register properly, you have a higher speed of descent of the lift.



Warning


By screwing the flow valve completely, you have the implement locked in both the raised and the lowered position. This provides safety for the transport of implements by road.



5.6.6 Road transport

In the case of road transport with the implement attached to the tractor, it is necessary:

- Fully screw in the adjusting tap (3) of the lowering speed of the lift arms so as to lock them;
- Raise the linkage fully by bringing the position control lever (1) fully back.



5.6 Front lift (if available)

This is a 3-point hydraulic front lift, lift/lower type, controlled by hydraulic distributor. The linkage is operated by one of the front auxiliary valves.

The lifter is controlled by the lever (1) of the front spool valve to which the lifter is connected.

- Lever forward lowering tool
- Back lever = Implement lifting.
- Lever all forward floating position, tool free to follow the contour of the ground




Fig. 5.59

5.7 Hook and towbar

5.7.1 Safety Warnings.



danger

Perform all installation, use, cleaning, and maintenance or adjustment operations with tractor switched off and safely in a stationary position. Wear personal protective equipment during these operations (gloves and safety shoes).



danger

To operate safely, it is necessary to choose the towing device based on the type of trailer or implement that must be towed in compliance with current laws.



danger

The towing device in the highest position can increase the risk of soaring Do not linger in the area between the tractor and the towed vehicle.



danger

Inspect and verify the operation of the implement before each use, to avoid damage and identify worn components. The use of a implement that has damaged, worn or missing components is strictly prohibited.



danger

Do not make any changes or alterations to the implement.



Warining

The implement should only be used by personnel with experience in the use of these types of tractors. The instructions described here should be consulted. Registration and maintenance operations must be carried out by authorized and qualified personnel.



Warining

The driving ease of the tractor also depends on correct use and subsequent adjustment of the height of the towing device.



Warining

When using a trailer equipped with synchronized traction, keep the drawbar as horizontal as possible.



Warining

The tractor is equipped with a front rescue hook to carry out any emergency trailer maneuvers or to tow the tractor if necessary.

Front rescue hook

The tractor is equipped with a front rescue hook to carry out any emergency trailer maneuvers or to tow the tractor if necessary.

- A Version with front ballast holder
- B Version with front lift



Warning

Use the front tow bar only for emergency towing of the tractor.

The direction of towing must coincide with the longitudinal axis of the tractor.

Use only for permitted purposes and methods.



ATTENTION:

The maximum speed allowed for towing a tractor is 10 km/h.

The presence of an operator on the towed vehicle is necessary to perform the necessary maneuvers.




Fig. 5.60



Note

When the tractor is not running, higher steering force is required.

To prevent damage to the transmission and hydraulic system, make sure you have:

- differential lock disconnected;
- gear and range selection levers in a neutral position;
- 4WD disengaged;
- parking brake off.

5.7.2 Rear tow bar

Rear tow bar

Proceed as follows.

- Remove the bushings (1) and the fixing pins (2) to unlock the hook. Adjust the hook to the appropriate height for the trailer drawbar eye, then reinsert the pins (2) and the handles (1) to lock it in place.
- Remove the eye-connecting pin (3) and move back with the tractor until the hook is correctly aligned with the trailer drawbar eye.
- Reinsert the connecting pin (3) into the hook and make sure that the protective cap (4) against accidental disengagement is inserted.




Fig. 5.62

Sliding trailer hitch support

Category	-
Vertical adjustment	-
Pin diameter (mm)	-





Fig. 5.63


CEE-X sliding rear trailer hitch (D.28)

Category	CEE-X
Vertical adjustment	Slider
Pin diameter (mm)	28




CEE-Y sliding rear trailer hitch (D.43)

Category	CEE-Y
Vertical adjustment	Slider
Pin diameter (mm)	43




CEE sliding rear trailer hitch (D.31)

Category	CEE
Vertical adjustment	Slider
Pin diameter (mm)	31



CEE fixed rear trailer hitch (D.31)

Category	CEE
Vertical adjustment	Pins
Pin diameter (mm)	31



CEE-X fixed rear tow hook (D.28)

Category	CEE-X
Vertical adjustment	Pins
Pin diameter (mm)	28




Fig. 5.68

CEE-Y fixed rear trailer hitch (D.43)

Category	CEE-Y
Vertical adjustment	Pins
Pin diameter (mm)	43





Fig. 5.69

5.7.3 Tow bars


Rear tow bar CEE-X (D.28)

Category	CEE-X
Length (mm)	850
Pin diameter (mm)	28



CEE rear tow bar (D.31)

Category	CEE
Length (mm)	850
Pin diameter (mm)	31



5.8 Trailer towing



danger

The braking space increases with the speed and weight of the towed load. Proceed slowly and keep an additional amount of time and distance for safe stopping.



danger

The total towed weight must not exceed the combined weight of the tractor, ballast and operator. Use counterweights or ballasts on the wheels as described in the implement or tractor operator's manual.



danger

Towing too much load can cause loss of traction and loss of control on slopes. Reduce the towed weight when operating on slopes.



danger

Never allow children or others to be carried in or on the towed implement



danger

Use only approved hooks. Tow only tractor equipped with a homologated towing hook. Towed implement must be attached only to the approved Hitching system.



danger

If it is not possible to back down a climb with a towed load, it means that the slope is too steep to work with the towed load. Reduce the towed load or give up work.



danger

Never drive downhill with clutch in neutral.



danger

Do not stay in the area between the tractor and the towed vehicle.



danger

Do not make abrupt turns. Pay special attention when making turns or operating on surfaces in difficult conditions. Use caution when going reverse.



Warining

If equipment reduces visibility of turn signals or other lights on the back of the tractor, use additional lights.



Position the hook at the correct height based on the characteristics and weight of the load to be towed.




Fig. 5.72

5.8.1 7-pin trailer socket

The seven-pin socket allows you to connect lights, turn signals and other electrical devices to a trailer or equipment.

If equipment reduces visibility of turn signals or other lights on the back of the tractor, use additional lights.




Fig. 5.73

Terminal function:

- 1 Left turn signal
- 2 Free
- 3 Mass
- 4 Right turn signal
- 5 Right tail light
- 6 Stop Lights
- 7 Left tail light




Fig. 5.74

5.9 Three point linkage



danger

Make any adjustment to the three-point linkage or the implement with the engine turned off, with the key unplugged and the equipment grounded.

Stay out of the engagement zone when controlling the three-point linkage.



danger

Do not use the third point linkage as a towing attachment.



danger

During transfers with mounted equipment, tension the chains and keep the lift up.



danger

Never work under a implements held up only by the hydraulic lift, but always lock it securely with a suitable support and turn off the engine.



The value of the maximum load allowed by the lift is only indicative. The weight of the implements to be lifted must be lower than the maximum liftable load as the distance from the three point linkage at which the tool's center of gravity is placed also significantly affects.

The weight increases significantly as the distance increases.

The tractor is equipped with the three-point attachment system.

To achieve proper operation of the lift, carefully check the construction dimensions of the implements that must be attached to the tractor.

These must have the same standard as the tractor's three point linkage to prevent, during work, being subjected to irregular stresses due to incompatibility in dimensions.

5.9.1 Rear three-point linkage

Cat. 1 and 1N.

The three-point linkage consists of the following organs:

- 1 third pointArm
- 2 Mechanical/hydraulic adjustable tie rod
- 3 Side stabilizer
- 4 Lift lower arm
- 5 Implement attachment terminal




Fig. 5.75

5.9.1.1 Third point arm support

The third-point arm support has four holes to facilitate attachment and proper inclination of the implement, also determines the sensitivity of controlled effort to be chosen according to the type of implement.

To adjust the third point, remove the forelock from the pin , remove the pin from the brackets, place the third point at the height of the desired hole, put the pin and the forelock back.

When choosing the fixing hole for the third point, keep in mind that:

- Placing it in the upper hole will result in lower sensitivity (indicated with tools that produce high stresses):
- Placing it in the lower hole will result in higher sensitivity (indicated with light equipment).




Fig. 5.76



Warning

When transporting, place the third point on the highest hole to prevent breaking of the oscillating support.

Three-point linkage adjustment



danger

This adjustment must be made when the tractor is stopped with the engine off and the parking brake on.

5.9.1.2 Third pointArm

Adjustable terminal implement attachment:

- - Category 1 and category 2 spherical kneecap

Adjust the length of the arm (third point) to change implement inclination in relation to the ground.

Rotate the third stitch to the desired length using the lever (1).

The implement attachment ball (2) has two holes so that it can be used as category 1 or category 2.

To lock the third point to the desired length, screw the ring (3).

If the third point is not in use, hook the spring (4) to the fixed support (5).




Fig5.77

5.9.1.3 Hydraulically adjustable third-point arm (if available)

Adjust the third-point arm (1) to the desired length using the lever on the rear distributor to which it is connected:

- Lever forward = arm extension
- Lever back = arm shortening

The hydraulically adjusted third-point boom (1) is available in two configurations:

- Hydraulic adjustment third point arm, category 1-2
- Hydraulically adjustable third-point arm with quick hook





Fig. <u>5.78</u>

5.9.1.3.1 Hydraulic adjustment third point arm, category1-2

The implement attachment ball (1) has two holes so that it can be used as category 1 or category 2.



Hydraulically adjustable third-point arm with quick hook

5.9.1.3.2

The implement attachment ball (1) has two holes so that it can be used as category 1 or category 2.

Equipment attachment lever (2).




Fig. 5.80

5.9.1.4 Adjustable vertical tie rods

Adjust the tie rod to be able to level and align the lower arms of the lift depending on the equipment used and the type of work to be performed.


For crank-adjustable tie-rods:

- Lift up the hook (1);
- Turn the crank (2) to lengthen/shorten;
- Lower the hook (1) to lock the cranck (2).

For adjustable tie rods without a crank:

- Remove cotter pin (4) and remove pin and plate (3);
- Body wheel to lengthen shorten;
- Reinsert pin, plate (3) and cotter pin (4).
 - Plates (3) in vertical position = swing enabled
 - Plates (3) in horizontal position = swing locked

After making the adjustment, check that with the lift completely up, the implement is not being lifted more than necessary, and with the lift down, the implement has the opportunity to make a further run downwards.







Fig. 5.82

Fig. 5.81

5.9.1.5 Hydraulically adjusted right vertical linkage (if available)

Adjust the tie rod to the desired length using the lever on the rear distributor to which it is connected:

- Lever forward = tie rod extension
- Lever back = shortening tie rod



5.9.1.6 - Side stabilizer

Adjust the side stabilizers (1) to limit the lateral movement of the lower linkage arms. Screw or unscrew the stabilizer by the handle until the desired swing is achieved.

- 50-60 mm oscillation for plows, rolling harrows, etc.;
- 10-50 mm oscillation for leveling blades, hoes, etc.;
- 0 mm oscillation for transporting equipment not at work.

Operating Instructions

- Lift hook and remove pin;
- Rotate body to lengthen/shorten;
- Insert pin in desired hole then close the hook.





Fig. 5.84



5.9.1.7 Adjustable lower arms

To adjust the lower arms, remove the two safety pins from the two pins (1) and adjust the arms to the correct length. Once the arms are adjusted, re-insert the two pins (1) and their pins to lock them in place.




Fig. 5.86


5.9.1.8 Adjustable terminal implement attachment:

Adjust the width of the attachment terminals

- (1) by unscrewing the bolt (3) and sliding them to coincide with the existing holes on the lower arms, until the desired widths are obtained. Screw the bolt
- (3) to lock them in place.

The kneecap balls (2) are equipped with reduction to be able to be used as category 1 or category 2.

Implement attachment lever (4).



5.9.2 Front three-point hitch (if available)

The three-point linkage consists of the following organs:


- 1 third pointArm
- 2 Implement attachment terminal

5.9.2.1 Three-point linkage adjustment

The third point arm support has two holes to facilitate the attachment and correct inclination of the implement.

To adjust the third point, remove the forelock from the pin , remove the pin from the brackets, place the third point at the height of the desired hole, put the pin and the forelock back.

This adjustment must be made when the tractor is stopped with the engine off and the parking brake on.



5.9.2.2 third pointArm

Adjust the length of the arm (third point) to change implement inclination in relation to the ground.

- 1 Unscrew the ring nut (2);
- 2 Adjust the length of the arm by turning the lever (1);
- 3 Tighten the ring nut (2) fully to lock the arm.

RULES OF USE





Fig. 5.90

5.9.2.3 - Implement attachment terminal

Equipment attachment pin (1).



5.10 Hydraulic spool valves



danger

When detaching and reattaching implements, use the maxium care.



danger

Always wear gloves and safety glasses to protect your eyes.

The release of hydraulic fluids under pressure can be so violent that it penetrates the skin. Hydraulic control fluid can also cause cuts in the skin. In the event of injuries caused by fluid spillage, seek immediate medical attention. Otherwise, you risk serious infections and skin reactions. Never control a hydraulic fluid leak with your hands, but use a piece of wood or cardboard.



danger

It is essential to check the tightness of all connecting devices and the condition of the flexible hoses and pipes before putting the system under pressure. Take the pressure off completely before disconnecting the pipes or before performing other types of work on the hydraulic system.


The tractor is equipped with additional hydraulic spool valves for controlling external hydraulic cylinders.

The spool valves are equipped with 1/2" NPTF female joints complete with rubber protectors. Various types of spool valves can be installed:

- simple effect;
- Double effect
- double effect with detent;
- double effect with floating

These spool valves are connected, through pipes, to special hydraulic outlets located on the rear or front right side depending on the equipment of the tractor. The color of the hydraulic outlet cap corresponds to the control lever of the same color.

The control levers (1) of the mechanical rear spool valves are placed on the right side of the driver's seat and control the hydraulic sockets (2) located on the rear side.



Control levers (3), located on the front right side of the driver's station, control the front hydraulic outlets (if available).




Fig. 5.93


Depending on the versions of the hydraulic spool valves installed, the control levers perform the following functions:

- **Single-acting hydraulic spool valve control lever**: with the lever in the raised position, the jack extends, with the lever in the lowered position, the jack retracts due to the mass of the installed implement.
- Single-acting hydraulic spool valve control lever with connection in a floating position: with the lever in the raised position, the jack extends, with the lever in the lowered position, the jack retracts due to the mass of the installed implement The floating function allows you to follow the soil profile with the implement
- **Double-acting hydraulic spool valve control lever: with** the lever in the raised position the jack extends, with the lever in the lowered position the jack retracts.
- **Double-acting hydraulic spool valve control lever with connection: with** the lever in the raised position the jack extends, with the lever in the lowered position the jack retracts. The locking function allows you to keep the spool valve lever in a raised position.
- Double-acting hydraulic spool valve control lever with spring lever return: the locking function allows you to keep the spool valve lever in position. The spring lever return function (KICK-OUT) allows the engagement function to be automatically disinhibited (unhooked), returning the lever to the neutral position once the set maximum pressure has been reached.
- Floating double-acting hydraulic spool valve control lever: with the lever in the raised position the jack extends, with the lever in the lowered position the jack retracts. The floating function allows you to follow the soil profile with the implement




Warning

Check the oil level in the transmission frequently to ensure smooth operation of the hydraulic circuit.



The quick coupling marked by the black-colored plug allows "free return" of the external tool oil directly to the gearbox housing.




5.11.1 Equipment available

5.11.1.1 Mechanical rear auxiliary spool valves

These tractor models are equipped with up to three rear spool valves

location	Туре
Α	Double effect
В	Double effect con fourth floating position
С	Double effect with locking and KICK-OUT



The lever (A) identified with black color controls the rear spool valve with black color quick couplings.

By pulling the lever (A) upwards, the oil will cross the hydraulic outlet (A1), so as to allow the jack to be extended.

By pulling the lever (A) downward, the oil will pass through the quick coupling (A2) so that the jack can retract.

The locking function allows you to keep the spool valve lever in a raised position. The spring lever return function (KICK-OUT) allows the engagement function to be automatically disinhibited (unhooked), returning the lever to the neutral position once the set maximum pressure has been reached.





Fig. 5.98

The lever (B) identified with the color blue controls the rear spool valve with blue-colored quick couplings.



By pulling the lever (B) upwards, the oil will cross the hydraulic outlet (B1), so as to allow the jack to extended. Pulling the lever (B) down will cause the oil to pass

retract.

Depending on the set-up, the spool valve is used to control the front linkage. Refer to the specific section for a description of operation.

The green-colored lever (C) controls the rear spool valve with green-colored quick couplings.

Pulling the lever (C) upward will cause the oil to pass through the quick coupling (C1) so that the jack can be extended. Pulling the lever (C) down will cause the oil to pass through the quick coupling (C2) so that the jack can retract.




Fig. 5.101




Fig. 5.102

5.11.1.2 Diverter (if available)

Switch (1) alternately activates the quick couplings (C1-C2) or (D1-D2), depending on its position.

When switch (1) is pressed a toward the seat side, quick couplings (C1) and (C2) are activated.

The lever (C) controls the active quick couplings.





Fig. 5.103

When switch (1) is pressed toward the opposite side seat, quick couplings (D1) and (D2) are activated.

The lever (C) controls the active quick couplings.



5.11.1.3 Front auxiliary distributors (if available)


These tractor models are equipped with two mechanical front spool valves: one double-acting and one double-acting with a floating function. The spool valves are controlled by the corresponding levers.

The orange-colored lever (A) controls the front spool valve with orange-colored quick couplings.

Pulling the lever (A) will cause oil to flow through the quick coupling (A1) so that the jack can be extended.

Pushing the lever (A) will cause the oil to pass through the quick coupling (A2) so that the jack can retract.

Floating function: The spool valve is equipped with a floating function.






Depending on the set-up, the spool valve is used to control the front linkage. Refer to the specific section for a description of operation.

Gray-colored button (B) controls the front spool valvewith gray-colored quick couplings.

By pulling the lever (B), oil will flow through the quick coupling (B1) so that the jack can be extended.

Pushing the lever (B) will cause the oil to pass through the quick coupling (B2) so that the jack can retract.



5.11 Hydraulic trailer brakes (if available)

danger

When a trailer equipped with hydraulic braking is attached to the tractor, the brake pedals must always be coupled with the appropriate hitch (1).





Fig. 5.107

When the tractor hand brake is engaged, press and hold button (2) to disengage the trailer parking brake. Release the button (2) to reactivate the trailer parking brake.



5.11.1 Hydraulic trailer brakes - Single-line type CUNA

Trailer hitch

After connecting the trailer to the tractor trailer hitch, proceed as follows.

- Apply the handbrake of the tractor and arrest the engine.
- Connect the hydraulic trailer braking connection to the coupling (1).



Make sure that the connection of the fittings has been made correctly.

- Connect the electrical wiring of the trailer to the socket (2).





Fig. 5.109

- Disconnect the solenoid wiring harness (Y4).



Warning


Check that the generic warning light (L15) does not light up on the dashboard.



- After starting the engine, depress the brake pedals to charge the trailer hydraulics.
- The indicator light on the side console
 (4) signals improper pressure on the trailer brake valve when the hand brake is off.
- The indicator light (3) indicates the activation of the turn signals.



The indicator light (4) comes on only when the engine is running.



Tractor stop and trailer detachment

Fig. 5.111

Proceed as follows.

- Stop the tractor by following the procedure described in the appropriate section.



Warning

Wait 10 seconds before arresting the engine after engaging the hand brake to allow the trailer parking brake to engage.

- Apply the trailer's mechanical parking brake (if equipped). Possibly place wedges to stop the wheels.
- Disconnect the hydraulic fittings and electrical connection of the trailer.

5.11.2 Hydraulic trailer brakes - Single-line France

Trailer hitch

After connecting the trailer to the tractor trailer hitch, proceed as follows.

- Apply the handbrake of the tractor and arrest the engine.
- Connect the hydraulic trailer braking connection to the coupling (1).



Make sure that the connection of the fittings has been made correctly.

- Connect the electrical wiring of the trailer to the socket (2).





Fig. 5.112

- Connect the electrical wiring of the solenoid (Y4).



Warning

Check that the generic warning light (L15) does not light up on the dashboard.



- After starting the engine, depress the brake pedals to charge the trailer hydraulics.
- The indicator light on the side console
 (4) of the dashboard signals a wrong pressure on the trailer brake valve when the handbrake is disengaged.
- The indicator light (3) indicates the activation of the turn signals.



The indicator light (4) comes on only when the engine is running.




Fig. 5.114

Tractor stop and trailer detachment

Proceed as follows.

- Stop the tractor by following the procedure described in the appropriate section.



Warning

Wait 10 seconds before arresting the engine after engaging the hand brake to allow the trailer parking brake to engage.

- Apply the trailer's mechanical parking brake (if equipped). Possibly place wedges to stop the wheels.
- Disconnect the hydraulic fittings and electrical connection of the trailer.

5.11.3 Hydraulic trailer brakes - Dual-line M.R.

Trailer hitch

After connecting the trailer to the tractor trailer hitch, proceed as follows.

- Apply the handbrake of the tractor and arrest the engine.
- Connect the hydraulic trailer brake fittings to the couplings (1) and (2).



Make sure that the connection of the fittings has been made correctly.

- Connect the electrical wiring of the trailer to the socket (3).





Fig. 5.115

- Connect the solenoid wiring harness (Y4).



Warning

Check that the generic warning light (L15) does not light up on the dashboard.



- After starting the engine, depress the brake pedals to charge the trailer hydraulics.
- The indicator light on the side console
 (5) of the dashboard signals a wrong pressure on the trailer brake valve when the hand brake is disengaged.
- The indicator light (4) indicates the activation of the turn signals.



The indicator light (5) comes on only when the engine is running.




Fig. 5.117

Tractor stop and trailer detachment

Proceed as follows.

- Stop the tractor by following the procedure described in the appropriate section.



Warning

Wait 10 seconds before arresting the engine after engaging the hand brake to allow the trailer parking brake to engage.

- Apply the trailer's mechanical parking brake (if equipped). Possibly place wedges to stop the wheels.
- Disconnect the hydraulic fittings and electrical connection of the trailer.

5.12 Wheels and track width

RULES OF USE



danger

The replacement of tires must be carried out by qualified personnel with suitable implements and appropriate technical skills.

The operation could cause serious and fatal injuries, if not performed according to these indications.



danger

The tire may explode during inflation if damaged or if the wheel is not intact or correctly matched.



Warning

Replace tires that are damaged, injured, or bulging immediately.




Warning

Check periodically that the tires are at the correct pressure, verifying the data with the instructions provided by the manufacturer related to the use of the tractor.

Follow the following instructions for using, maintaining, and replacing tires:

- choose tires suitable for the use of the tractor, in the recommended combinations;
- use tires suitable for the expected workload;
- do not exceed the speed shown on the tires;
- check the tightening of the nuts of newly installed tires after 3 hours of work;
- periodically check the tightening of the nuts, the regular consumption of the tread and the absence of damage, swelling or injury;
- consult specialized technicians if a tire suffers violent shocks or is injured;
- do not park your tires on hydrocarbons (oils, grease, diesel...) so as not to damage them;
- tires mounted on tractors in storage can age faster, lift the tractor off the ground and protect them from direct sunlight.
 - 1 Tire
 - 2 Channel
- 3 3 Connecting bracket
- 44 Circle (or disc)



5.12.1 Tire inflation




danger

Always keep the tire inflation at the correct pressure value. Never exceed this value, as excessive pressure may cause the tire to explode. Using inflated tires with incorrect pressures can have even deadly consequences.

Inflating tires to the right pressure is essential to ensure their safety and durability. Incorrect inflation pressure involves the following risks:

- Insufficient pressure causes premature and irregular wear and damage, significantly shortening the life of the tire. In addition, a flat tire can cause steel bead.
- Excessive pressure reduces the tire's resistance to shocks, increasing the probability that it will develop bulges and deformations, which can also affect the wheel and result in the tire bursting.




- 1 Correct pressure
- 2 Excessive pressure
- 3 Insufficient pressure

Pressure control

The pressure check must be carried out regularly, at least every 15 days, in particular if the tires are weighted with liquid.

Check when tires are cold because the pressure is altered by overheating. The tires are cold if they have not been used for at least 1 hour.





Never reduce the inflation pressure while the tires are hot.

When checking the tire pressure, position yourself outside the possible trajectory of the valve or cap.

Avoid overloading the tractor when track width has been enlarged



The load on the axles varies the inflation pressure.

5.13.2 Tire puncture



danger

Stop driving immediately if the tire is flat, as a result of a puncture, or any other cause.

If there are no safety conditions for immediate arrest, as in the case of road travel, it is necessary to identify the nearest parking area.

Repair and replacement operations must be carried out by authorized and qualified personnel.

The wheel replacement procedure is described in the 'Wheel Replacement' section.

5.13.3 Wheel replacement



Warning

If the user replaces the wheelset with one of a different size, go to an authorized dealer to insert the new wheel parameters into the vehicle control unit so that the real speed matches the one shown on the display.

To replace the wheel, proceed as follows.




danger

Repair and replacement must be carried out by authorized and qualified personnel, equipped with the appropriate equipment.

Make sure other people are at a safe distance during the operation.

- 1 Remove the wheel ballasts, if installed.
- 2 Lift up the tractor. See the 'Lifting points' section in the 'General Safety Regulations' chapter, for instructions on lifting the tractor safely.
- 3 Completely deflate the tire of the wheel you want to replace.
- 4 Unscrew the wheel fastening nuts to the drive shaft, then remove the wheel.
- 5 Install the new wheel, then screw in the nuts/fixing screws using the correct tightening torque.
- 6 Lift down the tractor.





Warning

After the first 10 hours of work elapsed since the wheel was reassembled, check the clamping torques by rescrewing the wheel screws, using an appropriate torque wrench.

Tightening torques

The following table indicates the tightening torques for fixing the wheels to the hubs (driveshaft).

Wheel	Tightening torque
Front wheel	148 N-m (14.8 kg-m)
Rear wheel	310 N-m (31 kg-m)

5.13.4 Adjusting the Track Width

Only use the tractor if the wheels, rims and flange are securely attached. Screw bolts and nuts to the specified tightening torque.

The various types of agricultural operations may require different Track widths.

A simple variation of the Track width is obtained by fixing the wheel to the axle shaft (4) with the concave part facing inwards or outwards, reversing the position of the wheels on the axle in order to keep the vertices of the tread facing in the direction of travel.

If the wheels are equipped with an adjustable rims, it is also possible to remove the rim (2) from the flange (1) and reassemble it in a different orientation. The connecting brackets (3) are decentralized with respect to the axis of the flange (1), allowing different track width to be determined depending on the replacement configuration. This adjustment is not available for fixed rims, since rim (2) and flange (1) are a single piece.

Not all possible track width are feasible in practice, the tire may have insufficient space.




Fig. 5.122



Warning

When adjusting the track width, make sure that the tread remains oriented correctly for the forward direction. The orientation of the tread is indicated by an arrow on the side of the tire.



Warning

Use an appropriate lifting tool to support the wheels and wear appropriate protective clothing.

Work on one wheel at a time and move on to the next only after you have completely fixed the previous one.

Check the maximum steering angle



Warning

Once the track adjustment is complete, the maximum steering angle must be checked.

Proceed as follows.

- Lift the front end above the ground so that the front axle can reach maximum oscillation. See the 'Lifting points' section in the 'General Safety Regulations' chapter, for instructions on lifting the tractor safely.
- Start the engine and steer until the end of the steering wheel stroke, both in the right and left directions.
- Make sure that the tires (or the fenders, if they are steering) remain at least **2 cm** away from the body (or from the fenders, if fixed).

If this distance is not respected, the **steering angle must be adjusted** and, if necessary, the front fenders must be adjusted (see the "Front fenders" section).

5.13.4.1 Connection between disc and flange

In variable track wheels, it is possible to vary the track width by disassembling the wheels (or discs) from the channel and reassembling them in a different orientation. The disc is fixed to the channel by bolts screwed into special brackets.

There are different types of brackets for connecting the disc to the flange.

Types of connecting brackets

Blocchetto	Ring (circular)	
Zeta	Omega	Te I li
Omega double	H.D Omega	
Waffle	-	-

Tightening torques for adjustable rims

The following table shows the tightening values of screws and nuts securing the rim to the channel, for available rims.

Wheel rim	Tightening (N-m)
DISC R. 7K X 12	N/A
DISC R. 8K X 16 REG.	112
DISC R. W10 X 20 REG.	250
DISC R. W11 X 20 REG.	250
DISC R. W10 X 24 REG.	250
DISC R. 8J X 15	N/A
DISC R. W12 X 24 REG.	250
DISC R. W8 X 20 REG.	112
DISC R. W10 X 24 REG.	250
DISC R. W9 X 18 REG.	250

5.13.4.2 **Track Width**

Axle width

'Axle width' means the altitude between the coupling planes of the axles (without wheels).

Front deck width (A): 1322 mm Rear deck width (B): 1260 mm





Fig. 5.123

Track width for rear tires




- A Internally assembled flange B Externally assembled flange

Speed radius index (mm)	Tire	Wheel rim	A1 (mm)	A2 (mm)	A3 (mm)	A4 (mm)	B1 (mm)	B2 (mm)	B3 (mm)	B4 (mm)
S65 - S80										
500	360/70R20	W11x20	1014	1248	1104	1338	1134*	1368	1224	1458
500	320/85R20	W10x20	1041*	1221	1131	1311	1161	1341	1251	1431
500	41/14.00R20	W11x20	-	1281*	-	-	1159	-	-	-
525	320/70R24	W10x24	1044*	1098	1134	1188	1284	1338	1374	1428
525	380/70R20	W11x20	1014	1248	1104	1338	1134*	1368	1224	1458
550	360/70R24	W12x24	-	1080*	1152	1170	1302	1320	1392	1410
Q80										
450	320/70R20	W10x20	-	1221	1131*	1311	1161	1341	1251	1431
450	340/65R20	W11x20	-	1248	1104	1338	1134*	1368	1224	1458
500	320/85R20	W11x20	-	1248	1104	1338	1134*	1368	1224	1458
500	360/70R20	W11x20	-	1248	1104	1338	1134*	1368	1224	1458
500	420/65R20	W11x20	-	1248	-	1338	1134*	1368	1224	1458
525	320/70R24	W10x24	-	1098	1134	1188*	1284	1338	1374	1428
525	380/70R20	W11x20	-	1248	1104	1338*	1134	1368	1224	1458

^{* -} Default (Factory) track width

Track width for front tires



A - Internally assembled flange B - Externally assembled flange

Speed	Tire	Wheel rim	A1	A2	A3	A4	B1	B2	B3	B4
radius index (mm)			(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)	(mm)
S65 - S80										
350	240/70R16	8Kx16	1081†	1274	1142	1335	1121*	1314	1182	1375
330	11.0/65R12	7Kx12	-	-	1146*	-	-	-	-	1306
330	27/10.50R15	8Jx15	-	-	1202	-	-	-	-	1254*
370	260/70R16	8Kx16	1081†	1274	1142	1335	1121*	1314	1182	1375
Q80										
370	260/70R16	8Kx16	1163	1356	1224	1417	1203*	1396	1264	1457
380	280/70R16	8Kx16	1163	1356	1224	1417	1203*	1396	1264	1457
400	280/70R18	W9x18	1171*	1251	1261	1341	1279	1359	1369	1449
425	320/65R18	W9x18	1171*	1251	1261	1341	1279	1359	1369	1449
425	260/70R20	W8x20	1122	1288	1212*	1378	1242	1408	1332	1498

^{* -} Default (Factory) track width

Carriages lower than the factory track width may require the steering angle to be adjusted and the front fenders (if any) removed, if any.

5.13.5 Steering angle adjustment

The tractor is delivered with the steering characteristics optimized according to the original equipment tires set.

By changing the track width, the tires can come into contact with the body, when the wheels are in the maximum steering position. To correct this problem, it is necessary to act on the appropriate registry screws.



Warning

The procedure must be carried out by qualified personnel, equipped with the appropriate equipment.



Warning

The registration procedure must be done with the axle in the maximum travel position (on a wedge first for one wheel and then for the other).

Proceed as follows.

- Steering the wheels.
 - Screw or unscrew the safety bolt (1) until a distance of at least 2 cm is determined between the tire and the body.
 - Once the correct distance has been obtained, lock the safety bolt registration by fully screwing the lock nut (2).

Do the above for both front wheels.

Once the entire procedure is complete, check again that there is a distance of at least 2 cm between the tire and the body, on both sides.




Fig. 5.126

5.13 Front fenders

The front fenders provide greater safety and help protect the tractor from excessive dirt.

Depending on the tires fitted and the track width established (see related section), it may be necessary to adjust the position of the fender to maintain proper clearance between it and other tractor components.

5.13.1 Fender rotation angle adjustment

It is possible to adjust the maximum rotation width of the front fenders. This adjustment is made by changing the position in the slot of the adjusting screw (1) relative to the retaining bracket (2):

- Positioning the screw (1) at the farthest point to the stop (2), as shown in (A), will allow the fender the maximum amplitude of rotation;
- Positioning screw (1) adjacent to retainer (2), as shown in (B), prevents the fender from rotating, effectively locking it in a position parallel to the engine:
- Positioning the screw (1) at an intermediate point ensures partial rotation between the two extremes described above.

Each of the front fenders has its own adjustment screw, so adjustment should be done on both.





Fig. 5.127

5.13.2 Horizontal adjustment


You can adjust the horizontal position of the fender in relation to the bracket (1): unscrew the fender attachment bolts located at the slots (2), then reposition the fender to the desired horizontal width and reattach it to the bracket (1) by retightening the bolts.



5.14 Ballasts

5.14.1 Front ballasts (optional)


If very heavy implements attached to the linkage are used that may unbalance the tractor, front cast-iron ballasts can be attached. Each ballast has a weight of 20 kg, and up to 5 ballasts can be installed.



To mount or dismount ballasts:

- Unscrew the bolt (1);
- Pull out the pin (2);
- Pull out the cotter pin (3) and spring (5);
- Pull out the pin (4) from the opposite side of the disassembled cotter pin (3);
- Insert or remove the ballast plates on the front support blade;
- Secure the plates with the appropriate tie rods;
- Reinsert the pin (3), spring (5) and cotter pin (4).
- Reinsert the pin (2);
- Screw the bolt

Make sure the ballasts are locked and the bolt is tightened, before using the tractor.



5.14.2 Liquid ballast (not for road traffic)

The ballast of the drive wheels is obtained by introducing water into the tires.



Warning

The installation of the liquid ballast requires special equipment and training. Contact your authorized dealer or a tire dealer.



Warning

NEVER fill a tire more than 90%. Excess fluid could damage the tires.



Warning

Preferably use wheels with air chambers.

In the case of using wheels with tubeless tires, ask your dealer for proper lubrication of the disc to prevent it from rusting.



Warning

In case of low temperatures, use water with antifreeze solutions.



Warning

Do not use alcohol as liquid ballast.



danger

Limit transport speed to 32 km/h (20 mph) when using liquid ballast.

To introduce water:

- place the valve at the top;
- carefully unscrew the movable valve connection;
- introduce water with a special tool;
- interrupt the filling from time to time to allow air to escape;
- fill the front tires to 40% or 75% depending on the need for ballast; fill the rear tires up to 40% at most;
- screw the movable valve connection;
- perform air inflation up to normal operating pressure.




Warning

All axle tires must be filled to the same level.

To extract water:

- place the valve at the bottom;
- carefully unscrew the movable valve connection;
- let the water drain;
- complete the emptying through a special connection site with a hose (dip tube);
- perform air inflation until the water is completely emptied;
- screw the movable valve connection;
- perform air inflation up to normal operating pressure.



6 : Service

Index

6.1	Maint	tenance interval tables	6-3
	6.1.1	Maintenance interval tables	6-4
	6.1.2	Engine technical maintenance operation	6-5
6.2	Gener	ral maintenance and inspection	6-7
	6.2.1	Opening the bonnet	6-7
	6.2.2	Refueling	
	6.2.3	Engine oil level and fuel control	6-9
	6.2.4	Engine Oil Filter Cartridge Replacement	6-10
	6.2.5	Engine oil replacement	6-11
	6.2.6	Screw tightening and connection sealing control	6-13
	6.2.7	Car body maintenance	6-13
	6.2.8	Checks and controls on the engine	6-14
	6.2.9	Air filter cleaning and replacement	6-14
	6.2.10	Service brake pedal height control and registration	6-16
		Clutch pedal stroke control and recording	
	6.2.12	Engine idle speed control	6-18
	6.2.13	Clutch check and adjustment Power take-off rear	6-18
		Seatbelt check	
	6.2.15	Circuit separation oil	6-19
	6.2.16	Air intake circuit and intercooler hose	6-19
6.3	Maint	enance of the coolingsystem	6-20
	6.3.1	Cleaning the cooling system	6-21
	6.3.2	Engine coolant level control	6-22
	6.3.3	Cooling circuit sleeve control	6-22
	6.3.4	Deaeration of the cooling circuit	6-23
	6.3.5	Engine coolant replacement	6-23
6.4	Power	r system maintenance	6-24
	6.4.1	Fuel filter replacement	6-24
	6.4.2	Power supply circuit bleed	6-25
	6.4.3	Checking and replacing fuel hoses	6-25
	6.4.4	Bleeding sediment from the fuel tank	6-26
	6.4.5	Fuel tank maintenance	6-26

6.5	Electr	ical system maintenance	6-27
	6.5.1	Battery	6-28
	6.5.2	Alternator belt control	6-29
	6.5.3	Poly-V alternator belt maintenance	6-29
	6.5.4	Lights	6-29
	6.5.5	Fuses and Relays	6-35
6.6	Maint	tenance of the hydraulic system of the tractor	6-38
	6.6.1	Front axle maintenance	6-39
	6.6.2	Maintenance of gearbox, traction transmission and final drive	6-40
	6.6.3	Front axle maintenance	6-41
	6.6.4	Suction hydraulic filter maintenance	6-42
	6.6.5	Hydraulic supply filter maintenance	6-42
	6.6.6	Maintenance of the hydraulic system of the tractor	6-43
6.7	Cab N	Naintenance	6-45
6.8	Lubrio	cation and greasing points	6-49
6.9	Techn	nical maintenance in case of long-term storage	6-51

6.1 Technical maintenance intervals

See the table for the parts subject to maintenance, the items affected, and the maintenance period.

Warning

Carry out any operation with the engine off and at room temperature.



Warning

Refueling and oil level control must be carried out with the engine in a horizontal position.



Warning

Before each start-up, to prevent oil spills, make sure that:

- the oil level rods are inserted correctly;
- are properly tightened:
 - oil drain plugs;
 - the oil supply plugs.



Note

After servicing, cleaning, or repairing the tractor, reassemble all protective cases or plates before starting it.

6.1.1 Maintenance interval tables

		Replacement interval									
Group	Intervention description	Hours	50	150	300	500	900	900	1.200	4.000	8.000
		Months	12		12	24	12	24	24		
	Engine Oil (1) (2)					Х					
	Engine oil filter (1)					Х					
	Fuel Filter					Х					
	Coolant								Х		
	Air filter clog sensor							Х			
Engine (3)	Engine Air Filter - External				Х						
	Engine Air Filter Safety					Х					
	Particulate Filter									Х	
	Partial Review Of the Engine									x	
	Engine Total Review										Х
	Cabin Air Filter				Х						
	Check Clut ch pedal stroke recording control			х							
	Filter Tra nsmission Oil Filter - Delivery			X (*)		х					
Transmission	Filter Tra nsmission Oil Filter - Suction					x					
	Transmission Oil - Rear final drives						x				
	Olio Front Axle						Х				
Brakes	Brake Oil						Х				
	Rear Lifter		Х								
Lubricatia:-	Front Axle		Χ								
Lubrication	Leverage O		X								
	f braking			1							1
	Greasers		Χ								<u> </u>

^(*) First time only.

- (1) In harsh working conditions, such as dusty environments and operation at extreme loads, replace every 150 hours.
- (2) Every time the engine oil light comes on, it is necessary to replace the oil even if the scheduled hours have not passed.
- (3) Routine engine maintenance (after run-in), referring to constant daily engine activity. For maintenance during the run-in phase, consult the appropriate section.

6.1.2 Engine technical maintenance operation



The maintenance operations on the engine are indicated below. For detailed operations, see the specific sections.

Maintenance during run-in phase (first 50 hours)

Frequency (1)	Component	Type of intervention	Intervention methods
Every 10 hours (every day)	Engine Oil (2)	Level control	Refil, if necessary
	Coolant (3)	Level control	Refil, if necessary
	Air filter	Cleaning control	Clean with low-pressure compressed air
		Control of the clogging indicator placed on the filter body	Clean the filter or, if necessary, replace it with a new one
	Engine and vehicle cooling system (radiators, intercoolers, fan)	Cleaning control	Clean with a soft bristle brush and/or low pressure compressed air

- (1) In the event of a lack of meter, the frequency of interventions must be calculated according to the calendar day: a calendar day corresponds to 12 hours of operation.
- (2) In harsh working conditions, such as dusty environments and operation at extreme loads, effet-Change the engine oil every 150 hours of operation. If the engine has not been running for the specified time, it is still necessary to replace the oil at least once a year.
- (3) If the engine has not been running for the time indicated, it is still necessary to replace the liquid at least every 24 months.

Routine maintenance (after run-in)


Frequency (1)	Component	Type of intervention	Intervention methods	
	Engine Oil (2)	Level control	Refil, if necessary	
Every 10	Coolant (4)	Level control	Refil, if necessary	
		Cleaning control	Clean with low-pressure compressed air	
hours (every day)	Air filter	Control of the clogging indicator placed on the filter body	Clean the filter or, if necessary, replace it with a new one	
	Engine and vehicle cooling system (radiators, intercoolers, fan)	Cleaning control	Clean with a soft bristle brush and/or low pressure compressed air	
F	Air filter	Main cartridge replacement	-	
Every 300 hours	Cabin Air Filter	Replacement	-	
	Engine Oil (1)	Replacement	-	
	Engine oil filter (2)	Replace the cartridge	-	
	Fuel filter (3)	Replacement	-	
Every 500	Air intake circuit and intercooler hose	Check neatness and pipe sealing	-	
hours	Oil separation circuit	Pipeline tightness check	-	
	Vacuum circuit	Pipeline tightness check	-	
	Valve a with TVA suction	Cleaning control	Contact ad an authorized workshop	
Every 900	Fuel tank	Cleaning the fuel tank and checking the efficiency of the load cap	-	
hours	Air filter	Replacement Of the indicator clogging	1	
Every 1200 hours	Coolant (4)	Replacement	-	
Every 4000 hours	Particulate filter	Carry out the regeneration	Contact ad an authorized workshop	
	Engine	Carry out the partial review	Contact ad an authorized workshop	
Every 8000 hours	Engine	Carry out the general review	Contact ad an authorized workshop	

- (1) In the event of a lack of meter, the frequency of interventions must be calculated according to the calendar day: a calendar day corresponds to 12 hours of operation.
- (2) In harsh working conditions, such as dusty environments and operation at extreme loads, effet-Change the engine oil every 150 hours of operation. If the engine has not been running for the specified time, it is still necessary to replace the oil at least once a year.
- (3) If the engine has not been running for the time indicated, it is still necessary to replace the filter at least every 12 months.
- (4) If the engine has not been running for the time indicated, it is still necessary to replace the liquid at least every 24 months.

6.2 General maintenance and inspection

6.2.1 Opening the bonnet

Insert an appropriately sized Allen key (1) into the appropriate hole, then turn clockwise to release the lock.



6.2.2 Refueling



danger

Refuel strictly when the engine is off.

All fuels are flammable. Leaking and falling fuel on hot surfaces and electrical components can cause fire. Do not smoke when you are filling up or when you are in that area.



ATTENTION:

Do not fill the tank completely, but keep about 1 cm from the maximum level, to allow some movement of the fuel. Before starting the engine, wipe off any fuel spills.




Warning

The use of fuels with specifications other than those indicated is prohibited.

Avoid using fuel mixed with water or other substances so as not to cause engine damage.

To refuel, use a funnel to prevent fuel spills. During refueling, make sure that the fuel does not contain residues, otherwise use special filters.

Use a quality fuel with technical characteristics set out in the 'Lubricants, Fuels and Coolants' section, in the 'Technical Specifications' chapter.



Engine oil level and fuel control



ATTENTION:

Protect your hands because the oil and the control rod, if too hot, could cause burns.



Warning

Do not disperse polluting material into the environment. Carry out the disposal in compliance with the laws in force on the subject.

The engine oil level control rod (1) is located on the lower right side of the engine.

- Turn on the engine and bring it to operating temperature (70÷80 °C).
- Turn off the engine and unplug the ignition key.
- Place the engine perfectly flat.
- Wait a few minutes for all the oil to drain into the cup.
- Take out the rod (1) and check the oil level. If the level is close to or below the minimum reference (MIN), refill.




Fig. 6.3


- Refill, if necessary, from the cap (2). When refilling the oil, to avoid exceeding the maximum value allowed, introduce the oil in small quantities (100÷200 ml at a time) until the correct level is reached.



Warning

The oil level must be between the minimum (MIN) and maximum (MAX) references indicated on the rod (1).

Don't mix oils of different brands or characteristics.



6.2.3 Engine Oil Filter Cartridge Replacement



Exhausted engine oil can cause skin cancer if left in contact repeatedly and for extended periods. If contact with oil is unavoidable, wash your hands thoroughly with soap and water as soon as possible.



Warning

Do not disperse polluting material into the environment. Carry out the disposal in compliance with the laws in force on the subject.

Proceed as indicated.

- Turn off the engine and unplug the ignition key.
- Allow the engine to cool down properly, to avoid the risk of sunburn.
- Prepare a collector to contain any leaks.
- Unscrew the filter (1) and replace it.
- Check the condition of the seal (2) and, if necessary, replace it.
- Lubricate the new cartridge seal before installing it.
- Install the oil filter.



Warning

Screw the oil filter with a tightening torque of 12.7 $N \cdot m$.




Fig 65

- Turn on the engine and keep it at idle speed for a few minutes until it reaches operating temperature (70÷80°C).
- Turn off the engine and unplug the ignition key.
- Wait a few minutes for all the oil to drain into the cup.
- Check the correct oil level and, if necessary, refill. When refilling the oil, to avoid exceeding the maximum value allowed, introduce the oil in small quantities (100÷200 ml at a time) until the correct level is reached.



Warning

The oil level must be between the minimum and maximum references of the oil level rod.

- Check for oil leaks.



Warning

If oil leaks, stop the engine immediately and contact an authorized GOLDONI workshop.

6.2.4 Engine oil replacement



Protect your hands because the oil and the control rod, if too hot, could cause burns.



Exhausted motor oil can cause skin cancer if left in contact repeatedly and for extended periods. If contact with oil is unavoidable, wash your hands thoroughly with soap and water as soon as possible.



Warning

Do not disperse polluting material into the environment. Carry out the disposal in compliance with the laws in force on the subject.

ALWAYS place a liquid collection container under the tank to be drained, at the discharge point.



Warning

The oil must be replaced with the engine in a horizontal position.

Proceed as indicated.

- Turn off the engine and unplug the ignition kev.
- Allow the engine to cool down properly, to avoid the risk of sunburn.



Note


Do not allow the engine oil to cool completely.

- Set up a collector of adequate capacity under the oil pan.
- Unscrew the load cap (2).
- Unscrew the drain plug (1) and allow all the oil to drain into the collector.
- Replace the copper seal and screw back the drain plug (1).



Warning

Tighten the cap (1) with a tightening torque of 55 N⋅m (5.5 kg⋅m).



- Introduce the new oil through the drain plug (2).

To reach the correct engine oil level, enter the minimum amount of oil depending on the engine model (see "Lubricants, Fuels and Coolants"). Then fill it up.

When refilling the oil, to avoid exceeding the maximum value allowed, introduce the oil in small quantities (100÷200 ml at a time) until the correct level is reached.



Warning

The oil level must be between the minimum and maximum references of the oil level rod.

- Rescrew the load cap (2).
- Turn on the engine and bring it to operating temperature (70÷80 °C). Check for any oil leaks.
- Turn off the engine.
- Wait a few minutes for all the oil to drain into the cup.
- Check the oil level.




Fig. 6.7



Warning

If oil leaks, stop the engine immediately and contact an authorized GOLDONI workshop.

6.2.5 screw tightening control and connection tightness;

Proceed as indicated.

- Start the engine and keep it at idle speed for a few minutes.
- Keep the engine running until it reaches the operating temperature (70÷80°C).
- Turn off the engine and allow it to cool down.
- Check the tightening of the fastening screws of the main organs.
- Check the tightness of the connections on the power supply circuit.
- Check the tightness of the clamps.
- Check for fluid leaks.

The tubes are checked by exerting a slight squeeze or bending, along the entire length of the tube and near the fixing clamps.

The components must be replaced if they have cracks, cuts, leaks and do not retain a certain elasticity.



Warning

If the components are damaged, contact an authorized GOLDONI workshop.

6.2.6 Car body maintenance



ATTENTION:

When using pressurized water jets, do not direct the jet to:

- Electrical system components
- TYRES
- Hydraulic hoses
- Radiator
- Electrical organs
- Soundproofing gaskets
- Other organs that can be damaged by water pressure

Periodically check the condition of the body shop. To ensure durability over time, deep abrasions and scratches must be treated by specialized personnel. Check any areas of water stagnation.

Clean the body with normal water solutions and specific shampoo:

- If necessary for tractor use in normal environments.
- Frequently for use in marine areas.
- Immediately after the use of organic or chemical substances.

The fenders and bumpers should be cleaned regularly and any muddy sediment removed.



Note

Do not disperse liquids such as fuels, lubricants, refrigerants, various fluids in the environment.

6.2.7 Checks on the engine

The list shows some of the maintenance, verification and control activities to be carried out on the engine during normal operation:

- power supply circuit purge;
- screw tightening control and connection tightness;
- engine oil level control;
- engine coolant level control;
- belt tension check;
- engine oil change;
- coolant change;
- oil filter cartridge change;
- fuel filter change.
- particulate filter cleaning.

6.2.8 Air filter cleaning and replacement



For every maintenance operation, the engine must be turned off and cool.



Use protective safety glasses when using compressed air.

On the instrument panel, there is a filter clogging light. Its ignition indicates that the air filter is clogged and it is necessary to proceed with maintenance or replacement.



Proceed as indicated.

- Open the hooks (1) and disassemble the cover (2).
- Clean the filter by means of a jet of compressed air (3 bar maximum) from the inside to the outside.
- Take out the internal filter and clean it with a jet of compressed air.
- Clean the inside of the air filter housing.
- Check that the filter elements are not damaged by using an inspection lamp or by scanning it against the light in an oblique position. If the filter elements should be damaged or worn out, replace them with new ones.
- Reassemble the internal filter.
- Reassemble the external filter and secure it by screwing the bolt.
- Reassemble the cover



Warning

Make sure that the filter is properly mounted to prevent dust or anything else from entering the suction ducts.





Fig. 6.9



Warning

After replacing the external filter (6) two or three times, it is important to also replace the internal filter (7).



6.2.9 Service brake pedal height control and registration



danger

Registration must be carried out exclusively by the dealer or specialized personnel.

Register when:

- The brake pedal stroke is too long or too soft.
- When one of the wheels brakes differently respect to the others.
- When braking distances increase compared to the same conditions of use.

The height between the pedal and the platform is 21,



Note

Contact the authorized workshop to make the adjustment.





Fig. 6.11

Once the adjustment has been made, grease the inner bushings using the indicated grease nipples located in front of the dual drive assembly.



6.2.10 Clutch pedal stroke control and recording



danger

Registration must be carried out exclusively by the dealer or specialized personnel.

Periodically check the free stroke of the command. The free stroke must be kept within the specified interval. If the free stroke found does not fall within this interval, the clutch pedal must be registered

Rops and SG1/1 cab versions


0	Note
The figure is indicative.	

Starting stroke (A)	195 mm
Clutch release start (B)	220 mm
Limit switch (C)	360 mm
Free stroke	15 ÷ 25 mm

GL9 cab versions

Note
The figure is indicative.

Starting stroke (A)	165 mm
Clutch release start (B)	190 mm
Limit switch (C)	330 mm
Free stroke	15 ÷ 25 mm



6.2.11 Engine idle speed control

Check that the knob (1) is turned completely counterclockwise and make sure that the engine speed stabilizes at idle speed. Otherwise, contact an authorized workshop.





Fig. 6.14

6.2.12 Clutch check and adjustment Rear power take-off

Periodically check the free stroke of the command. The no-load travel of the lever should be no more than 20 mm. If increased stroke is found, adjustment of the rear PTO clutch lever must be performed.



To access the adjustment screws, the side closure flap must be removed. Act as follows to register the lever:

- To change the no-load stroke, screw or unscrew the adjusting nut (1).
- To change the end position, start or unscrew the screw (2).

Once the control stroke meets the specified dimensions, registration is completed.



danger

Registration must be carried out exclusively by the dealer or specialized personnel.




Fig. 6.16

Replace the clutch when necessary, at an authorized workshop and using only an original replacement part.



danger

Registration must be carried out exclusively by the dealer or specialized personnel.

6.2.13 Seatbelt check

Check the seat belt and the locking elements at least once a year. If the belt has cuts, breaks, excessive or abnormal wear, faded, rusty, scratched spots, or the elastic ring or wrapping device is damaged, it must be replaced immediately. For your safety, when replacing the belt, use only the accessories provided for this tractor.

6.2.14 Oil separation circuit

For the control and maintenance of the oil separation circuit, contact an authorized workshop.

6.2.15 Air intake circuit and intercooler hose

For inspection and maintenance of the air intake circuit and intercooler tube, contact an authorized workshop.

6.3 Cooling system maintenance



ATTENTION:

The radiator must not come into contact with acidic, basic or corrosive substances.




During winter, check the antifreeze concentration regularly according to temperature conditions.

Before starting the engine, check the coolant level in the radiator (1) to see if a refill is necessary and check that there are no leaks.

Check that the radiator cover is attached.

Check regularly for weeds, dirt, grease, or other contaminants on the radiator core and, if present, remove them.

Check that the thermostat constantly offers good performance, otherwise the circulation of the cooling water will be occluded, with a consequent reduction in the cooling effect.



6.3.1 Cleaning the cooling system



ATTENTION:

For every maintenance operation, the engine must be stopped and cool.

Do not open the radiator expansion tank with a hot engine, as the coolant is under pressure and at a high temperature, with a consequent risk of burns.



ATTENTION:

Use protective safety glasses when using compressed air.




Warning

Avoid using a pressure washer to clean the cooling system, because it could damage the components.

Clean with a soft bristle brush, making sure to remove weeds and debris.

Using a jet of compressed air (maximum pressure 3 bar), blow from the inside to the outside.



Fia. 6.18

6.3.2 Engine coolant level control

Proceed as indicated.

- Turn on the engine and bring it to operating temperature (70÷80 °C).
- Turn off the engine and unplug the ignition key.
- Allow the engine to cool down properly.
- Check that the coolant level in the tank (2) is higher than the minimum level mark (MIN).
- Top up the cap (1) if the liquid level is below the notch (MIN).



Open the cap (1) carefully to release the pressure.

- Once the refilling is finished, screw the cap (1) back on and tighten it tightly.




Fig. 6.19



Do not fill the tank (2) above the level indicated, the coolant must have the necessary space to expand when the temperature increases.



Warning

For the amount and type of liquid, see 'Lubricants, Fuels, and Coolants'.

6.3.3 Cooling circuit sleeve control


Proceed as follows.

- Squeeze the tubes (1) to assess their wear, and check the tightness of the clamps (2).
- Tighten the clamps (2) if the tightening is insufficient.
- Replace components if damaged or if they show signs of wear.



Warning

To make the replacement, contact an authorized workshop.



6.3.4 Deaeration of the cooling circuit

Start the engine without a cap on the radiator or on the compensator tank, and keep it running, at the lowest speed of rotation, to allow the coolant to replace the air bubbles remaining inside the circuit. The liquid level made earlier, will drop more and more until it stabilizes. Stop the engine and refill. After a few hours of operation, when the engine is cold, it is advisable to recheck the coolant level.

6.3.5 Engine coolant replacement

Proceed as indicated.

- Start the engine and keep it at idle speed for a few minutes. The cooling circuit reaches the operating pressure.
- Turn off the engine and unplug the ignition key.



Allow the engine to cool down properly, to avoid the risk of sunburn.

- Unscrew the load cap (1).





Fig. 6.21



Open the cap (1) carefully to release the pressure.

- Screw back the cap (1) and tighten it tightly.
- Turn on the engine and keep it at idle speed for a few minutes until it reaches operating temperature (70÷80°C).

If the liquid level decreases, top up to keep it constant between the reference notches.

- Turn off the engine and allow it to cool down properly.
- Check the coolant level and, if necessary, top up.



Warning

Do not disperse polluting material into the environment. Carry out the disposal in compliance with the laws in force on the subject.

6.4 Power system maintenance



danger

All fuels are flammable.

Leaking and falling fuel on hot surfaces and electrical components can cause fire. Do not smoke or use open flames during operations to avoid explosions or fires.



danger

The vapors generated by the fuel are highly toxic, carry out operations only outdoors or in well-ventilated environments.

Do not get too close to the cap with your face so as not to inhale harmful vapors.



danger

Do not waste fuel in the environment as it is highly polluting.

6.4.1 Fuel filter replacement



ATTENTION:

If fuel leaks, stop the engine immediately and contact an authorized GOLDONI workshop.




Warning

Do not disperse polluting material into the environment. Carry out the disposal in compliance with the laws in force on the subject. When replacing the fuel filter, keep it separate from other waste.

Proceed as indicated.

- Turn off the engine and unplug the ignition key.
- Allow the engine to cool down properly, to avoid the risk of sunburn.
- Prepare a collector to contain any leaks.
- Disassemble the filter (1) and replace it.
- Fill the new filter with the fuel from the disassembled filter.
- Lubricate the seal (2) of the new filter before installing it.
- Reassemble the filter.
- Purge air from the fuel supply circuit (see "Purging power circuit").
- Start the engine and check for fuel leaks.



6.4.2 power supply circuit purge;



danger

To avoid the risk of fire due to fuel leaks or spills, always carry out the operation with the engine off and cold.



Warning

This operation must be performed after each change of the fuel cartridge.

Proceed as indicated.

Turn off the engine and unplug the ignition key.



ATTENTION:

Allow the engine to cool down properly, to avoid the risk of sunburn.

- Prepare a collector with an adequate capacity.
- Loosen the screw (1).



ATTENTION:

Do not loosen the high-pressure pipe fittings of the fuel supply circuit.




Fig. 6.24

- Manually operate the pump (2) to remove air from the circuit.
- Check that a flow of clean airless diesel comes out of the purge screw (1).



Warning

Take care that all the fuel contained in the filter does not leak out. In this case, remove it, fill it manually and repeat the purge operation.

- Tighten the screw (1).
- Wipe off any fuel residue before starting the engine.

6.4.3 Checking and replacing fuel hoses

Check that the tubes are free from leaks. In the event of leaks, contact an authorized GOLDONI workshop.

6.4.4 Purging sediment from the fuel tank

Park the tractor on a flat area, remove the drain plug (1) under the fuel tank and drain the sediment at the bottom of the tank.



danger

Empty the fuel tank when the tractor is stopped and the engine is cold.

Do not smoke near fuel and during operation.



Warning

Use a hose and funnel to avoid dispersing the fuel that drains out.




Fig. 6.25

6.4.5 Fuel tank maintenance

Clean the area around the tank cap. Replace the tank cap if missing or damaged, with an original replacement.


Check the tank for dents or abrasions. Replace the tank if damaged, with an original part.



Note

The replacement of the fuel tank must be carried out only by the dealer or specialized personnel. Contact an authorized GOLDONI workshop.

If necessary, clean the fuel filter (1) shown in the figure.



6.5 Electrical system maintenance



Keep the battery away from open flames. This is because the gas released from the electrolyte is explosive.

Keep away from vibrations and fire. Before servicing the electrical system, first disconnect the negative cable (-). If you need to disassemble the battery, disconnect the positive cable (+).

After turning off the tractor and placing the key on OFF, wait 2 minutes before disconnecting the battery. If this time is not respected, serious damage can occur to the electronic engine management control unit.



ATTENTION:

The battery electrolyte is corrosive: avoid contact with eyes, skin or clothing. Should the acid come into contact with the eyes, wash immediately with water and go to the hospital as soon as possible, to avoid the risk of permanent injury.

If you use the battery and then store it, check at regular intervals that the exhaust vent works, to prevent the battery from warping or bursting.

When charging and discharging the battery, ensure good ventilation of the environment to evacuate the acid fog and the fuel gases generated during charging: the air coming from outside, in addition to lowering the degree of erosion on people and equipment caused by acid molecules, prevents the ignition of combustible gases.

During charging, the battery temperature must not exceed 45°C. To avoid the risk of explosion, lower the temperature with a water bath, temporarily reduce the charging current or charging voltage.

The environment in which the battery is charged must have good ventilation. This is because the battery releases hydrogen during charging, and if the concentration of hydrogen in the ambient air were to reach $4\% \sim 7\%$, an explosion would occur in the event of a fire. In particular, do not smoke and do not keep open flames in the environment.

When connecting the charging cable, make sure that there is no short circuit, otherwise a fire may develop.



Note

Store the batteries in a dry, clean and well-ventilated place, at a temperature between 5-40°C. Keep them out of direct sunlight and at least 2 m away from heat sources (heaters, etc.). Protect them from rain, dust and other impurities. Avoid external short circuit discharges.

Don't turn them upside down, don't put them in horizontal position. Avoid shocks or stresses caused by other tractor.

The battery must be stored in the fully charged state instead of in the almost empty state. Avoid tilting the battery while installing it, it is strictly forbidden to turn it upside down and bump it.

Check the battery voltage every three months. Charge the battery if the voltage drops below 12.5V, to avoid having to perform an intensive charge after long-term storage, which could reduce the service life of the battery itself.

Check the color of the density meter on the battery cover at regular intervals. Perform maintenance and possible replacement based on color.

Connect the battery anode to the charger anode, the battery cathode to the charger cathode. Don't reverse the links.

Lay down the battery. Secure the charging connections.

6.5.1 Battery

Maintenance-free battery condition check

Installing the battery

To perform maintenance on the battery located in front of the radiator, open the bonnet.

Battery cleaning

When the engine is off, wipe the battery with a damp cloth to clean it. If necessary, clean and tighten the contacts.

Disassembling the battery



Wait **2 minutes** from the moment the tractor is turned off (key in the OFF position). If this procedure is not respected, serious damage can occur to the electronic engine management control unit.



To avoid the risk of fire, first disconnect the negative pole for battery movement and finally connect the negative pole for installation first.

- Disconnect the negative cable first, then disconnect the positive cable.
- Unscrew the bolts (1), then remove the bracket (2) of battery fixing.
- Remove the battery by lifting it slightly and sliding it forward.




Fig. 6.27

Specifications for the replacement battery

To replace the battery, consult your dealer.

Battery voltage: 12 VStarting current: 850 A

Battery charging mode

Normally, the types of charging are divided into constant current charging, limited current charging with constant voltage, etc. For batteries that do not require maintenance, limited-current charging with constant voltage is recommended.

1) Constant current charging

After charging the battery at a voltage of 16 V with a current of 12 A, switch to a current of 6 A to continue charging. The charge ends when the battery voltage stabilizes for 1-2 hours without changes (with a difference between two voltages of *min* 0.03 V), or if the battery is recharged for 3-5 hours at a current of 6 A after the voltage reaches 16 V.

2) Constant voltage charging

14.8 V~15.5 V with constant voltage, the maximum current should not exceed 30 A. Continue charging for 3 hours after the charging current becomes *min* 0.5 A. The total charge time should not exceed 24 hours.

6.5.2 Alternator belt control

Check that the belt has no signs of wear or cracks, if there are these signs of deterioration, the belt must be replaced.

6.5.3 Poly-V alternator belt maintenance

Belt control

Check that the belt has no signs of wear or cracks.

Belt replacement with linear tensioner



Replacing the belt with a linear tensioner involves the use of special implements and must be strictly carried out by competent personnel. Contact an authorized workshop to do this.

6.5.4 Lights

Replacing the low beam headlight bulb

Proceed as indicated.

- Lift the bonnet.
- Disconnect the connector (1).
- Unscrew the nuts (2) and remove the entire headlight from the bonnet.



The nuts (2) secure springs, protect your eyes and make sure you don't lose them.





Fig. 6.28

- Unscrew the screws (3) and remove cover (4).
- Unclip the clip (5) then turn the cover (6) counterclockwise.
- Replace the bulb with a new original component, then screw the cover back on (6) and re-clip the clip (5).
- Insert the cover (4) and secure it by screwing the screws (3).
- Mount the complete light on the bonnet and screw the nuts (2) to secure it.
- Close and secure the bonnet.





Warning

The service must be performed exclusively by specialized personnel equipped with specific implements. Contact an authorized GOLDONI workshop.

Replacing the low beam headlight bulb

Proceed as indicated.

- Lift the bonnet.
- Disconnect the connector (1).
- Turn the cover (2) counterclockwise to remove the bulb.
- Replace the bulb with a new original component, then screw the cover back on (2) and reconnect the connector (1).
- Close and secure the bonnet.





Fig. 6.30

Replacing the bulb of the cabin work lights

- Disconnect the connector (1).
- Turn the cover (2) counterclockwise to remove the bulb.
- Replace the bulb with a new original component, then screw the cover back on (2) and reconnect the connector (1).





Warning

In machines with GL cabs, the wiring harness connection to the bulb is located inside the canopy, so you must first unscrew the canopy fastening screws and lift the canopy up so you can disconnect the wiring harness and replace the bulb.




Fig. 6.32


Rear work projector bulb replacement



Note

This maintenance operation is valid for tractor versions without a cab.

- Take out the lamp holder (1) from the headset (2).
- Unclip the clip (3) and remove the bulb.
- Replace the bulb with a new original component, then re-clip the clip (3) to secure the bulb in place.
- Insert the lamp holder (1) inside the headset (2). Make sure that the headset wraps around the lamp holder evenly.



Replacing the side bulkhead light and side direction indicator

Roll-bar version

Proceed as indicated.

- Unscrew the screws (1) and remove the lamp holder cover (2).
- Unscrew the bulb counterclockwise, pushing it at the same time.
- Replace the bulb with a new original component.
- Reassemble the lamp holder cover (2) and screw in the screws (1) to secure it.





Fig. 6.34

Cabin version


- Unscrew the bolts (1) and remove the lamp holder cover (2).
- To replace the turn signal bulb: unscrew the bulb anti clockwise, pushing it at the same time.
- To replace the bulky light bulb: spread the tabs and pull out the bulb.
- Replace the bulb with a new original component.
- Reassemble the lamp holder cover (1) and screw in the bolt (1) to secure it.



Replacing the tail light, rear turn signal light and stop light

Proceed as indicated.

- Unscrew the bolts (1) and remove the lamp holder cover (2).
- Unscrew the bulb counterclockwise, pushing it at the same time.
- Replace the bulb with a new original component.
- Reassemble the lamp holder cover (1) and screw in the bolt (1) to secure it.



Replacement of ceiling light

(A) A - Cabin GL9

Remove the slide of the ceiling light by levering cautiously with a screwdriver, replace the bulb, perform the function test, and reinstall the slide.

(B) B - Cabin SG1/1

Remove the ceiling light slide by unscrewing the retaining screws with a screwdriver, replace the bulb, perform the function test, and reinstall the slide.





Fig. 6.37

Replacing the driving plate light

Proceed as indicated.

- Unscrew the bolts (1) and remove the lamp holder cover (2).
- Unscrew the bulb counterclockwise, pushing it at the same time.
- Replace the bulb with a new original component.
- Reassemble the lamp holder cover (1) and screw in the bolt (1) to secure it.



6.5.5 Fuses and Relays

Fuses

All electrical circuits are protected by fuses. Each fuse has a label that indicates its amperage. To distinguish between the various types of fuses, use the color code, which allows you to easily select the correct replacement.



Warning

Before replacing a fuse, eliminate the cause that caused the short circuit.




Warning

Do not replace a blown fuse with a fuse with a higher amperage. Otherwise, it could damage the tractor. If the fuse with the correct specifications maintains the same power load but continues to burn out, contact an authorized GOLDONI workshop.

Preheating glow plug relay

It is located on the left side of the engine.


1 Preheating glow plug relay



Fuse box

The electrical circuit is fully protected by a fuse (1).

The fuse box (1) is installed in front of the engine, next to the battery.



The fuse box (2) is installed at the back of the machine, above the quick couplings of the hydraulic spool valves





Fig. 6.41

Fuse functions (1), Figure 6.40:

R1	Main relay	30A
R2	VEHICLE CONTROL UNIT STARTER RELAY	-
R3	ENGINE CONTROL UNIT STARTER RELAY	-
R4	AVAILABLE	-
F1		MAIN ENGI NE CON TROL UNIT FUSE 30A
F2	Engine control unit (battery)	15A
F3	ECU Engine accessories (battery)	10A
F4	AVAILABLE	-
F5	AVAILABLE	-
F6	AVAILABLE	-
F7	Glow plug preheat fuse	80A



Fuse functions (2), Figure 6.41:

	(<u>-</u>), · · · g ··· · · · · · · ·	
F1	Horn, socket, rotating lamp	15A
F2	Right parking light	7.5A
F3	Left parking light	7.5A
F4	High beams	7.5A
F5	LOW BEAM LIGHTS	15A
F6	Right directional lights	7.5A
F7	Left directional lights	7.5A
F8	Right stop light	7.5A
F9	Left stop light	7.5A
F10	3-pin socket	25A
F11	ECU Engine and vehicle control unit (ignition key)	7.5A
F12	Switches and sensors	10A
F13	Lights by emergency - Starter key panel	10A
F14	Dashboard (ignition key)	5A
F15	CIGARETTE LIGHTER	10A
F16	Pneumatic seat	15A
F17	Vehicle ECU (battery)	20A
F18	Dashboard (battery)	7.5A
F19	Lights by emergency and diagnostic socket	15A
F20	TRAILER OUTLET	25A
F29	Front PTO and solenoid valves	10A
F30	3-pin socket (starter key)	10A
R6	LOW BEAM RELAY	-
R7	High beam relay	-
R8	LED DASHBOARD RELAY	-
R9	Stop light relay	-





Fig. 6.43


GL cabin fuse box

The electrical circuit is protected entirely by a power supply fuse (shown in the figure).

It is installed on the right side of the canopy.



Α	Windshield wipers and washers	7,5A
В	Fan switch	20A
	Ceiling lamp	
С	Working projector	15A
D	The fan/heat exchanger compartment	25A
Е	Rear headlamps	10A
F	Beacon	20A



6.6 Maintenance of the hydraulic system of the tractor



Warning

ALWAYS place a liquid collection container under the tank to be drained, at the discharge point.



Warning

Do not disperse liquids such as fuels, lubricants, refrigerants, various fluids in the environment. Dispose of used oil in compliance with current laws and regulations.



Note

Keep the area surrounding the caps clean with the graduated rod.

6.6.1 Front deck maintenance

Oil level control

Park the tractor on level ground then check the oil level through the control plugs (1) and (2), the oil should touch the bottom edge of the hole. If necessary, top up with the recommended type of oil.




Fig. 6.46

Oil replacement

Proceed as indicated.

Drain the oil through the plugs (1) and (2), and if necessary by removing the plate (3) located at the bottom of the gearbox on both front wheels.



Note

To remove the plate (3), the screws that attach it to the gearbox must be unscrewed.


Fill in oil through the plug (1) and plugs (2) located on both front wheels.

Before checking the new level, allow the oil to stabilize.



Warning

To carry out the front axle oil change, it is recommended to contact an authorized GOLDONI workshop.



6.6.2 Maintenance of gearbox, traction transmission and rear differential

Oil level control

Park the tractor flat, then check the oil level in the frame by unscrewing the dipstick

- (1). If the oil level falls below the lower notch (MIN), add transmission oil to the position between the lower notch (MIN) and the upper notch (MAX) on the dipstick
- (1). Run the engine at idle for 5 minutes after the oil has been introduced, before measuring the level.



Do not overfill the box, otherwise it will overheat with subsequent damage to the gearbox.




Fig. 6.48

Oil replacement

Place a collection vessel of adequate capacity under the filter

Lower the outer lift arm of the lifter to drain the oil in the cylinder.

Remove the following plugs to drain the oil:

- 1 Change
- 2 Dual traction
- 3 Rear differential



Note

Dispose of used oil in compliance with current laws and regulations.




Fig. 6.49

6.6.3 Front deck maintenance

Oil level control

Check the oil level through the control plugs. (1) and (2), the oil should graze the bottom edge of the hole. If necessary, top up with the recommended type of oil.




Fig. 6.50

Oil replacement

Drain the oil through the plug (4), and if necessary by removing the plate (3) located at the bottom of the gearbox on both front wheels.



Note

To remove the plate (3), the screws that attach it to the gearbox must be unscrewed.


Fill in oil through the plugs (2) located on both front wheels, and the plug (1).

Before checking the new level, allow the oil to stabilize.



Warning


To carry out the front axle oil change, it is recommended to contact an authorized GOLDONI workshop.



6.6.4 Suction hydraulic filter maintenance

The absorbent suction filter for hydraulic lift oil is located on the left side of the front gearbox, near the engine. The table shows the maintenance period. Proceed as follows.

- Place a collection vessel of adequate capacity under the filter.
- Unscrew the filter cover (1) with an appropriate wrench.
- Take out the filter cartridge. Check that there are no traces of dirt left in the chamber.
- Insert a new original cartridge and screw back the cover (1).





Protect your hands because the oil, if too hot, could cause burns.

6.6.5 Hydraulic supply filter maintenance

The absorbent hydraulic lift oil filter is located on the left side of the front gearbox, near the engine. The table shows the maintenance period. Proceed as follows.

- Place a collection vessel of adequate capacity under the filter.
- Unscrew the filter cover (1) with an appropriate wrench.
- Take out the filter cartridge. Check that there are no traces of dirt left in the chamber.
- Insert a new original cartridge and screw back the cover (1).




Fig. 6.53




Protect your hands because the oil, if too hot, could cause burns.

6.6.6 Maintenance of the hydraulic system of the tractor

Inspection and maintenance of the service brake oil reservoir

The service brake oil reservoir (1) is equipped with a device that detects the level of brake fluid installed in the reservoir cap; if the level is below the normal level, a warning light (2) on the dashboard will come on, indicating that oil needs to be added.



To manually check the oil level of the service brake reservoir (1), proceed as follows.


- Remove the shuttle knob (3).
- Remove the steering wheel using the steering wheel puller.



Note

Steering wheel puller tool: code 07006212.

- Unscrew the screws (4) securing the dashboard (5), then lift the dashboard carefully.
- Check that the oil level in the reservoir
 (1) is higher than the minimum (MIN) mark. If necessary, refill oil with appropriate specifications. Avoid exceeding the maximum (MAX) notch.



Air exhaust from the brakes




danger

In case of abnormal behavior or malfunction of the brake system due to the presence of air in the brake hydraulic circuit, contact an authorized workshop to bleed the air.



If the tractor is equipped with a hydraulic trailer brake valve, bleeding must also be done on the pilot valve block.



6.7 Cabin maintenance

Seatbelt check

Check the seat belt and the locking elements at least once a year. If the belt has cuts, breaks, excessive or abnormal wear, faded, rusty, scratched spots, or the elastic ring or wrapping device is damaged, it must be replaced immediately. For your safety, when replacing the belt, use only the accessories provided for this tractor.

General cabin maintenance

Check for and eliminate any water stagnation in areas covered by mats or seals. Protect

hinges and locks with lubricating and water-repellent products.

Refill the windshield wiper fluid reservoir using appropriate cleaners. In the winter period, check that the liquid has antifreeze properties.

Keep windows and rearview mirrors clean to ensure proper visibility at all times.

Cabin air conditioner maintenance



Do not bring open flames or heat sources near the air conditioning system.



Avoid loosening fittings and/or tampering with pipes as the system is under pressure.



The refrigerant gas can cause skin and eyes to freeze.



ATTENTION

Use protective safety glasses when using compressed air.



Warning

Never work on the air conditioning system yourself, refer it to specialized personnel.

- A Cabin GL9
- B Cabin SG1/1


Clean with compressed air as needed assessing environmental working conditions (dusty, dry, etc.) or at a minimum once a week:


- -The side ventilation grilles of the heat exchanger.
- The fan/heat exchanger compartment



To facilitate cleaning, it is recommended to unscrew the fixing knobs (1) and remove or move the rear grille.

In case of excessive internal dirt on the exchanger or in case the air conditioning system does not work, contact an authorized service center.





GL cabin air filter maintenance

Unscrew the knob (1) securing protection, remove the protection (2), pull out the filter (3) and then clean it: carefully tap it several times, with the perforated part downward, over a hard, flat surface. Blow slowly through all folds, with compressed air at **no more than 7 bar**, in the opposite direction of the arrows printed on the filter itself.



Warning

Replace the filter as needed or at most according to the indicated interval.




Fig. 6.59

SG cabin air filter maintenance

Unscrew the knob (1) securing protection, remove the protection (2), pull out the filter (3) and then clean it: carefully tap it several times, with the perforated part downward, over a hard, flat surface. Blow slowly through all folds, with compressed air at **no more than 7 bar**, in the opposite direction of the arrows printed on the filter itself.



Note

There are two filters in the SG1/1 booth, one on the left side and one on the right side.



Warning

Replace the filter as needed or at most according to the indicated interval.



Fig. 6.60

Maintenance of activated carbon cabin air filter



Warning

Replace as needed or at most every 200 h of use of the filter itself or 36 months.

Follow the manufacturer's directions for maintenance.

Windshield washing system

Restore the level using detergents and antifreeze.

Cabin SG1/1




Fig. 6.61

A - Cabin GL9




Fig. 6.62

Cabin glass replacement



All cabin windows are approved. In case of breakage replace with original spare indicating the same approval details.

Replacing cabin lights



Maintenance operations are described in the section on electrical system maintenance.

6.8 Lubrication and greasing points

Add new grease at the indicated points. Perform the operation as needed or every 50 business hours.



Lower the lifter before lubricating the components.



Use lubricating grease recommended by the manufacturer.

Lubrication of the rear linkage

The rear linkage greasing points are as follows:

- Third point pin
- Vertical tie rods



Lower the lifter before lubricating the components.



Use lubricating grease recommended by the manufacturer.





Fig. 6.63



Lubrication of the front axle

Add new grease in the sleeve of the front axle center pivot pin.





Fig. 6.65

Lubrication of the braking leverages

Add new grease in the brake control return pin. The pre-positioned grease nipples are located on the underside of the tractor, in front of the traction connection unit.



6.9 Technical maintenance in case of long-term storage

tractor inactivity

If the vehicle/equipment on which the engine is installed remains idle, it is necessary to carry out some maintenance work to keep the engine in maximum efficiency.

In case of short periods of inactivity, carry out the following actions:

- check the efficiency of electrical contacts and, if necessary, protect them with an antioxidant spray;
- check the battery charge and the liquid level;
- carry out scheduled maintenance operations if necessary.



Warning

However, it is advisable to start the engine and bring it to operating temperature (70÷80°C) at least once a month.

If the engine is used for emergency applications, refer to the specific regulations in force for mandatory start-up: in the absence of specific regulations, it is recommended that it be started once a month.

When the tractor must be idle for more than a month, take the following precautions:

- Carry out the general cleaning of the tractor and especially of the body components, protect the painted parts by applying silicone waxes and the unpainted metal parts by means of a protective lubricant. Place the tractor itself in a covered, dry and possibly ventilated room.
- Seal the vents, the exhaust, the crankcase filler cap, the fuel tank cap, the flexible radiator overflow hose, and the transmission and plumbing filler cap using plastic bags and adhesive tape.
- Empty the diesel tank and fill it with new diesel to the maximum level.
- Change the engine oil and replace the filter (if necessary).
- Drain the engine coolant from the radiator and engine.
- Perform fuel filter cleaning.
- Lubricate all organs equipped with greasers. Perform general greasing.
- Grease all exposed metal surfaces such as the lifting cylinders and the steering cylinder stem with a light layer of grease.
- Lower the lift.
- Make sure that all controls are in a neutral position (including electrical switches).
- Do not leave the starter key inserted in the switch.
- Remove the batteries and store them in a cool, dry place away from sunlight. Keep the batteries charged-Spread stringy vaseline on the terminals and clamps
- Place stands or other supports under the axles, in order to keep the wheels suspended. If the tractor is raised, it is advisable to deflate the tires; otherwise, check the tire pressure periodically.
- Release the tension from the auxiliary drive belt and remove the belt from the air conditioner pulley
- Cover the tractor with a towel, avoiding the use of waterproof material (plastic sheets) because it retains moisture, encouraging the formation of rust.

If the tractor must be kept outside, follow the additional precautions.

- Cover the instrument panel, the control levers and the seat with layers of cardboard to protect them from sunlight.
- Clean the tractor thoroughly, touching up any painted surfaces that have been scratched or chipped.
- Wax or cover the entire tractor.
- Lift the tires off the ground and/or cover them to protect them from heat and sunlight.



Note

Disconnect the battery's ground cable only for short storage periods (20 to 90 days).

Restarting the tractor after a storage period

- Remove all covers placed on the tractor during the preparation of the storage.
- Clear all previously sealed openings.
- Remove any accumulated dirt or debris, especially around the engine and inside the engine compartment.
- Inspect the tires and check the inflation pressures. If the tractor had been placed on little stands, inflate the tires to the prescribed pressure and return the tractor to the ground.
- Re-tension the drive belt.
- Check if there are any liquid leaks under or around the tractor.
- Check the transmission/hydraulic oil level. Add oil if necessary.
- Check the engine oil level and, if necessary, refill or replace it according to the established frequency.
- Replace the engine oil filter according to the set frequency.
- Check the coolant level and, if necessary, refill or replace it according to the established frequency.
- Refill the fuel tank.
- Replace the fuel filter according to the set frequency.
- Replace the air filter according to the set frequency.
- Check the tightness of the hydraulic fittings.
- Check the integrity of the rubber sleeves and their fastening ties.
- Perform all maintenance procedures to be carried out daily or every 10 hours and the others scheduled as needed.
- Check the battery charge and the liquid level. Check the integrity and efficiency of the electrical contacts. Install the batteries and connect the cables.
- Diagnose engine functionality.
- Start and run the engine at idle speed, idle, for a few minutes.



Note

During engine operation at idle speed, visually inspect all instruments and lights to ensure proper operation.

- If no operating anomalies are found, bring the engine to operating temperature (70÷80°C).
- Check tractor systems and functions, including air conditioning.
- Turn off the engine and check again that the engine oil and coolant are level.



Warning

If there are traces of oil leaks, do not start the tractor until the cause has been determined and the necessary repairs have been made.



Warning

Some lubricants or engine components, even when idle, lose their characteristics over time, therefore, when evaluating maintenance intervals, it is also necessary to consider replacing them due to aging and not for operating hours.

The following is indicatively the maximum time required to maintain the chemical-physical characteristics of some components or lubricants.

1 year - Lubricating oil

1 year - Fuel filter cartridge

2 years - Coolant

7: INCONVENIENCES AND REMEDIES

Index

7.1	Troubleshoot search	7-	2
		-	-

7.1 Troubleshoot search

The information below is intended to help identify and correct any anomalies and malfunctions that may occur during use.

Some of these problems can be solved by the user, for all the others precise technical competence or special skills are required and therefore must be carried out exclusively by qualified personnel with recognized experience acquired in the specific field of intervention.



The activation of a visual and/or acoustic signal indicates the presence of an anomaly. In this case, turn off the engine immediately and consult the documentation provided by the manufacturer of the vehicle/device where the engine is installed.

Inconveniences, causes and remedies

Inconvenience	Cause	Remedy
During the ignition	Low battery	Recharge or replace the battery
phase, the control panel	Interrupted fuse	Replace fuse
and the engine do not turn on.	The electrical cables Disconnect or not guarantee continuity	Check electrical connections
	Faulty engine speed sensor	Replace the sensor
		Contact an authorized workshop
The engine is not running	Presence of air in the power supply circuit	Purge (see 'Power supply circuit purge')
	Dirty or defective injectors	Replace injectors
		Contact an authorized workshop
	Defective fuel pressure control valve	Replace the valve
		Contact an authorized workshop
	Failing start command	Replace the start command
		Contact an authorized workshop
	Presence by and/or in combustib impuritie le water s	Contact an authorized workshop
	Clogged fuel filter	Replace the filter (see 'Replacing fuel filter')
The Scooter	The electromagnet is out of order	Check the starter
Idle starter		Contact an authorized workshop
The Starter motor by	Low battery	Recharge or replace the battery
is not running	Interrupted electrical connection	Check electrical connections
	Worn out brushes	Replace worn out brushes
		Contact an authorized workshop

Inconvenience	Cause	Remedy
The engine stops after ignition	Presence of air in the power supply circuit	Purge (see 'Power supply circuit purge')
	Clogged fuel filter	Replace the filter (see 'Replacing fuel filter')
	Failing injection pump	Contact an authorized workshop
	Defective fuel pressure control valve	Replace the valve
		Contact an authorized workshop
	Presence by water and/or impurities in the fuel	Contact an authorized workshop
	Electrical cables are disconnected or do not provide continuity	Check electrical connections
The engine does not reach operating speed	Clogged fuel filter	Replace the filter (see 'Replacing fuel filter')
	Presence of air in the power supply circuit	Purge (see 'Power supply circuit purge')
	Failing injection pump	Contact an authorized workshop
	Dirty or defective injectors	Replace injectors
		Contact an authorized workshop
	Presence by water and/or impurities in the fuel	Contact an authorized workshop
	Clogged air filter	Clean or replace the filter
	Insufficient oxidizing air flow	Contact an authorized workshop
	Engine overheating	Contact an authorized workshop
	Overload	Reduce the load
Emission of black	Dirty or defective injectors	Replace injectors
smoke from the exhaust pipe		Contact an authorized workshop
Pipo	Defective supercharger turbine	Replacing the turbine
		Contact an authorized workshop

Inconvenience	Cause	Remedy
Slight white smoke	Oil level too high	Restore oil level
emission from the exhaust pipe	Worn segments	Check the compression
extidust pipe		Contact an authorized workshop
	Worn valve guide	Contact an authorized workshop
Abundant emission of	Burnt head gasket	Contact an authorized workshop
white smoke from the	Failing water pump	Replace the pump
exhaust pipe		Contact an authorized workshop
		Replace the belt
		Contact an authorized workshop
	Thermostatic valve failed	Replace the valve
		Contact an authorized workshop
	Insufficient coolant	Top up, if necessary (see 'Engine coolant level control')
The pressure gauge	Failing pressure gauge	Check or replace the pressure gauge
indicates insufficient		Contact an authorized workshop
engine oil pressure and the relevant light comes on	Insufficient oil level	Restore oil level (see 'Engine Oil Level')
	Failing oil pump	Check or replace the pump
		Contact an authorized workshop
	Faulty sensor	Check and replace the sensor if necessary.
		Contact an authorized workshop
	Clogged engine oil filter	Replace The strainer oil Engine (see 'Engine Oil Filter Cartridge Replacement')
The spies liquid temperature by	Insufficient coolant	Restore engine coolant level (see 'Engine coolant level control')
cooling It turns on	Load cap overpressure valve blocked	Replace the cap
	Failing water pump	Replace the pump
		Contact an authorized workshop
	Thermostatic valve failed	Replace the valve
		Contact an authorized workshop

Inconvenience	Cause	Remedy
The spies liquid	Broken or worn belt	Replace the belt
temperature		Contact an authorized workshop
by cooling It		
cooling It turns on		
Power reduction	Clogged fuel filter	Replace the filter (see 'Replacing fuel filter')
	Presence of air in the power supply circuit	Purge (see 'Power supply circuit purge')
	Failing injection pump	Replace the pump
		Contact an authorized workshop
	Dirty or defective injectors	Replace injectors
		Contact an authorized workshop
	Clogged air filter	Clean or replace the filter
	Engine overheating	Contact an authorized workshop
	Insufficient oxidizing air flow	Contact an authorized workshop
The battery light turns	Alternator does not charge the battery	Check and possibly replace the alternator
on	, mornator decement smarge and battery	Contact an authorized workshop
		Contact an authorized workshop
The oil pressure light	Insufficient engine oil pressure	Turn off the engine.
turns on		Contact an authorized workshop
Water in fuel indicator light comes on	Presence of water in the fuel filter	Bleed water from the fuel filter (see "Bleeding water from fuel filter").
The spies Engine It turns on	Faulty sensor	Contact an authorized workshop
The spies Filter Anti-particulate It turns on	Particulate filter	Regeneration of the Particulate Filter is required, see chapter "RULES OF USE."







FBM97101197

Goldoni Keestrack srl Via Canale 3, 41012 Migliarina di Carpi Modena, ITALY T +39 0522 640111 reception@goldoni-keestrack.net